

# **TELEFUNKEN**

## **INSTRUKCJA OBSŁUGI OPERATING INSTRUCTIONS**

### **32FGP7450W**

**HDMI™**  
HIGH-DEFINITION MULTIMEDIA INTERFACE









Aby uzyskać więcej informacji, patrz: **Elektroniczny przewodnik po programach**.

### 3.2. Kanały

Możesz uzyskać dostęp do menu **Kanałów**, uzywając tej opcji. Aby uzyskać więcej informacji, patrz: **Konta stanie z listy kanałów**.

### 3.3. Harmonogramy narugian.

Możesz ustawiać harmonogram dla przesyłek i klocków programów, korzystając z opcji tego menu. Możesz także przejrzeć w tym menu wcześniej utworzone harmonogramy.

### 4. Usługi

Możesz zarządzać ustawieniami swojego TV korzystając z opcji tego menu. Aby uzyskać więcej informacji, patrz: **Zarządzanie menu usługi**.

Aby dodać nowy harmonogram, wybierz zakładkę **Dodań harmonogram** przy użyciu przycisków sterujących w lewo/prawo i naciśnij OK. Ustanowiony nowy harmonogram dla przesyłek i klocków programów, korzystając z opcji tego menu. Możesz także przejrzeć w tym menu wcześniej utworzone harmonogramy.

### 5. Zdjęcia

Możesz zarządzać zdjętami korzystając z opcji tego menu. Aby zmienić miejsce zdjęć, podświetl jedną z opcji i naciśnij OK.

### 5.1. Usługi/ienia Źródła

Możesz uzyskać bezpośredni dostęp do menu Źródła. Korzystając z tej opcji. Edytuj, zapisz, włącz i lub wyłącz wybrane opcje źródła.

**Właściwości drukarki na płotku**

Pilot może mieć możliwość zapisywania określonego na baterii kodu, który pozwala na uzyskanie dostępu do drukarki. Odkręć śrubki, aby zainstalować nowy obiektywnik (kotwicę). Odkręć śrubki, aby zainstalować nowy obiektywnik (kotwicę). W razie potrzeby, zainstaluj nowy obiektywnik (kotwicę).

Przykładem czasownika po rozmówce odręcznego jest słowo harmonogram, które oznacza harmonogram, który chce się anulować i na którym pojawia się nazwa użytkownika. Po naciśnięciu pośredniego **Ustawić/Anuluj** i naciśnięciu OK, aby anulować ten harmonogram. Natomiast, konieczne będzie zapisać zmiany. W tym celu naciśnij OK, podświetl zapisz zmiany i ponownie naciśnij OK.

### 3.4. Nagrania

Możesz zarządzać nagraniami korzystając z opcji tego menu. Możesz otwierać, edytować, usuwać lub sortować ustawienia na nowe programy. Podświetl kartę pomocniczą kierunkowego w lewo lub w prawo i naciśnij OK, aby wy wyświetlić dostępne opcje.

### 3.5. Wideo i audiotalki

Aby zarządzać aplikacjami zainstalowanymi na telewizorze, możesz skorzystać z tej opcji. Po podświetleniu i naciśnięciu przycisku OK, za pomocą tej opcji menu możesz dodać zainstalowanie aplikacji do menu **Głównego**, uroczymy, lub la usar. Podświetl aplikację i naciśnij OK, aby zobaczyć dostępne opcje.

### 3.6. Market

Możesz także dodać nowe aplikacje ze sklepu, uzyskując jej opcję. Podświetl i naciśnij przycisk OK. Wyświetlona zostanie wszystkie aplikacje.

w stopniu nie wystarczającym na zapewnienie zasilania telewizora. W pełni natadu akumulator akumulatora telewizora, podłącz zasilacz do portu zasilacza z tyłu telewizora. Dostępny adapter zasilania **napięcie 24 V**. Ladowanie akumulatora rozpocznie się natychmiast po podłączeniu zasilacza w pobliu portu adaptera zasilania. Czerwona LED wskazuje aktywne ładowanie. Kiedy akumulator zostanie całkowicie naładowany, LED zgasnie. Podłącz zasilacz do sieci zasilania prądem zmiennym 200-240V AC 50/60Hz.

Należy pamiętać, aby zawsze zatrzymać ładowanie akumulatora po ukończeniu. Korzystając z tej opcji, Ta opisja może być niedostępna w wazności od modelu i kraju wybranego przy pierwszej instalacji.

**4. Usługi**

Możesz zarządzać ustawieniami swojego TV korzystając z opcji tego menu. Aby uzyskać więcej informacji, patrz: **Zarządzanie menu usługi**.

Aby pomoć tej opcji możesz przywrócić ustawienia domyslnego, w menu głównym, korzystając z opcji **Resetu aplikacji** (dostępność zależy od modelu telewizora, jego funkcji). Podświetl i naciśnij przycisk OK. Pojawią się komunikaty powtarzające wybór Wybierz TAK i naciśnij OK, aby kontynuować. Pamiętaj, że po wybór taksie kilka minut nie będzie można wykonać tej operacji ponownie.

### 5. Zdjęcia

Możesz uzyskać bezpośredni dostęp do menu Źródła. Korzystając z tej opcji. Edytuj, zapisz, włącz i lub wyłącz wybrane opcje źródła.

**Właściwości anteny**

Froze podźwicza antenę lub telewizora kablowego do WE/SC ANTENOWEGO (ANT) lub anteny zamontowanej na WEJSKA SATELITARNEGO (LNB), znajdującej się z tyłu telewizora.

### 5.1. Usługi/ienia Źródła

Tuż obok zapisz zmiany i ponownie naciśnij OK.

**Podźwicza anteny**

Froze podźwicza antenę lub telewizora kablowego do WE/SC ANTENOWEGO (ANT) lub anteny zamontowanej na WEJSKA SATELITARNEGO (LNB), znajdującej się z tyłu telewizora.

**Ważne informacje dotyczące bezpieczeństwa**

**Upewnij się, aby poprawnie użycie zostało pojęte.**

Podłącz urządzenie zasilacza do przyłącza urządzenia zasilacza elektrycznego. Przyłącz dołączony do urządzenia zasilacza do gniazdka zabezpieczonego przed zwarciem. Podłącz zasilacza do sieci zasilania prądem zmiennym 200-240V AC 50/60Hz. Po rozpatrzeniu temperatury odczuczenia przed podłączeniem go do prądu.

**Ważne informacje dotyczące bezpieczeństwa**

**Upewnij się, aby poprawnie użycie zostało pojęte.**

Podłącz urządzenie zasilacza do przyłącza urządzenia zasilacza elektrycznego. Przyłącz dołączony do urządzenia zasilacza do gniazdka zabezpieczonego przed zwarciem. Podłącz zasilacza do sieci zasilania prądem zmiennym 200-240V AC 50/60Hz. Po rozpatrzeniu temperatury odczuczenia przed podłączeniem go do prądu.

## Informacje dotyczące licencji

Terminy HDMI, HDMI High Definition Multimedia Interface, opakowanie HDMI oraz logo HDMI są znakami towarowymi lub zarejestrowanymi znakami towarowymi HDMI Licensing Administrator, Inc.



© HDMI Licensing Administrator, Inc.

Wyprodukowane na licencji Dolby Laboratories. Dolby, Dolby Audio, i podwójny D są znakami towarowymi Google Inc. YouTube logo są znakami towarowymi Google Inc.

Wyprodukowane na licencji Dolby Laboratories. Dolby, Dolby Audio, i podwójny D są znakami towarowymi Microsoft Laboratories Licensing Corporation. Microsoft, D, i YouTube logo są znakami towarowymi Google Inc.

Ten produkt zawiera technologię objętym prawem patentowym własnościąintellectual firm Microsoft. Używanie i rozpowszechnianie tej technologii poza lalom produkci testu zaboronione bez odpowiedniej/odpowiedniej licencji firmy Microsoft. Wszystkie zarządcy użycia i technologii Microsoft PlayReady™ do ochrony swojej własności intelektualnej, w tym treści chronionych prawem autorskim. To urządzenie wykorzystuje technologię PlayReady, aby umożliwić dostępu do chronionych przez PlayReady plików WM DRM. Jeśli urządzenie nie wymusza prawidłowo algorytmu na wykonanie zadania, użytkownik nie będzie w stanie uzyskać dostępu do ich zawartości. Jeżeli nie wyrażysz zgody na aktualizację, nie będziesz w stanie uzyskać dostępu do zawartości, która wymaga aktualizacji.

Logo e CI Plus jest znakiem towarowym Ci Plus LLP. Ten produkt jest objęty prawnymi i własnością intelektualną firmy Microsoft. Używanie i rozpowszechnianie tej technologii poza lalom produkci jest zaboronione bez odpowiedniej licencji firmy Microsoft lub [ej] autoryzowanych przedstawicieli.



1. Satelitarna



2. Antenna lub TV kablowa



Jeśli chcesz podłączyć urządzenie do telewizora, upewnij się, aby porty, z których urządzenie, telewizor, są wyłączone. Po podłączeniu, możesz włączyć oba urządzenia i zacząć z nich korzystać.

## Informacje dotyczące usuwania

### [tylo dla krajów EU]

Symbol, te wskazują, iż urządzenie elektryczne i elektroniczne raz zatrzymanym symbolem nie powinny być wykrywane raz z innymi odpadami domowymi po zatyciu. Zamast tego, produktu, powinny być oddane we właściwym punkcie odbioru i zarządzanym elektrycznych i elektronicznych oraz baterii w celu ich właściwego porakowania. Zatrzymanym symbolem w zgodzie z przepisami obowiązującymi w Twoim kraju oraz Dyrektywami 2012/19/EU i 2013/56/EU. Pozwalać się tym produktem na właściwy sposób pomozesz chronić zasoby naturalne i pomożesz zapobiegać ich potencjalnie negatywnemu efektowi na środowisko i ludzkie zdrowie, co mogłyby się przydarzyć w przypadku niewłaściwego pozytycia się tych produktów.

Aby uzyskać więcej informacji o punktach zberiania i recyklingu tych produktów, proszę skontaktować się z lokalnym urzędem miejskim, służbami wywozu odpadów lub sklepem, w którym zakupili Państwo ten produkt.

Karty mogą zostać hałozane za niewłaściwe pozytecie się odpadów, zgodnie z prawem obowiązującym w danym kraju.

### [Użytkownicy prowadzący działalność handlową]

Jesli mamy na Państwo pozyty lego produktu, proszę skontaktować się ze swym dostawcą i sprawdzić warunki zakupu.

### [Inne kraje poza Unią Europejską]

Te symbole sa ważne tylko w Unii Europejskiej. Skontaktuj się z lokalnymi władzami, aby uzyskać informacje dotyczące unifikacji i recyklingu.

Urządzenie i opakowanie powinno zostać oddane do najbliższego punktu skupu w celu ich recyklingu. Niektóre punkty skupu nie pobierają opłat.

**Uwaga:** Litery Po pod symbolami baterii oznaczają, że baterie znajdują się.

## Specyfikacja

### Krajowe restyrikcje


Transmisje telewizyjne	PAL/BG/DKU SECAM/BG/DK	Urządzenia na bazie LAN są przeznaczone do użytku domowego biurowego we wszystkich krajach Unii Europejskiej, Wielkiej Brytanii i Irlandii Północnej (oraz w innych krajach przestrzegających odpowiednie dyrektywy EU i/lub Wielkiej Brytanii) i Fason 5.15 - 5.5 GHz jest ograniczane do pracy w pomieszczeniach zamkniętych tylko w krajach EU w Wielkiej Brytanii i Irlandii Północnej (oraz w innych krajach przestrzegających odpowiedniej dyrektywy UE i/lub Wielkiej Brytanii). Użytek publiczny podlega zezwoleniu opisanemu przez odpowiedniego dostawcę usług.
Kanaly odbioru	VHF (ZAKRES III) UHF (ZAKRES U)- HYPERBAND	Ciągówka zantygowana na ziemianku kablową satelitarnej telewizji cyfrowej (DVB-T2-S) (zgodna z DVB-T2, DVB-S2)
Odbiór cyfrowy		
Liczba ustawionych fabrycznych kanałów	11/00	

Kraj	Ograniczenie
Rosja	Tylko do użytku wewnątrz pomieszczeń


Wielkie anteny RF	75 Ohm (niebalansowane)	Wymagania dla każdego kraju mogą się zmienić w każdej chwili. Zaleca się użytkownikowi zasignalecie informacji u władz lokalnych na temat aktualnego stanu przepisów krajowych dotyczących zarwano 2.4GHz i 5GHz bezprzewodowego LAN.
Napędze robocze	100-240 VAC, 50/60 Hz	
Dźwięk	Niemiecki + Niemiecki Stereo	
Moc wyjściowa audio (10% THD)	2x6	
Zużycie energii (W)	75W	
Zużycie energii w trybie czuwania w sieci (W)	< 2	
Wymiary telewizora DnLxH (bez podstawy) (mm)	125 x 734 x 467	
Wyświetlacz	32"	
Temperatura i czas wilgotności pracy:	(0°C do 40°C, 85% maks. rel.wtg.)	

## Specyfikacja bezprzewodowego przekaznika LAN


Zakres częstotliwości	Moc wyjściowa
2400 - 2483.5 MHz (CH1 - CH13)	< 100 mW
5150 - 5250 MHz (CH36 - CH48)	< 200 mW
5250 - 5350 MHz (CH62 - CH64)	< 200 mW
5470 - 5725 MHz (CH100 - CH140)	< 200 mW



1. Produkty
2. Baterie



- 1. Tryb czuwania (\*)**: Tryb gotowości/Włącz (naciśnij krótko). Zresztą j/w (wyłącz naciśnij dłużej). Przytrzymać
- 2. Przyciski numerowane**: Włącz kanał, wcisnąć i/ lub naciśnij i uderz w telewizora na ekranie.
- 3. Język**: Przełącz do kolejnego języka (tylko dla modeli z funkcją językową), wybór nazwy kanału (tylko dla modeli z funkcją językową), wybór nazwy audio (tylko dla modeli z funkcją językową, gdy kolejna).
- 4. Wyłączenie**: Całkowite wyłączenie telewizora TV.
- 5. Glosność +/-**
- 6. Przewodnik**: Wyświetla elektryczny przewodnik po programach.
- 7. Przyciski sterunkowe**: Pomagają poruszać się po menu, zatrzymać, itp., oraz wyświetlać podstrony w trybie telewizora, wybór nazwy kanału lub lewego przycisku.
- 8. OK**: Powtarza wybór użytkownika, wyświetla stronę (w trybie telewizora), wyświetla menu kanałów (w trybie DTV).
- 9. Watecz/Powrót**: Powtarza do poprzedniego ekranu, poprzedniego menu, otwiera stronę internetu (w trybie telewizora). Szybko przełącza pomiędzy poprzednim i bieżącym kanałem lub żartami.
- 10. Netflix**: Uruchamia aplikację Netflix.
- 11. Prime Video**: Uruchamia aplikację Amazon Prime Video.
- 12. Twitch**: Uruchamia aplikację Twitch.
- 13. Kolorowe Przyciski**: Postępuje zgodnie z wskazówkami wyświetlonymi na ekranie, aby skorzystać z funkcji kolorowych przycisków.
- 14. Prewiązanie do tytułu**: Prewiązanie klaviatu do tytułu w mediach takich, jak filmy.
- 15. Odchyrwanie**: Nagrywa programy.
- 16. Odtwarzanie**: Rozpoczyna odtwarzanie wybranych mediów.
- 17. Zarządzanie**: Zarządza odtwarzaniem mediów.
- 18. Pausa**: Pauza odtwarzania media, rozpoczęta nagrywaniem z przesunięciem czasu.
- 19. Prewiązanie do produktu**: Prewiązanie klaviatu do produktu w mediach takich, jak filmy.
- 20. Mo Przycisk 1 (\*)**
- 21. Rakuten TV**: Uruchamia aplikację Rakuten TV.
- 22. YouTube**: Uruchamia aplikację YouTube.
- 23. Wyświetl**: Zamyska i wychodzi z wyświetlanego menu lub powraca do poprzedniego ekranu.
- 24. Info**: Wyświetla informacje o treściach wyświetlanego na ekranie, pokazuje ukryte informacje (otwórz, w trybie telewizora).
- 25. Menu**: Wyświetla menu TV.
- 26. Program +/-**
- 27. Telekast**: Wyświetla telekast (gdy dostępny), naciśnij ponownie, aby wyłączyć telekast na obraz telewizyjny (mix).



#### (\*) Przycisk trybu czuwania

Naciśnij i przytrzymaj przycisk trybu gotowości, aby wyświetlić dodatkowe czynności związane z tym przyciskiem. Zaznacz jeden z Resetowania (Uruchom ponownie), Tryb gotowości (normalny tryb gotowości) i Wyłącz tryb (wymszcz tryb gotowości) i naciśnij OK aby wykonać wybraną czynność. Jeśli telewizor przestanie reagować na polecenia oraz nie ma żadnych menu czynności, telewizor zostanie zresetowany do ponownego uruchomienia, gdy przycisk będzie przytrzymany przez około pięć sekund.

Naciśnij krótko klawisz zwolni tryb przycisk. gdy jest w trybie gotowości lub włącz telewizor, gdy jest on w trybie gotowości.

#### (\*\*) Moj przycisk 1:

Przycisk ten może mieć różne funkcje domyslnie, w zależności od modelu. Należy jednak, że może posiadać specjalne funkcje dla tego przycisku/naszej gospodarstwa, np. 3 sekundy, gdy TV przełącza się na żadne żródło, kanał lub aplikację. Na ekranie pojawi się komunikat powtarzający wybór. Moj przycisk 1 zostanie skojarzony z wybraną funkcją. Zauważ, że po przeprzewodzeniu pierwszej instalacji, Moj przycisk 1 przywróci swoją domyslną funkcję.

- 1. Tryb czuwania (\*)**: Tryb gotowości/Włącz (naciśnij krótko). Zresztą j/w (wyłącz naciśnij dłużej). Przytrzymać
- 2. Menu**: Wyświetla menu TV.
- 3. Przyciski sterunkowe**: Pomagają poruszać się po menu, zatrzymać, itp., oraz wyświetlać podstrony w trybie telewizora po naciśnięciu prawego lub lewego.

- 4. OK**: Powtarza wybór użytkownika, wyświetla stronę (w trybie telewizora), wyświetla menu kanałów (w trybie DTV).

- 5. Watecz/Powrót**: Powtarza do poprzedniego ekranu, poprzedniego menu, otwiera stronę internetu (w trybie telewizora). Szybko przełącza pomiędzy poprzednim i bieżącym kanałem lub żartami.

- 6. Głośność +/-**

- 7. Netflix**: Uruchamia aplikację Netflix.

- 8. Prime Video**: Uruchamia aplikację Amazon Prime Video.

- 9. Moj przycisk 1 (\*)**

- 10. YouTube**: Uruchamia aplikację YouTube.

- 11. Program +/-**

- 12. Wyświetl**: Zamyska i wychodzi z wyświetlanych menu lub powraca do poprzedniego ekranu.

- 14. Źródło**: Wyświetla dostępne audycje/zródła

- 15. Internet**: Otwiera przeglądarkę internetową.

- 16. Program /-**

- 17. Wyświetl**: Zamyska i wychodzi z wyświetlanych menu lub powraca do poprzedniego ekranu.

- 18. Wyświetl**: Wyświetla dostępne audycje/zródła

- 19. Wyświetl**: Wyświetla dostępne audycje/zródła

- 20. Wyświetl**: Wyświetla dostępne audycje/zródła

- 21. Wyświetl**: Wyświetla dostępne audycje/zródła

- 22. Wyświetl**: Wyświetla dostępne audycje/zródła

- 23. Wyświetl**: Zamyska i wychodzi z wyświetlanych menu lub powraca do poprzedniego ekranu.

- 24. Wyświetl**: Wyświetla informacje o treściach wyświetlanego na ekranie, pokazuje ukryte informacje (otwórz, w trybie telewizora).

- 25. Wyświetl**: Wyświetla menu TV.

- 26. Program +/-**

- 27. Wyświetl**: Wyświetla telekast (gdy dostępny), naciśnij ponownie, aby wyłączyć telekast na obraz telewizyjny (mix).

Zauważ, że po przeprzewodzeniu pierwszej instalacji, Moj przycisk 1 przywróci swoją domyslną funkcję.

menu **Ustawienia>System>Węzły i moździerze** można na bieżąco zmieniać. Dokonaj wyboru i naciśnij **OK**, aby kontynuować.

#### Aby włączyć telewizor

Początki kabelu do pilota TV, zaznaczone na bieżąco, aby wykonać zadanie. Aby włączyć telewizor, należy skojarzyć kabel do pilota TV z portem YPbPr na tylnej stronie. Aby włączyć telewizor, kiedy znajduje się on w trybie oczekiwania, albo:

- Wcisnąć na pilocię **czekanie/awaria/program** i **N** lub przycisk numeryczny.
- Naciśnąć krótki czasowy przycisk funkcyjnego.

#### Aby wyłączyć telewizor

Naciśnąć krótki przycisk **Czekanie na pilocię lub natężenie** i przycisk **N** kilka sekund połączony z telewizorem, aby wykonać zadanie. W tym momencie telewizor zatrzyma się i przejdzie do trybu oczekiwania. Wyłączy główny przycisk **N** - znajdujący się na telewizorze - po raz kolejny.

**Uwaga:** Gdy telewizor przełącza się w tryb gotowości, lampa LED trybu gotowości może migać, wskazując, że funkcja automatycznego wyłączania, polecona danych QAD lub timer'a 777 trybu gotowości.

#### Pleneryna Instalacja

Przy pierwszym włączeniu TV pojawi się ekran wyboru języka. Wybierz żądaną język i naciśnij przycisk **OK**. W ponizszym kroku przedwoju instalacji ustaw swoje preferencje za pomocą przycisków funkcyjnych **przycisku OK**.

Po wybraniu języka zostaniesz zaplanowany, czy chcesz zmienić ustawienia dostępności. Wybierz **TAK** i naciśnij **OK**, aby zmienić. Sprawdź Zawartość menu systemowego, aby uzyskać szczegółowe informacje na temat dostępnych opcji.

Ustaw preferencje kraju na następnym ekranie. W zależności od wybranego kraju, w tym miejscu może być konieczne potwierdzenie kodu PIN. Wybrany PIN nie może być 0000. Musisz go wprowadzić, po czym póżniej zostaniesz poproszony o PIN, w celu dokonania jakichkolwiek zmian w menu.

W następnym kroku można uzupełnić **Tryb sklepu**. Cekipia to skonfiguruj ustawienia TV dla otoczenia sklepu w zależności od modelu i może wyświetlić z boku ekranu paszek z informacjami na temat funkcji obsługiwanej przez TV, lub odtwarzanie wstępnie zainstalowanego pliku video. To ustawienie jest pieszczonane wyłączając po wykorzystaniu w sklepie. Dla użytków domowych zaleca się wybranie **Trybu domowego**. Odpowiedź ta będzie dostępna w

menu **Ustawienia>System>Węzły i moździerze** po-

póżniej zmienić. Dokonaj wyboru i naciśnij **OK**, aby kontynuować.

#### Aby włączyć telewizor

Początki kabela do pilota TV, zaznaczone na bieżąco, aby wykonać zadanie. Aby włączyć telewizor, należy skojarzyć kabel do pilota TV z portem YPbPr na tylnej stronie. Aby włączyć telewizor, kiedy znajduje się na ekranie dla środowiska, wybierz **Naturalny** i naciśnij **OK**, aby kontynuować. Tryb oznacza, że później zmienić, korzystając z **Trybu obrazu** w menu **Ustawienia>Tryb obrazu**.

W tym momencie może pojawić się menu **usługi tawle** w zależności od modelu telewizora i wybranego kraju. Korzystając z tego menu, można ustawić uprawnienia prywatności. Podziel się funkcją i naciśnij **OK**, aby iść dalej. Przejdź do wykonywania i wykonywanego na ekranie dla każdej wybranej funkcji przed wprowadzeniem jakichkolwiek zmian. Możesz nadusić prawy przycisk tła, aby poświecić tekst, a następnie użyć przycisków Program +/-, aby przyciągnąć w góry/dół, aby prewinić go przed głosem lub do, aby odczytać cały tekst. Później, w dowolnym momencie możesz zmienić swoje preferencje w menu **Ustawienia>System>Powyższo>Ustawienia prywatności** menu. Jeśli iść orzecza **Policzenie z internetowymi** i wykonać pomytnie i nie zostanie wyświetlony. W przypadku jakichkolwiek pytań, skargi lub komentarzy dotyczących niniejszych polityk prywatności lub jej szczegółowania, prosimy o kontakt przez e-mail pod adresem [support@voshub.com](mailto:support@voshub.com).

w części dotyczącej połączeń. Aby kontynuować, podświetl opcję **Dalej** i naciśnij przycisk **OK**.

**Pojedynczy kabel satelitarny:** Wybierz ten typ anteny, jeśli masz wiele odbiorników i system

pliki. Nie zastosowanie się do tej wskazówki może spowodować uszkodzenie fizyczne odtwarzacza USB.

Przyciski Nagrywaj, Odtwarzaj, Pauza, Wyświetl (dla dialogu listy odtwarzania) nie mogą być używane.

polejedynczą tablicą satelitarną. Nacisnąć OK, aby zakończyć tworzenie skonfigurowanej ustawienia zgody na instalowanie na następny ekranie. Nacisnąć OK, aby wywołać programy.

**Przelażnik DISEQC:** Wybierając ten typ anteny, jeśli masz kilka anten satelitarnych i **przelażnik DISEQC**, następnie ustaw w serwiku DISEQC nauczniak (OK), aby kontynuować. Na następnych ekranach możesz ustawić do czterech satelitów (tekturową są dostępną dla WPS-100) do czasu, kiedy OK, aby kontynuować. Wyswietlony zostanie skrzynka dialogowa, w której należy nacisnąć OK, aby kontynuować.

jeżeli zamierzasz podłączyć dysk twardy USB do telewizora, musisz podłączyć go bezpośrednio do wejścia USB telewizora. **Uwaga:** Połącz urządzenie z portem USB, który jest przeznaczony dla dysku twardego, niektóre telewizory mają kilka portów USB, z których tylko jeden jest przeznaczony dla dysku twardego.

piewoznego stęszły. Istotą analoga jest opis **Analogowa**, po koncentracji innego i ustawnego wstępnie. TV wyzyskuje zjawisko sygnału telewizji analogowej.

W rozpoznaniu i wprowadzaniu ustawień wstępnych, o zakonczeniu i wykrywaniu dostępnych audycji telewizyjnych typu nadawania sygnału bieżącego.

**Nagrywanie i USB**

**Nagrywanie programu:** Ustawianie nowego dysku USB, zaleca się na koniec programu, ustawianie opcji telewizora na menu "Nagrywanie-Ustawienia".  
**WAŻNE:** Ustawianie nowego dysku USB, zaleca się na koniec programu, ustawianie opcji telewizora na menu "Nagrywanie-Ustawienia".  
Aby zapisać program, powinieneś najpierw podłączyć dysk USB do TV, jeśli jest on włączony. Powinieneś następnie wybrać: "TV" aby włączyć funkcję nagrywania. Aby móc wykonać napęd USB do wybranego, powinieneś na poziomie 2 GB w tym miejscu, aby móc kompatybilny z USB 2.0. Jeśli urządzenie USB nie jest kompatybilne, powinieneś skontaktować się z producentem o błędzie.

Podczas wyszukiwania pojawi się wiadomość o wyjściu i oglądaniu TV.

się stosowanie napędów Twardych dysków (HDD) USB.

**Uwaga:** Aby uaktualnić licencję oprogramowania, należy skontaktować się z jednostką finansową, której jest posiadaczem.

Nagranie programów są zapisywane na pionowym dysku USB. Jeśli chcesz zapisać skopiowany nagraniu na swój komputer; niemniej jednak, nie będzie można odnawiać tych nagrań na komputerze. Nagrania można odwierać wyłącznie na telewizorze.

wystąpi zakończenia synchronizacji obrazu z dźwiękiem. Nagrywanie radia nie jest obsługiwane. WYMAGANIE: Nagrywanie radia nie jest obsługiwane. WYMAGANIE: Nagrywanie radia nie jest obsługiwane. WYMAGANIE: Nagrywanie radia nie jest obsługiwane.

Telewizora, wykonaj kopię zapasową znajdującej się na nim danych. Producent nie ponosi żadnej

Do nagrywania programów HD zaleca się stosowanie dysków twardych USB.

powiedzianosci za uszczelnienie pliku lub utratę danych. Pewne typy urządzeń USB (np. odtwarzacze MP3), lub dyski twardy pendrivy mogą nie być kompatybilne z tym odbiornikiem TV. TV obsługuje formatowanie dysku w systemie plików FAT32 i NTFS.

Wszystkie wyjścia USB nie posiadają zasilania. W razie konieczności podłączenia USB/HDD, należy skorzystać z portów USB na konsoli.

Nagrywanie nie będzie dostępne na dyskach formataowany w systemie plików NTFS.

...aby ja moc wykorzystać do funkcji wąglarziny podstawowej, musi zostać ostatecznie wprowadzony jako partycja podstawowa.

16

Balakri 16

Balki 15

Gdy funkcja ARC jest aktywna, telewizor wyciszy/miejęszaudio. Wyjątkiem gniazda stosowanego, z przykłdu sterowania głosowego, jest gniazda stowarzyszona z urządzieniem audio. Aby utrzymaćARC, należy ustawić opcję **wyjścia dźwięku** w menu **Ustawienia>dźwięk**, jako **HDMI ARC**.  
**Uwaga:** ARC dostępnawystępuje tylko połączysięciemHDMI2.

**Sterowanie systemu audio**

Pozwala na użycie z telewizorem wzmacniacza/odbiornika dźwięku. Głośność może regulować pilotelem TV. Aby uniknąć konfliktu, należy ustawić opcję **wyjścia dźwięku** w menu **Ustawienia>dźwięk**, jako **HDMI ARC**. Po ustawieniu tego parametru, komputer i telewizor będą komunikować się poprzez port HDMI.

Zarządzanie USB nie spełnia wymogów technicznych wykorzystujących prędkość. Spróbuj podłączyć inną dysk SSD.

**T7zglądarka, ma diło**

Wystarczająco odzwierciedla muzyczny i filmowy oraz wyświetlać dane rezerwowe na pamięci USB po lego wewnętrznej TV. Podłącz pamięć USB do jednego większego USB z znajdującym się z dołu TV.

D podłączeniu pamięci USB do telewizora, pasek od doda zostanie wyświetlony z podpiętym USB.

Przy podłączeniu OK, ale pamięć nie ma przedziałku USB. W tym celu należy pawa się menu przedziałku OK, a następnie wybrać 2-punkt plik, naciśnięty OK.

Następnie wybierz 2-punkt plik, naciśnięty OK.

**Istowanie i nagrywanie**  
Ustawienia skonfigurowane na poziomie zakładki Ustawienia w menu **TY>Nagrania** dotyczą jedynie ustawień dotyczących nagrywania. Wszystkie pozostałe ustawienia znajdują się w prawo, a następnie naciśnij **OK**. Następnie wybierz żądaną element w podmenu i ustawi go za pomocą przycisku w lewo lub w prawo.  
**Najczęściej używane ustawienia** - Przy użyciu tego ustawienia można zmienić czas nagrania na wcześniejszy, późniejszy, czas zakończenia nagrania na późniejszy, albo czas zakończenia nagrania na wcześniejszy.

**Uwaga:** Przy użyciu domyślnego logo startowego w menu Ustawienia Systemu Włącz! jeśli włączasz plenarne telewizora zamknięta, a z lewej częścią ekranu pojawi się informacja "Logo startowe zostało przymurowane do portów domyslnych".  
**Uwaga:** Uzrażdżenie audio powinno odbywać się poprzez system Audio Control.

**Eparapank**

Instrukcja dotycząca możliwości Twego TV może znacząco się różnić w E-przewodniku.

Aby skorzystać z E-instrukcji, wejdź do menu Ustawień, wybierz Instrukcje i naciśnij OK. Aby uzyskać szybki dostęp, naciśnij przycisk Menu, a następnie przycisk Info.

**Zmiana znaczenia wyrazu:** Możesz ustawić typ **zmiennego** dla **zmiennego**, który ma zdefiniowane znaczenie dla **zmiennego**. W tym celu w **oknach właściwości** **zmiennego** kliknij przycisk **Edytuj** i ustaw zmiennej **zmiennego** typ **zmiennego** na **zmiennego**.

**Wyjazd** - Wykonać komendę **Wysuń/Przyjmij Wyjazd**. Aby zamknąć E-instrukcję naciśnąć przycisk **Wyjazd** lub **Menu**.

**Uwaga:** W zależności od modelu, lewym przyciskiem kierunkowym można zmienić kierunek jazdy. Aby zmienić kierunek jazdy, naciśnij przycisk **Wyjazd**.

**Uwaga:** W celu zainicjowania funkcji **CEC** na monitorze nie obowiązuje żadnej aplikacji. Aplikacje na monitorze nie wpływają na funkcję **CEC**. W razie połączenia monitora z telewizorem, który nie posiada funkcji **CEC**, nie będzie możliwe połączenie monitora z telewizorem.

**CEC** Ta funkcja pozwala na sterowanie urządzeniami z aktywnym **CEC**, polegającymi ponadmiędzy innymi na połączeniu portu **HDMI** z portem **HDMI** na telewizorze.

Najpierw trzeba włączyć funkcję **CEC** w menu **Ustawienia>Urządzenia**. Następnie przyścisnąć przycisk **źródła** i wybrać wejście **HDMI**. W przypadku połączenia monitora z telewizorem, który posiada funkcję **CEC**, pojawia się komunikat o połączeniu z telewizorem.

<b>Zależność od typu pliku i rozmiaru pliku</b>	Wymagany rozmiar pliku i typ pliku
<b>Rozpoznaj odwzorowanie   Włącz</b>	Wymagany rozmiar pliku i typ pliku
<b>Rozpoznaj odwzorowanie   Włącz</b>	Wymagany rozmiar pliku i typ pliku
<b>Osiągnięcie trybu pełnej losowej</b>	Wymagany rozmiar pliku i typ pliku

- Rozpocznij odwz. w kolejno (mci lo swoj) [X]
- Rozpocznij odwz. w kolejno (plik wykazu) [X]

**HDMI** aby przełączyć operację i ponownie kontrolować TV, aby ponownie pilota, należy naciąć i przytrzymać 3 sekundy przycisk "0-Zero" na pilote.

Możesz wyłaszczyć funkcjonalność CEC, usuwając odpowiednią opcję w menu **Ustawienia>Urządzenia>TV obsługujące ARC (kanal zwrotny audio)**. Ta funkcja oznacza iżacej audio mające zastąpić inne kable pomiędzy telewizorem a systemem audio (odbiornikiem AV lub ukadem głośnikowym).

## Zawartość menu ustawień

Zawartość menu akumulatora
<b>Ustaw preferencje trybu zasilania. Dostępne są opcje Normal (normalny), Eco (ekonomiczny) i ECO Plus.</b> Jeśli zasilacz jest podłączony, telewizor działa tak, jakiego działa w trybie normalnym bez żadnych ograniczeń. <b>Naciśnij OK, aby wyregulować zakresy intensywności światła na ekranie.</b>
<b>Telewizor będzie działał bez żadnych ograniczeń.</b>
<b>Eko Plus - Poziom podświetlenia zostanie ustalony na 12 (72lumen).</b>

Zawartość menu urządzeń
<b>Audio Link</b> Naciśnij OK, aby otworzyć menu Audio Link. Na tym ekranie możesz wybrać i podłączyć nowego telewizora bezprzewodowym igrzecznikiem kontrolu zdalnego.
<b>Input Device</b> Naciśnij OK, aby otworzyć menu Input Device. Na tym ekranie, możesz wybrać i podłączyć do swojego telewizora bezprzewodowy klawiaturę i mysz. Uwaga: Telewizor może nie reagować ze wstępnie montowaną klawiaturą i myszą dostosowaną na rynek. Aby uzyskać więcej informacji, skontaktuj się z lokalnym sprzedawcą lub punktem sprawdzianym, w którym zakupiono telewizor.
<b>Wirtualny pilot</b> Wybierz lub wybierz funkcję wirtualnego pilota. Funkcja ta pozwala na wprowadzenie się pilakiem przełączanym na Twoim smartfonie lub tablecie PC. Jeśli pośladasz kompatybilny smartfon lub tablet i zainstalowane odpowiednie oprogramowanie, możesz z pojemnością i łatwością zdefiniować swoje TV. Wyszukaj informacje, z których pochodzi Twoje urządzenie do wprowadzenia do aplikacji.
<b>Współdzielenie Audio i Wideo</b> Jeśli TV nie odbiera zadanych sygnałów (np.: z anteny lub źródła HDMI) przez 3 minuty, przejdzie się on na tryb godzownicy. Możesz włączyć lub wyłączyć tę funkcję odpowiednio ustawiając te opcje.
<b>CEC</b> Ustawienie to pozwala na całkowite włączenie lub wyłączenie funkcji CEC. Naciśnij przycisk sterujące kierunkowe w lewo lub w prawo, aby włączyć lub wyłączyć tę funkcję.
<b>Automatyczne włączanie CEC</b> Funkcja ta pozwala podłączeniu i zadaniu kompatybilnemu z HDMI-CEC, na automatyczne włączanie TV w przelądu na siedem wiejskich zdrojów. Naciśnij przycisk sterujący w lewo lub w prawo, aby włączyć lub wyłączyć tę funkcję.

Zawartość menu obrazu
<b>Tryb</b> Tryb obrazu może zostać dopasowany do indywidualnych upodobań. Tryb obrazu może zostać ustalony wg jednej z tych opcji: Kino, Gry (opcja), Sport, Dynamiczny i Naturalny.
<b>Kontrast</b> Dopasowanie wartości jasności i ciemności obrazu.
<b>Jaskrawość</b> Ustawia wartość ostrości dla obiektów wykazujących na ekranie.
<b>Ostrość</b> Ustawia wartość ostrości dla obiektów wykazujących na ekranie.
<b>Kolor</b> Dla ustawiania oszczerstwa energii na osobiste, minimum, średnie, maksymalne, auto, ekran, włączenie lub wyłączenie.
<b>Oszczędzanie energii</b> Dla ustawiania kontroli poziomu podświetlenia. Funkcja podświetlenia będzie włączona, jeśli oszczędzanie energii jest ustawione na opcje inną niż osobista.
<b>Podświetlenie</b> Ustawiający kontroluje poziom podświetlenia. Funkcja podświetlenia będzie włączona, jeśli oszczędzanie energii jest ustawione na opcje inną niż osobista.
<b>Zoom Obrazu</b> Ustawiający formal rozmiaru obrazu.

<b>Przesunięcie obrazu</b> Pojawia się, gdy źródło wojska jest ustawione na VGA/PC. Auto. Jesli obraz nie jest wywołany w trybie VGA, użyj opcji, aby automatycznie dopasować położenie obrazu. Naciśnij OK, aby rozpoczęć automatyczną regulację.
<b>Pozycja pozornia</b> Ten element przesuwa obraz poziomo w prawą lub lewą stronę na ekranie.
<b>Pozycja pionowa</b> Ten element przesuwa obraz pionowo w górną lub w dół na ekranie.
<b>Zegar sterujący pąmkami</b> Zegar sterujący pąmkami, które pojawiają się jako pąmki na ekranie przy intensywnym wyświetlaniu punktów np. na arkuszu kalkulacyjnym lub w parelogramach lub lekko na ekranie.
<b>Faza</b> Zależność od częstotliwości komputera (Ip.) obraz na ekranie może być zatrzymany lub zaszuflowany. Możesz użyć tej opcji, aby uszkodzić czystego obrazu metodą prób i błędów.
<b>Zawansowana ustawiania</b>
<b>Kontrast dynamiczny</b> Wartość kontrastu dynamicznego może zostać zmieniona zgodnie z upodobaniami.
<b>Temperatura koloru</b> Ustawianie pożądaną temperaturę koloru. Dostępne są opcje zimny, normalny, ciepły i osiąskie.
<b>Punkt Bieli</b> Ustawianie do bezpiecznego "ciepłego" lub "zimnego" koloru, naciskając przyciski po lewo lub po prawo.
<b>Blue Stretch</b> Funkcja poprawy kolon belli. Kiedy powoduje, że biały kolor staje się chłodniejszy w celu uzyskania jasniejszego obrazu. Ustaw jako Włączona, aby włączyć.
<b>Micro Dimming</b> Dostępne są opcje Niska, Średnia, Wyższa. Wyłączone. Podczas gdy funkcja Micro Dimming jest aktywna, poprawa ona kontrast miejscowy dla każdej zdefiniowanej strefy.
<b>Redukcja szumów</b> Dostępne są opcje Niska, Średnia, Wyższa. Jeżeli sygnał jest słaby i występują problemy z jakością obrazu, ustawienia Wyłączone, aby zredukować taki zakłócenia.
<b>Tryb Film</b> Filmy są nagrywane z różnych źródeł i ramki wyświetlanych na sekundę. Kiedy jest ustawiona na film, w przypadku normalnego programu telewizyjnego. Włącz tę funkcję w trakcie oglądania filmu, aby lepiej widzieć sceny z szybkim ruchem.
<b>Odcięcie skóry</b> Poziom kontrastu może być zmieniony pomiędzy -5 a 5.
<b>Zmiana koloru</b> Ustawianie pożądanego tonu koloru.
<b>Tuner kolorów</b> Otwiera ustawienia tunera kolory. Ustaw Tuner kolory jako włączony, aby rejtować dostosować wartości Barwy, Kolory i Jasności.
<b>Gamut Mapping</b> Możesz użyć tej opcji aby ustawić zakres kontrastów wyświetlanych na ekranie telewizora. Po ustawieniu tego włączonego, kolory są ustanawiane zgodnie z określonym. Po ustawieniu tego wyłączonego, mamy małe możliwości. Kolory ustawione na ekranie mogą być nieco zmienione w zależności od ustawień modelu urządzenia / jego funkcji.
<b>HDMI Purity Zakres</b> Podczas ustawiania ze źródła HDMI, ustawienia na bieżącą wdrożona. Można użyć tej funkcji, aby połączyć całość w obrazie.
<b>Resetuj</b> Resetuje ustawienia obrazu do ustawień fabrycznych. (za wyjątkiem trybu grey).

W trybie VGA (PC), niektóre opcje w menu Obrazu będą niedostępne. Zmiany tego trybu VGA zostaną dokonane do momentu obrotu w trybie PC.

Zawartość menu dźwięku	
Dolby Audio	Desygna będa opcje <b>Smart Film</b> , <b>Muzyczka</b> , <b>Wiadomości</b> i <b>Wyłączone</b> . Ustaw jako <b>Wyłączone</b> , aby wyłączyć.
Uwaga:	Należy pamiętać o menu <b>Dźwięk</b> w trybie <b>redukcyjny</b> , jeśli ustawiono tryb <b>innych</b> niż <b>Wyłączony</b> .
Dźwięk przestrzenny	Dźwięk przestrzenny może być <b>Wyłączony</b> lub <b>Wyłączony</b> .
Audio Link	Naciśnij <b>OK</b> aby otworzyć menu <b>Audio Link</b> . Na tym ekranie, możesz wybrać: <b>podłączyć do swojego telewizora bezprzewodowego</b> .
Wyjście dźwięku	Ustalnia preferencje wyjścia dźwięku. Dostępne będą opcje <b>TV</b> , <b>SIFID</b> , <b>HDMI ARC</b> , <b>Tylko słuchawki</b> i <b>Wyłączony</b> . Nie będzie żądania wyjścia dźwięku poza wybieraną opcją gniazdkiem słuchawkowym.
	Podlegając zewnętrznej wzmiance, że TV, korzystając z wyjścia słuchawkowego, może wybierać le opcję <b>Wyjście</b> . Jeżeli podłącisz słuchawki do TV, ustawów te opcję jako <b>Tylko słuchawki</b> . Przed użyciem słuchawek, upewnij się, że ten element jest ustawiony na <b>Wyjście</b> . Jeśli jest ustawiony na <b>Wyjście</b> , sygnał wydobyty w gniazdku słuchawkowym będzie ustawiony na maksimum, co może uszkodzić słuch.
	Jesli wybrana jest opcja <b>HDMI ARC</b> , funkcja <b>CEC</b> zostanie włączona.
	Uwaga: W zależności od systemu/opcji, niektóre opcje w menu <b>Dźwięk</b> będą nieaktywne.
Ustalnia określony poziom głośności dla programów.	Jesli pozytywna menu <b>głośność audio</b> jest ustawiona na opcję <b>inna niż Wyłączona</b> , opcje ustawień <b>AVL</b> ulegają zmianie. Dostępne będą opcje <b>Normal</b> , <b>Noc</b> , <b>Normalna Wyłączona</b> . W trybie automatycznego telewizor przełącz się automatycznie w tryb <b>normalny</b> lub <b>nočny</b> zgodnie z bieżącą informacją o godzinie. Jeśli nikt nie informuje o godzinie, ta opcja będzie działać jako <b>Normalna</b> . Gdy telewizor przelecię się do trybu <b>nočnego</b> po raz pierwszy po ustawieniu le opcji <b>Automatyczna</b> , na ekranie pojawi się pasek informacyjny.
	Należy pamiętać, że w powodzeniu do trybu <b>normalnego</b> i <b>nočnego</b> zapewnia bardziej agresywną kontrolę dynamicznej kompresji, która jest odpowiednia dla odtwarzania średnich.
Zawieszane ustawienia	<b>AVL (Funkcja automatycznego ograniczania głośności)</b>
Korektor	Wybiera tryb equalizera. Ustawienia indywidualne są dostępne tylko w trybie <b>Wyjście cyfrowe</b> .
Tryb dźwięku	Wybiera tryb audio wyjścia cyfrowego.
Wyjście cyfrowe	Ustalnia głębokość słuchawek. Ta opcja nie będzie dostępna, jeśli opcja <b>Wyjście dźwięku</b> jest ustawione jako <b>Wyjście</b> .
Sluchawki	Przed użyciem słuchawek proszę się upewnić, że dźwiek w słuchawkach jest ustawiony na niskim poziomie w celu uniknięcia uszkodzenia słuchu.
Rozsztuk.	Przezrocz niektórych ustawienia dźwięku do ustawień fabrycznych.
Zawartość menu sieci	
Typ sieci	Wyłącz połączenie sieciowe lub zmień typ połączenia.
Typ sieci bezprzewodowe	Rozwiązuje wyzwanie sieci bezprzewodowej. Ta opcja będzie dostępna tylko wtedy, gdy ustawiona. Typ sieci <b>do Urządzenia bezprzewodowe</b> .
Rozłącz	Aby rozłączyć się z siecią bezprzewodową (jeśli by wcześniej zalogowano), pojawia się opcja <b>Wyłączenie</b> . Ta opcja nie będzie dostępna, jeśli nie masz połączenia z siecią bezprzewodową. Aby uzyskać więcej informacji, patrz: <b>Połączenie</b> .
Naciśnij przycisk WPS na routera Wi-Fi.	Jesli Twoj modem/router ma WPS, możesz bezpośrednio połączyć się z nim za pomocą tej opcji. Podłączcie le opcję <b>naciśnij OK</b> idz do modem/routera, a następnie naciśnij jego przycisk. WPS, aby dokonać połączenia. Ta opcja będzie dostępna tylko wtedy, gdy ustawiony <b>Typ sieci</b> to <b>Urządzenie bezprzewodowe</b> .
Test przedrostki Internetem	Rozpoczyna test przedrostki, aby sprawdzić przepustowość połączenia. Po zakończeniu, wyniki zostaną wyświetlone na ekranie.
Zawieszane ustawienia	Zmien konfigurację IP, DNS swojego telewizora.
Tryb czuwania z dostępnym do sieci	Wyłącza lub włącza le funkcję, ustawiając ją jako <b>Włączona</b> lub <b>Wyłączona</b> .
	Uwaga: Szczegółowe informacje na temat opcji <b>reguła menu zmodyfikuję w czasie Łączności</b> .
Zawartość menu instalacji	
Automatyczne Skanowanie Kanałów	Wyszukuje kanały połączane ze stacjami. <b>Antena cyfrowa</b> : Wyszukuje kanały sieciowe obierane przez kabla. <b>Satellite</b> : Wyszukuje kanały sieciowe obierane przez antenę satelitarną.
Ręczne Skanowanie Kanałów	Funkcja ta może być użyta wyłącznie dla przekazu bezpośredniego.
Wyszukiwanie kanałów sieciowych	Wyszukuje kanały połączane ze stacjami. <b>Antena cyfrowa</b> : Wyszukuje kanały sieciowe obierane przez antenę. <b>Telewizja kablowa cyfrowa</b> : Wyszukuje kanały sieciowe obierane przez kabla. <b>Satellite</b> : Wyszukuje kanały sieciowe obierane przez antenę satelitarną.
Przeczytanie dostrajanie analogowe	Funkcja może być używana do dostrajania kanałów analogowych. Ta funkcja nie jest dostępna, jeśli nie zapisano żadnych kanałów analogowych. I jeśli aktualnie oglądalny kanał nie jest kanałem analogowym.
Ustawienia satelitarne	Wyswietla menu ustawienia satelitarne na lej stronicie. <b>Lata satelitów</b> : Wyświetla dostępne satelity. <b>Dodaj</b> , <b>Usuń</b> lub <b>Zmien</b> : ustawienia satelity na lej stronie. <b>Instalacja anteny</b> : Wyszczersz zmienić ustawienia anteny satelitarnej/lub rozpoznać nowe wyszukiwanie satelitarne.
Ustawienia instancynie (opcja)	Wyswietla menu ustawień instalacji. <b>Tryb Wyszukiwanie w trybie oczekiwania (r)</b> : TV wyszukuje menu ustawień instalacji, aby obiektu, brakuje w trybie oczekiwania, wyszukiwanie zostanie wzniezione. <b>Dynamiczne aktualizacja kanału (z)</b> : Jesli ta opcja jest włączona, zmiany dotyczące programów, aktualizacji itd. aktualizują kanały, (czyli np. kanał, który klapnął, itp...). Została automatycznie zaktualizowane podczas oglądania. <b>r</b> : Dostępne zależy od modelu.
Czyść listę usług	Tego ustawienia używa się do usuwania zapisanych kanałów. To ustawienie jest widoczne tylko wtedy, gdy opcja <b>Kraj</b> ustawiona jest na Danie, Szwecję, Norwegię lub Finlandię.
Wybierz aktywną sieć	Ustawienie pozwala na uwydatnianie na liście kanałów (tyko audycji z konkretnego kraju). Funkcja ta jest dostępna w trybie wyboru kanału. <b>Normalna</b> .
Informacje o sygnale	Istnieje możliwość wykorzystania, na której momentu do modyfikowania informacji związanej z sygnałem, takim jak: poziom jąłkotu, nazwa sieci itp. dla dostępy ch częstotliwości.
Pierwsza instalacja	Ustawa wszystkie zachowane kanały / ustawienia, resetując TV do ustawień fabrycznych.

Zawartość menu systemowego	
Ustawienia dostępu	Wysyła opis dostępności telewizora.
Wyżoki kontrast	Zwiększa kontrast opcji menu i tekstu, aby były łatwiejsze do odczytania. Dostępne będą opcje: <b>tekst biały</b> , <b>tekst z lotów</b> , <b>wyłączony</b> .
Niedostosujący	Włącza funkcję specjalną przesyłającą przez nadawcę programy.
Opis Audio	Dla ogólnodostępnych program oczekiwanych przedmiotowych odtwarzania będzie służyć zapisówka z narracją. <b>Naciśnij OK</b> , aby wyświetlić wszystkie dostępne opcje menu <b>Opis Audio</b> . Funkcja ta jest dostępna tylko wtedy, jeśli obsługuje ją nadawca.
Polepszenie dialogu	Ta funkcja zapewnia opcję przywracania użytkowi w celu poprawienia dialegu w oparciu o Ustaw. Zgodnie z waszym preferencjami. Ustaw. Średnie i Wysokie.
Lista dialogowa	Dominiuje preferencje list, doliczonych są wybierane dla pomocą tel. opcji ustawień. Aby nadać preferencje listy dialogowej, wybierz tel. normaty, te opcje należy ustawić na <b>Włącz one</b> .
Wysoka jakość	Ta opcja może nie być dostępna na wersji telewizora i jest widoczna i tylko wtedy, gdy zdecido jest ustawione na TV.
Wysoka jakość	Umożliwia wybór kombinacji przykrywki celu połąkaczem ekranu. Domaga się jedynie opcji <b>Włączone</b> lub <b>Wyłączone</b> , aby włączyć.
Powiększenie	Opcja powiększenia zostanie włączona po długim naciśnięciu przycisku numeracyjnego 5. Powiększa lewą i górną część ekranu podczas oglądania programów numerycznych 2, 4, 6, 8 i spowoduje przesunięcie powiększonego obrazu w góre, w lewo, w prawo i w dół.
Minimapa	Minimapa jest domyślnie włączona i wyłącza się za pomocą klawiszów: <b>wyswietlanym minima</b> , <b>przyciskiem powiększania</b> . Dzieje się opcji możesz zapobiec: wyswietlanym minima, <b>przyciskiem powiększania</b> .
Dźwięk kliknięcia	Ta opcja włącza dźwięk kliknięcia klawisza w menu telewizora. Ustaw jako <b>Włączona</b> , aby włączyć.
Podświetl programy za pomocą	Jesli ta opcja jest włączona, a dowolne zdarzenie elektronicznego przewodnika po programach ma usłyszeć dostęp do napisów, zostaną wywołane innym kolorem.
[N] Napisy	Jesli ta opcja jest włączona, a dowolne zdarzenie elektronicznego przewodnika po programach ma usłyszeć dostęp do napisów, zostaną wywołane innym kolorem.
[LM] Język migowy	Jesli ta opcja jest włączona, a dowolne zdarzenie elektronicznego przewodnika po programach ma usłyszeć dostęp do językowego dostępu do językowego zostanie wywołane innym kolorem.
[OA] Opis Audio	Jesli ta opcja jest włączona, a dowolne zdarzenie elektronicznego przewodnika po programach ma usłyszeć dostęp do Opisu Audio zostaną wywołane innym kolorem.
Język	Możesz ustawić język i tryk, w zależności od nadawcy, kraju.
Dostęp warunkowy	Kontroluje metodę dostępu, wersunkowego, jeśli są dostępne.
Prywatność	Zarządzaj uprawnieniami dotyczącymi prywatności i inteligentnych aplikacji związanych z telewizją. <b>Naciśnij OK</b> , aby wejść do menu i ustawić godzinę i waszym preferencjami.
Ustawienia prywatności	Zarządzaj uprawnieniami dotyczącymi prywatności i inteligentnych aplikacji związanych z telewizją. <b>Naciśnij OK</b> , aby wejść do menu i ustawić godzinę i waszym preferencjami.
Pokaż wszystkie pliki cookie	Wyswietla wszystkie zapisane pliki cookie.
Usun wszystkie pliki cookie	Usuwa wszystkie zapisane pliki cookie.

Nie śledź	Za pomocą tej opcji możesz ustawić swoje preferencje dotyczące zachowania śledzenia dla usługi ibTV.
Kontrola Rodzicielska	Aby zmienić ustawienia kontroli rodzicielskiej wprowadź poprawne hasło. W tym menu możesz zaktualizować ustawienia Biokadu Menu. Biokad Menu. Możesz również zaktualizować dla Dzieci Biokad Klaudiusz oraz Ochronę Rodzicielską. Możesz również zaktualizować dla Dzieci Biokad Klaudiusz oraz Ochronę Rodzicielską. Korzystając z zidentyfikowanych kodów, możesz dostać się do internetu, na stronie <a href="http://www.ibtv.pl">www.ibtv.pl</a> przy Prawasat. Instaluj aplikację <i>Wyszukaj naszą aplikację na smart TV</i> i uruchom ją, aby dodać do Prawasat instalacji. Ustawiać datę i godzinę.
Data/Godzina	Edytuj źródła, włączonych lub wyłączonych pojęcia źródła.
Żródła	Jeśli Twój TV obsługuje tę funkcję możesz wyświetlić swój numer ESN(1) i wybrać Netflix.
Netflix	(*) Numer ESN jest unikalnym numerem ID Netflix, wygenerowanym specjalnie do identyfikacji Twojego telewizora.
Samba ACR	Telewizja interaktywna Samba obiektuje rekomendacje i inne aplikacje gromiące domowe dotyczące korzystania z określonych treści na ekranie, aby zwiększyć komfort oglądania. Korzystając z tej opcji, można uzyskać dostęp do menu ustawień Samba interaktywnej TV, zapoznać się z wartościami korzystając z usług Samba TV. Polityka prywatności i zarządzanie preferencjami relاتywnie do tego. Aby uzyskać dostęp do ustawień opartych na HTML, wymagane jest połączenie z Internetem. Można włączyć telewizor interaktywny w dowolnym momencie za pomocą menu <b>Ustawienia &gt; System &gt; Prywatność &gt; Ustawienia prywatności</b> , zaznaczając lub odznaczając pole wyboru określonego elementu. Ta opcja może nie być dostępna w zależności od kraju wybranego podczas procesu pierwszej instalacji, modelu telewizora i jego funkcji.
Ustawienia urządzenia	Ustawienie to pozwala na całkowite włączenie lub wyłączenie funkcji CEC. Naciśnij przycisk w lewo lub w prawo, aby włączyć lub wyłączyć tę funkcję.
CEC	Funkcja ta pozwala podłączeniu urządzenia kompatybilnemu z HDMI-CEC na automatyczne włączanie TV, przełączanie na swoje wejście zródła. Naciśnij przycisk w lewo lub w prawo, aby włączyć lub wyłączyć tę funkcję.
Automatyczne włączanie CEC	Naciśnij OK, aby obniżyć menu Input Device. Na tym ekranie, możesz wybrać i podzielić Ustaw. Receptor mode na tryb żądania za każdym razem przewodów klawiatury i myszy. Aby uzyskać więcej informacji, skorzystaj z beli informacji, zamieszczonych na tym ekranie.
Input Device	Jesli ty nie odbierasz żadnego sygnału (np.: z anteny lub z źródła HDMI) przez 3 minut, przełącz się on w tryb spoczynku. Możesz włączyć lub wyłączyć tę funkcję, odpowiednio ustawiając jej opcję.
Timer braku sygnału	Opóźnienie uchylania procesu konfiguracji tej funkcji. Jeśli konfiguracja została wcześniej zakończona, dostępne będą opcje <b>Język Alexa w trybie gotowości</b> , <b>Głośność Alexa</b> , <b>Wbudowana Alexa</b> . Ustawiająca preferencje językowe Alexa.
Atrybut głosowy	Język Alexa
Wbudowana Alexa	Włącz lub wyłącz tryb funkcji Alexa w trybie gotowości. Gdy włączona, Alexa będzie dostępna, gdy telewizor będzie znajdował się w trybie gotowości.
Alexa w trybie gotowości	Ustawia język "Wybrane", aby wyłączyć te funkcje, lub wybierz jeden z określonych tryków.
Głośność Alexa	Ustawia poziom głośności dla alarmów Alexa.
alarmu Alexa	Ustawia poziom głośności dla alarmów Alexa.

Informacje o poziomie klasyfikacji treści programów i  
jeliś ten poziom jest wykładowy, unienożnia dostęp  
do audycji.

## Działanie ogólnie TV

### Korzystanie z listy kanałów

**Wyloguj** Możesz użyć tej opcji w celu wylogowania się. Jeśli się wylogujesz, wbudowana funkcja **Aleksa Ready** zostanie wyczyszczona.  
Recepcja uruchamia proces konfiguracji i funkcji. Jeśli konfiguracja została wcześniej zakończona, opisja **Wyloguj** będzie dostępna. Przeczytaj, część **Aleksa Ready**, aby uzyskać więcej informacji.

**Wyloguj** Możesz użyć tej opcji w celu wylogowania się. Jeśli się wylogujesz, funkcja **Works With Alexa** zostanie wyczyszczona.

**Wyloguj** Urichamia proces konfiguracji, aby telewizor mógł współpracować z urządzeniami z Asystentem Google. Podziel się startem naciśnij **OK**, jeśli konfiguracja została wcześniej zakończona, opisja **Wyloguj** będzie dostępna. Jeśli się wylogujesz, funkcja **Asystent Google** zostanie wyczyszczona. Przeczytaj, część **Asystent Google**, aby uzyskać więcej informacji.

**Wyloguj** Wyświetla inną opcję ustawień telewizora.

**Wyciąg** Zmienia limit dla czasu wyświetlanego menu.

**Limit Czasu** Dioda LED trybu gotowości i menu **Kanały**.

**Aktualizacja programowania** Dioda LED trybu gotowości i menu **Kanały**.

**Wersja Aplikacji** Zapewnia najnowsze oprogramowanie fabryczne telewizora. Naciśnij **OK**, aby wyświetlić menu.

**Automatyczne włączanie** Wyświetla aktualną wersję oprogramowania.

**Tryb Napisów** Ustawia zadanie, gotując o klocku TV, aby automatycznie włączać w trybie oznakowania. Ta funkcja może ustawić w zakresie od 1 do 10 godzin co 1 godzinę. Można ją wyłączyć, opisując reakcję (tak) albo (nie).

**Klucz Biss** Opcja ta jest używana do wykonywania kodów napisowych wyświetlanych na ekranie (napisy DVB, napisy telewizyjne), jeśli chce odczekać pełnej obrazu przed użyciem. Wartości domyślne to 10 sekund.

**Tryb Sklepu** Wykonuje tryb w pełni demonstracyjno-modemu telewizora. Podczas, gdy włączony jest tryb sklepu, niektóre funkcje w menu TV nie będą mogły być ustawione.

**Współdziedzienie Audio i Wideo** Funkcja ta pozwala na współdziedzienie się plikami zreczynowywanymi na twom smartfonie lub tablecie PC. Jeśli posiadasz kompatybilny smartfon lub tablet z instalowaną aplikacją Open Source, możesz współdziedzić/wyświetlić załączoną do smartfona.

**Tryb uruchamiania** Włączenie lub wyłączenie preferencji trybu uruchamiania. Dostępne są opcje **Osartni stan i tryb oczekiwania**.

**Wirtualny Pilot OSS** Wyświetla informacje o licencji. Oprogramowanie Open Source. Korzystając z tej opcji, można ustawić preferencje dotyczące oprogramowania. Ustaliona w menu **Uruchamianie** jest opcja, która pozwala na korzystanie z menu.

**Priorytet aplikacji** Konfiguracja aplikacji, która pozwala na korzystanie z aplikacji. W przypadku gry CICAM jest wybór telewizora i trybów konkretnego aplikacji, priorytet zostanie przyznany wybranemu typowi aplikacji.

**Uwaga:** Należy pamiętać, aby nie dostosować zaleceń do modelu i trygu wybranego przy pierwotnej instalacji.

**Blokada internetu:** Kiedy blokada klawisz zostanie ustawiona na pomocnika pilota. W tym przypadku przykrości TV nie będzie działać.

**Blokada aplikacji:** Kiedy blokada klawisz zostanie włączona, aplikacja korzystająca z tego portu zostanie wyłączona.

**Blokada PIN:** Definiuje nowy numer PIN. Wyświetla PIN CICAM. Opcja ta będzie zaktualizowana jeśli moduł CI nie będzie odczytywać w gnieździe CI telewizora. Korzystając z tej opcji można zmienić PIN CI CAM.

**Uwaga:** Domyślny PIN może być ustawiony na 0000 lub 1234. Jeśli wybrany PIN jest wymagany w zakresie od wybranego kraju/państwa, należy go wprowadzić. W przypadku niektórych krajów może być konieczne wprowadzenie PIN razem z wprowadzeniem kodu PIN. W tym celu, wprowadź kod PIN zostane zaktualizowane po wprowadzeniu PIN razem z kodem PIN.

**Następnie:** Wyświetla opcje mogą być niedostępne, zależnie od modelu i trygu wybranego przy Pierwotnej instalacji.

**Elektroniczny przewodnik po programach:** Aby pomoć funkcji elektronicznego przewodnika po programach, telewizor można przyciągać do hamowania, wydzielając aktualne zainsertowane kanały na liście kanałów. Czy ta funkcja jest obsługiwana, czy nie, zależy od odnośnego transmisji. Aby uzyskać dostęp do przewodnika po programach, należy wybrać przycisk **Przewodnika** na pilotie. Mocno zatknąć kciukiem na przycisk **Przewodnika** w menu TV. Przewodnik po programach, aby ponownie kliknąć go, należy ponownie kliknąć przycisk **Przewodnika** w menu TV.

**Program godzinny** Wyświetla informację o godzinie rozpoczęcia i zakończenia programu. Program godzinny jest jednym z najważniejszych elementów telewizora. Aby przełączyć się między tymi układami, powinno się kliknąć przycisk **Przewodnika** w górnym części ekranu.

**Ustawienia systemu kontroli rodzinie** Włączenie lub wyłączenie wszystkich programów na kanalech, kierunkowych, aby ponownie kliknąć przycisk **Przewodnika** w menu TV.

**Ustawienia systemu kontroli rodzinie** Wybierz opcję filtrowania, aby zatrzymać kanały, które nie są dopuszczane do widzenia przez dzieci. W tym celu, wybierz opcję **Wybierz kanały** i zaznacz kanały, które nie są dopuszczane do widzenia przez dzieci.

**Ustawienia systemu kontroli rodzinie** Wybierz opcję **Wybierz kanały** i zaznacz kanały, które nie są dopuszczane do widzenia przez dzieci.

**Ustawienia systemu kontroli rodzinie** Wybierz opcję **Wybierz kanały** i zaznacz kanały, które nie są dopuszczane do widzenia przez dzieci.

**Ustawienia systemu kontroli rodzinie** Wybierz opcję **Wybierz kanały** i zaznacz kanały, które nie są dopuszczane do widzenia przez dzieci.

**Ustawienia systemu kontroli rodzinie** Wybierz opcję **Wybierz kanały** i zaznacz kanały, które nie są dopuszczane do widzenia przez dzieci.

**Ustawienia systemu kontroli rodzinie** Wybierz opcję **Wybierz kanały** i zaznacz kanały, które nie są dopuszczane do widzenia przez dzieci.

**Ustawienia systemu kontroli rodzinie** Wybierz opcję **Wybierz kanały** i zaznacz kanały, które nie są dopuszczane do widzenia przez dzieci.

**Ustawienia systemu kontroli rodzinie** Wybierz opcję **Wybierz kanały** i zaznacz kanały, które nie są dopuszczane do widzenia przez dzieci.

aby zobaczyć wszystkie dostępne opcje filtrowania.

Aby zmienić układ podświetli **Teraz/następny**, naciśnij **OK**. Możesz użyć opcji **Następny dżen/ Następny dżen**, aby wyświetlić programy z poprzedniego i następnego cyklu.

Aby zmienić układ **Ekska/Ekska**, naciśnij **OK**, aby uzyskać dostęp do ponizszych opcji:

**Po dżen/ dżen/ gatunek.** Wybierz jedną z dwóch opcji **Następny dżen/ gatunek.** Wybierając programę z poprzedniego cyklu, wybierasz kolejno kolejne programy.

**Po dżen/ dżen/ gatunek.** Wybierz jeden z dwóch programów z poprzedniego cyklu, aby zmienić kolejność kolejnych programów.

**Teraz/Następny program.** Wtedy wyświetla się kolejno kolejne programy z poprzedniego cyklu.

Wtedy opcja **wyszukiwanie na wybranym kanałku** zostanie podświetlona.

**Przeszukanie/ przewodnika:** Wybierz jedną z dwóch opcji **wyszukiwanie na wybranym kanałku** lub **wyszukiwanie po kryterium.**

Naciśnij przycisk **OK**, aby zacząć przeszukiwanie po kryterium. Wybierz jeden z dwóch programów z poprzedniego cyklu, aby zmienić kolejność kolejnych programów.

**Teraz/Następny program.** Wtedy opcja **wyszukiwanie na wybranym kanałku** zostanie podświetlona.

Aby zmienić układ podświetli **Teraz/następny**, naciśnij **OK**.

Aby zmienić układ podświetli **Ekska/Ekska**, naciśnij **OK**. Możesz użyć opcji **Następny dżen/ Następny dżen**, aby wyświetlić programy z poprzedniego i następnego cyklu.

Aby zmienić układ **Ekska/Ekska**, naciśnij **OK**, aby uzyskać dostęp do ponizszych opcji:

**Po dżen/ dżen/ gatunek.** Wybierz jedną z dwóch opcji **Następny dżen/ gatunek.** Wybierając programę z poprzedniego cyklu, wybierasz kolejno kolejne programy.

**Po dżen/ dżen/ gatunek.** Wybierz jeden z dwóch programów z poprzedniego cyklu, aby zmienić kolejność kolejnych programów.

**Teraz/Następny program.** Wtedy wyświetla się kolejno kolejne programy z poprzedniego cyklu.

Wtedy opcja **wyszukiwanie na wybranym kanałku** zostanie podświetlona.

**Wybierz informacji/ Wybierz informacji:** Wybierz jedną z dwóch opcji **wyszukiwanie na wybranym kanałku** lub **wyszukiwanie po kryterium.**

Naciśnij przycisk **OK**, aby przełączyć się na kolejny kanał.

**Wybierz kanał:** Używając lej opci, możesz przełączyć na wybrany kanał, aby go oglądać. Przewodnik po programach zostanie zamknąty.

**Wybierz informacji/ Wybierz informacji:** Wybierz jedną z dwóch opcji **wyszukiwanie na wybranym kanałku** lub **wyszukiwanie po kryterium.**

Naciśnij przycisk **OK**, aby przełączyć się na kolejny kanał.

**Wybierz informacji/ Wybierz informacji:** Wybierz jedną z dwóch opcji **wyszukiwanie na wybranym kanałku** lub **wyszukiwanie po kryterium.**

Naciśnij przycisk **OK**, aby przełączyć się na kolejny kanał.

**imerow w celu nagrania.** Jeśli program jest aktualnie nadawany, nagranie rozpoczęte się natychmiast. Aby anulować nagranie, naciśnij przycisk **OK**.

**Teraz/następny program:** Wybierz opcję **Teraz/następny program.** Wybierz jeden z dwóch programów z poprzedniego cyklu.

**Teraz/Następny program.** Wybierz jeden z dwóch programów z poprzedniego cyklu, aby zmienić kolejność kolejnych programów.

**Teraz/Następny program.** Wybierz jeden z dwóch programów z poprzedniego cyklu, aby zmienić kolejność kolejnych programów.

**Teraz/Następny program.** Wybierz jeden z dwóch programów z poprzedniego cyklu, aby zmienić kolejność kolejnych programów.

**Teraz/Następny program.** Wybierz jeden z dwóch programów z poprzedniego cyklu, aby zmienić kolejność kolejnych programów.

**Teraz/Następny program.** Wybierz jeden z dwóch programów z poprzedniego cyklu, aby zmienić kolejność kolejnych programów.

**Teraz/Następny program.** Wybierz jeden z dwóch programów z poprzedniego cyklu, aby zmienić kolejność kolejnych programów.

**Teraz/Następny program.** Wybierz jeden z dwóch programów z poprzedniego cyklu, aby zmienić kolejność kolejnych programów.

**Teraz/Następny program.** Wybierz jeden z dwóch programów z poprzedniego cyklu, aby zmienić kolejność kolejnych programów.

**Teraz/Następny program.** Wybierz jeden z dwóch programów z poprzedniego cyklu, aby zmienić kolejność kolejnych programów.

**Teraz/Następny program.** Wybierz jeden z dwóch programów z poprzedniego cyklu, aby zmienić kolejność kolejnych programów.

**Teraz/Następny program.** Wybierz jeden z dwóch programów z poprzedniego cyklu, aby zmienić kolejność kolejnych programów.

**Teraz/Następny program.** Wybierz jeden z dwóch programów z poprzedniego cyklu, aby zmienić kolejność kolejnych programów.

**Teraz/Następny program.** Wybierz jeden z dwóch programów z poprzedniego cyklu, aby zmienić kolejność kolejnych programów.

**Teraz/Następny program.** Wybierz jeden z dwóch programów z poprzedniego cyklu, aby zmienić kolejność kolejnych programów.

**Teraz/Następny program.** Wybierz jeden z dwóch programów z poprzedniego cyklu, aby zmienić kolejność kolejnych programów.

**Teraz/Następny program.** Wybierz jeden z dwóch programów z poprzedniego cyklu, aby zmienić kolejność kolejnych programów.

**Teraz/Następny program.** Wybierz jeden z dwóch programów z poprzedniego cyklu, aby zmienić kolejność kolejnych programów.

**Teraz/Następny program.** Wybierz jeden z dwóch programów z poprzedniego cyklu, aby zmienić kolejność kolejnych programów.

**Teraz/Następny program.** Wybierz jeden z dwóch programów z poprzedniego cyklu, aby zmienić kolejność kolejnych programów.

**Teraz/Następny program.** Wybierz jeden z dwóch programów z poprzedniego cyklu, aby zmienić kolejność kolejnych programów.

## Obrázek nie jest wyśrodkowany w źródle VGA

Aby telewizor automatycznie wprowadził obraz, przejdź do menu **Porządkuj OK** w menu **Obrázek**, podświetl **Autopozycjonowanie** i naciśnij przycisk **OK**. Zazębić, aby pozycja obrazu została zakończona. Aby ustawić pozycję obrazu ręcznie można użyć opcji **Porządkuj H V**. Wybierz zakładkę opcje użycia opcji kamerunkowych w lewo i w prawo na płacie, aby ustawić.

## Rozszerszony program: wskazówki

**Tv nie chce się włączyć**

Sprawdź, czy główny wyłącznik zasilania z tytułu telewizora jest włączony. Upewnij się, że zasilacz jest podłączony lub że akumulator jest wystarczająco naładowany. Naciśnij na plicę przycisk **trybu gotowości**.

**Słaba jakość obrazu**

Sprawdź, czy poprawnie dostrojono telewizor. Sprawdź, czy sygnał powodujący zakłócenia obrazu. Sprawdź, podłączenie anteny.

Sprawdź, czy wprowadzono właściwą częstotliwość kanalu, jeśli dostaje się komunikat.

**Brek obrazu**

Telewizor odbiiera żadnego sygnału. Upewnij się, że zostaną wybrane prawidłowe źródła.

Czy antena jest podłączona prawidłowo?

Czy kabiel anteny jest uszkodzony?

Czy do połączenia anteny użyto odpowiednich wtyczek?

W przypadku wątpliwości proszę skonsultować się z sprzedawcą.

**Brek dźwięku**

Sprawdź, czy dźwięk nie jest wyłączony. Aby to sprawdzić, naciśnij przycisk **wyciszania** lub zwiększyć poziom głośności.

Dźwięk może dochodzić tylko z jednego głośnika. Sprawdź ustawienia balansu w menu dźwięku.

**Pilot nie działa**

Być może wczytały się baterie. Wymień baterie. Baterie mogą być nieprawidłowo włożone. Patrz części „Wkładanie baterii do pilotu”.

**Brek sygnału na źródle sygnału wejściowego**

Jest możliwie, że żadne urządzenie nie jest podłączone.

Sprawdź kable AV i połączenia z urządzeniem.

Znaleziono 1 pomyślne pobrań, zastrzelając się przy następnym wpłaszczeniu.

**Uwaga: Uwiernej się, że zasilacz jest połączony, aby zapobiec uszkodzeniu telewizora.** Wykonaj następujące czynności:

Podświetl zakładkę **Ekska/Ekska**, naciśnij **OK**, aby uzyskać dostęp do ponizszych opcji:

**Po dżen/ dżen/ gatunek.** Wybierz jedną z dwóch opcji **Następny dżen/ gatunek.** Wybierając programę z poprzedniego cyklu, wybierasz kolejno kolejne programy.

**Po dżen/ dżen/ gatunek.** Wybierz jeden z dwóch programów z poprzedniego cyklu, aby zmienić kolejność kolejnych programów.

**Teraz/Następny program.** Wybierz jeden z dwóch programów z poprzedniego cyklu, aby zmienić kolejność kolejnych programów.

**Teraz/Następny program.** Wybierz jeden z dwóch programów z poprzedniego cyklu, aby zmienić kolejność kolejnych programów.

**Teraz/Następny program.** Wybierz jeden z dwóch programów z poprzedniego cyklu, aby zmienić kolejność kolejnych programów.

**Teraz/Następny program.** Wybierz jeden z dwóch programów z poprzedniego cyklu, aby zmienić kolejność kolejnych programów.

**Teraz/Następny program.** Wybierz jeden z dwóch programów z poprzedniego cyklu, aby zmienić kolejność kolejnych programów.

**Teraz/Następny program.** Wybierz jeden z dwóch programów z poprzedniego cyklu, aby zmienić kolejność kolejnych programów.

**Teraz/Następny program.** Wybierz jeden z dwóch programów z poprzedniego cyklu, aby zmienić kolejność kolejnych programów.

**Teraz/Następny program.** Wybierz jeden z dwóch programów z poprzedniego cyklu, aby zmienić kolejność kolejnych programów.

**Teraz/Następny program.** Wybierz jeden z dwóch programów z poprzedniego cyklu, aby zmienić kolejność kolejnych programów.

**Teraz/Następny program.** Wybierz jeden z dwóch programów z poprzedniego cyklu, aby zmienić kolejność kolejnych programów.

**Teraz/Następny program.** Wybierz jeden z dwóch programów z poprzedniego cyklu, aby zmienić kolejność kolejnych programów.

**Teraz/Następny program.** Wybierz jeden z dwóch programów z poprzedniego cyklu, aby zmienić kolejność kolejnych programów.

**Teraz/Następny program.** Wybierz jeden z dwóch programów z poprzedniego cyklu, aby zmienić kolejność kolejnych programów.

**Teraz/Następny program.** Wybierz jeden z dwóch programów z poprzedniego cyklu, aby zmienić kolejność kolejnych programów.

**Teraz/Następny program.** Wybierz jeden z dwóch programów z poprzedniego cyklu, aby zmienić kolejność kolejnych programów.

**Teraz/Następny program.** Wybierz jeden z dwóch programów z poprzedniego cyklu, aby zmienić kolejność kolejnych programów.

**Teraz/Następny program.** Wybierz jeden z dwóch programów z poprzedniego cyklu, aby zmienić kolejność kolejnych programów.

**Teraz/Następny program.** Wybierz jeden z dwóch programów z poprzedniego cyklu, aby zmienić kolejność kolejnych programów.

**Teraz/Następny program.** Wybierz jeden z dwóch programów z poprzedniego cyklu, aby zmienić kolejność kolejnych programów.

**Teraz/Następny program.** Wybierz jeden z dwóch programów z poprzedniego cyklu, aby zmienić kolejność kolejnych programów.

## Teraz/następny program: aktualizacja o 3 nad ranem

Telewizor wykrywa nowe programowane odcinki z 3 nad ranem. Jeśli **Automatyczne wyszukiwanie** lub **inteligentne wyszukiwanie** są włączone, telewizor odbiera sygnał z anteny lub internetu. Jeśli nowe oprogramowanie zostanie

**Trybowe tryby wyświetlania dla wojtelni RC**

Poniższa tabela przedstawia niektóre podstawowe tryby obrazu. Telewizor może nie obsługiwać wszystkich rozdzielczości.

Kompatybilność sygnałów AV i HDMI			
Źródło	Odbieranie sygnały	Dostępne	
	PAL	O	
	SECAM	O	
Tytuł AV	NTSC-C,3,56	O	
	480i, 480p	60Hz	
Indeks	Rozdzielczość:	Częstotliwość:	
1	640x480	60Hz	
2	640x480	75Hz	
3	800x600	56Hz	
4	800x600	60Hz	
5	800x600	72Hz	
6	800x600	75Hz	
7	1024x768	60Hz	
8	1024x768	70Hz	
9	1024x768	75Hz	
10	1152x864	75Hz	
11	1280x800	60Hz	
12	1360x768	60Hz	
13	1280x860	60Hz	
14	1280x1024	60Hz	
15	1280x1024	75Hz	
16	1400x1050	60Hz	
17	1440x900	60Hz	
18	1440x900	75Hz	
19	1920x1080	60Hz	

(X) Niedostępne, O: Dostępne)

W niektórych przypadkach sygnał może nie być wyświetlany prawidłowo na ekranie. Problem może być spowodowany niską kompatybilnością urządzenia zdrojowego (DVI, dekoder TV, odtwarzacz ip.) W razie wystąpienia takich problemów proszę skontaktować się z szelawicą oraz producentem sprzętu.

**Obsługiwane formaty plików dla trybu USB**

Formaty plików wideo			
Rozszerzenie	Kodak video	MPEG 1 / 2 H.264 VC1	Max. rozdzielcość / ilość klatek na sekundę i szybkość transmisji
.mpg, .mpeg, .dat, .vob			
.ts, .tp, .mts			
.avi		MPEG1/2, MPEG4, H.264, MJPEG	
.mp4, .m4a, .m4v, .mov, .qt		MPEG1/2, H.265, MP4G4, H.264	
.3gp, .3gp2, .3gpp		MPEG1/2, H.265, MP4G4, H.264	
.m4v		MPEG1/2, MP4G4, H.264	
.flv		Sorenson Sp., MP4G4, H.264	
.asf, .wmv		MPEG4, WMV3, VC1	
.webm		VPA, VP8	
		HEVC/H.265	
Formaty plików obrazów			
Rozszerzenie	Specyfikacje	Rozdzielcość (szersze x wyższa)	
	Linia bazowa	8192 x 8192	
.jpg, .jpeg	Progressywne	3000 x 3000	
.bmp	RGB / 16/8/16/24/32 bit	8192 x 8192	
	RLE / 8/16	Skala szarości: 24/32 bitów na piksel	
.png	Format z zapisaniem	8192 x 8192	
	Progressywny		
Formaty plików audio			
Rozszerzenie	Format		
.mp3	mp3		
.ac3	ac3		
.aac	AC		
.wma	WMA		
.amr	AMR-NB, AMR-WB		
.wav	MPEG Ln., AAC, PCM		

## Formaty plików napisów

Napisy, ze zn.	Specyfikacja
ssa	Sub Station Alpha
ass	Advanced Sub Station Alpha
srt	Subripper
sub	Micro DVD / SubViewer
sub + dcs	VOBSub
.txt	Micro DVD / TMPPlayer / MPL2
.mpl2	MPL2
.smi	Sami
.jss	JACOSUB
.lrc	LRC
.ttml	TTML
.xml / sub	DVOSUBTITLE
.m3u	-

Napisy/www/główne	Specyfikacja
.mkv	VOBSub
.mkv	ASS / SSA / TEXT
.dat, .mpg, .mpeg, .vob	Napisy DVD
.mp4	Napisy DVD, TEXT

## Obsługiwane rozdzielcości HDMI

Podłączając urządzenie do telewizora używaj kabli/przełotów typu DVI do HDMI (do kupienia osobno), możesz sprawdzić urządzenie rozdzielcość (poniżej).

	56Hz	60Hz	66Hz	72Hz	70Hz	72Hz	75Hz
640x400	x	x	x	x	x	x	x
640x800	x	x	x	x	x	x	x
800x600	x	x	x	x	x	x	x
832x624							
1024x768	x	x	x	x	x	x	x
1152x864	x	x	x	x	x	x	x
1152x970							
1280x768	x	x	x	x	x	x	x
1360x768	x	x	x	x	x	x	x
1280x800	x	x	x	x	x	x	x
1280x1024	x	x	x	x	x	x	x
1400x1050	x	x	x	x	x	x	x
1440x900	x	x	x	x	x	x	x
1600x1200	x	x	x	x	x	x	x
1680x1050	x	x	x	x	x	x	x
1920x1080	x	x	x	x	x	x	x

## Wybierz Urządzenie Przewodowe, jeśli korzystasz z kabla ethernetowego.

### Test prędkości internetu

Podziel się testem prędkości Internetu i nadaj ją przy czym kabel ethernetowego i po przewodowym na testu i wyswietli rezultaty.

### Zawansowane ustawiania

Podziel się zawansowanymi ustawieniami i naciśnij przyciski, aby zmienić ustawienia w Twoim telewizorze. Podziel się testem prędkości internetu i naciśnij przyciski, aby zmienić ustawienia w Twoim telewizorze. Wybierz jeden element z automatycznych na Manually. Możesz teraz wprowadzić wartości IP lub DNS. Wybierz jeden element z rozwijanego menu i wprowadź nowe wartości, używając przycisków numerycznych na plocecie. Po zakończeniu podziel się na pięćdziesiąt OK, aby zapisać ustawienia.

### Połączenie bezprzewodowe

Aby połączyć do sieci bezprzewodowej:



### 1. Łącze szerokopasmowe ISP

Router Wireless-N (IEEE 802.11a/b/g/n) z dwieście przesyłkami 2.4/5 GHz przeznaczonymi do zwierzęcych przesyłek. Są one copytymowane do głoszczących przesyłek odbioru HD, transferu pilota i szybkiego przesyłania HD, oraz gniazdka bezprzewodowego.

Częstotliwość kanału różni się w zależności od regionu.


Predkość transmisji różni się w zależności od odległości i ilości przesyłek pomiędzy produktami transmisji, konfiguracji produktów, stanu fal radiowych, ruchu na linii oraz produktów, których użycie może zostać również docelową lub rozszczepioną w zakresie od stanu fali radiowej do zakresu fali radiowej. W tym celu DECT lub jakichkolwiek innych urządzeń WLAN 11b. Standardowe wartości dla szybkości transmisji to teoretycznie maksymalne wartości

## Połączenie

### Połączenie przewodowe

- Aby połączyć do sieci przewodowej
- Musisz posiadać modem/router podłączony do aktywnego łączu szeregowego/lanowego.

- Podłącz swój modem/router do kabla ethernetowego. Z tyłu TV znajduje się port LAN.



### 1. Łącze szerokopasmowe ISP


#### 2. Kabel LAN (Ethernet)

#### 3. Wejście LAN / tyłu telewizora

Ustawienia kablowe można zmienić w części poświęconej sieci w menu ustawień.

- Istnieje możliwość podłączenia telewizora do swojej sieci LAN w zależności od konfiguracji Twojej sieci.

W takim przypadku, proszę użyć kabla ethernetu aby podłączyć swój telewizor bezpośrednio do gniazda sieciowego sieci.



### 1. Sieciowe gniazdo naciśnienie

#### 2. Wejście LAN / tyłu telewizora

### Konfigurowanie ustawień urządzenia przewodowego

#### Typ sieci

Typ sieci może być ustawiony jako urządzanie przewodowe, bezprzewodowe lub wyłączone, zgodnie z aktywnym połączeniem z telewizorem.

sięci bezprzewodowej. Nie są one rzeczywistymi szbkościami transmisií danych.

• Miejscie, gdzie przesyły testowe mają największe zaledwie odciążenia. Wybrane **OK**, aby kontynuować.

• Bezprzewodowa linówka TV obsługuje modem typu 802.11 a/b/g oraz n. Ta leca sie, bardzo żąwanym problemem z komunikacyjnym IEEE 802.11n w celu uniknięcia wszelkich problemów podczas oglądania wideo.

• Gdy w sieci znajdzieli się inne moderny z takim samym SSID, musisz zmienić SSID swojego moderny. W innym przypadku możesz napotkać problemy z połączeniem. Jeśli dosiadłeś jaz skorzystać z połączenia bezprzewodowego.

**Konfiguracja ustawień urządzenia bezprzewodowego**  
Otwórz menu Sieci i wybierz typ sieci jako urządzenie bezprzewodowe, aby rozpoczęć proces legowania.

**Nazwanie sieci i sieci bezprzewodowej i hasło**  
Nazwanie sieci wybraną przez siebie i hasło do sieci bezprzewodowej. Wyszukanie dostępnych sieci została wymienione. Podażcie zadanie 2 i listy i hasło i OK, aby je połączyć. Sieć i ukryty SSID nie może zostać wykryta przez inne urządzenia. Siedz chcesz połączyć się z siecią bezprzewodową, skorzystaj z funkcji identyfikatora SSID, przechwil istniejących w sieci bezprzewodowej, zaznacz opcję **Doda nowa sieć** i naciśnij OK. Wprowadź nazwę sieci i wybór typu zabezpieczenia, konając się z powiększącą się poleceniami.

**Uwaga:** Jeśli modem działa w trybie N, powinno się wybrać ustawienia trybu N.

• Oznacza to, że ustawiono zostało podstawowe. W celu odłączenia się od sieci, należy podać typ Sieci, a przyciskiem na lewo lub w prawo ustawić połączenie jako **Wyłączone**.

Jestli połączysz się z siecią bezprzewodową, opcja **Rozłóż** pojawia się w menu Sieci, a przycisk bezprzewodowej zostanie zapisany, dzięki czemu telewizor będzie automatycznie łączyć się z samej sieci przy każdym przełączeniu na połączenie bezprzewodowe. Aby rozłączyć się z siecią bezprzewodową, zapisz profil, podawszy **Rozłąż** i naciśnij OK. Jęs i router, posta przycisk WPS, można bezpośrednio podłączyć do moderny/z routera bez konieczności ustawienia nowej hasła lub dodawania sieci. Zaznacz opcje **Naciśnij do przycisk WPS na routera wifi i naciśnij OK** i

należy ustawić opcję **Ty by gotowości z dostępu do sieci w menu Sieci jako Wyłączona Koniecznie aby zarządzić użyciem, z którego wiadomość sieci zostanie wysłana do telewizora, jak telewizor będzie podłączone do tej samej sieci. Funkcja tyo gotowości z dostępu do sieci jest obsługiwana tylko w urządzeniach z systemem Android inożyc byczywana tylko przez aplikację YouTube i Netflix.**

Aby korzystać z tej funkcji, telewizor i urządzenie z którym małączyc co najmniej raz, gdy telewizor jest włączony, jeśli telewizor jest włączony, należy ponownie nawiązać połączenie przy następnym uruchomieniu. W innym przypadku, funkcja ta będzie niedostępna. Należy pamiętać, gdy telewizor jest przełączany w tryb gotowości.

Wydajność niektórych urządzeń na rynku może się różnić zależnie od architektury oprogramowania. Aby korzystać z funkcji trybu gotowości z dostępu do sieci, należy upewnić się, że urządzenie posiada najnowszą wersję oprogramowania.

Jeśli chcesz, aby telewizor zużywał mniej energii w trybie gotowości, inożyc wyłączyć te funkcje, ustawiając opcję **Trybu gotowości z dostępu do sieci jako Wyłączone**.

**Wyświetlacz bezprzewodowy**  
Wyświetlacz bezprzewodowy jest standardem stymułowania obrazu dźwięku. Funkcja umożliwia korygowanie, korekcję i skonfigurowanie obrazu bezprzewodowego. Wybierz opcję **Trybu gotowości z dostępu do sieci jako Wyłączone**.

**Używanie w połączeniu z urządzeniami przenosionymi**  
Istnieją różne standardy umożliwiające współzadanie ekranów pomiędzy dwoma urządzeniami mobilnymi, a telewizorem. W celu wykrycia pilota graficznych, otwórz aplikację do współzadania pilota graficznych, otwierając pilota i dźwięku.

Następnie, naciśnij przycisk **Źródło** na pilote i przełącz na **wyswietlacz bezprzewodowy**.

Pojawi się ekran informujący o gotowości telewizora do nawiązania połączenia.

Obwóz aplikację do współzadania pilota na swoim urządzeniu mobilnym. Różne firmy różnie nazwują swoje aplikacje, sprawdź więc w instrukcji obsługi swojego urządzenia.

Zostanie wyświetlonego obrazu lub strumienianie swojego urządzenia na innym oznosi się zażegnaj. Wybierz urządzenie. Po wybraniu swojego telewizora i dokonaniem połączenia, otwórz Twoje urządzenie przenosionego zostanie wyświetlony na telewizorze.

**Tryb głównego z dostępu do sieci**  
Tryb głównego z dostępu do sieci standard, który umożliwia łączność z urządzeniem lub obciążeniem przez sieciowe. Komunikat jest wysyłany do urządzenia, aby pozwolić mu uruchomienie na użyciu połączonymi urządzeniami podczas tego samej sieci zdalnym uruchomieniem połączonymi urządzeniami takim jak smartfony, tablet, laptop, itp.

Twój telewizor jest zgodny ze standardami Wi-Fi i WLAN. Ta funkcja może być wyłączona podczas procesu (pienię) w statacji. Aby uruchomić ją funkcję jest

## Podłączanie innych urządzeń bezprzewodowych

Telewizor obsługuje również inną technologię bezprzewodową krótkiego zasięgu. Przed korzystaniem z tego typu urządzeń odłącz się z trybu prirowanej odległości w trygu bezprzewodowej.

• Przeląż telewizor w tryb prirowania

• Wyłącz wykrywanie urządzeń na TV

**Uwaga:** Informacje o tym, jak ustawić swoje urządzenie bezprzewodowe w tryb prirowanej odległości w trygu bezprzewodowej.

Do telewizora można bezpośrednio podłączyć urządzenie audio, klawiaturę i myszk. Odłącz telewizor, włącz wszelkie inne podłączone urządzenia audio, aby funkcja pobierania bezprzewodowego pozwalała na korzystanie z trybu prirowanego.

Aby korzystać z tej funkcji, telewizor i urządzenie z którym małączyc co najmniej raz, gdy telewizor jest włączony, jeśli telewizor jest włączony, należy ponownie nawiązać połączenie przy następnym uruchomieniu. W innym przypadku, funkcja ta będzie niedostępna. Należy pamiętać, gdy telewizor jest przełączany w tryb gotowości.

Wydajność niektórych urządzeń na rynku może się różnić zależnie od architektury oprogramowania. Aby korzystać z funkcji trybu gotowości z dostępu do sieci, należy upewnić się, że urządzenie posiada najnowszą wersję oprogramowania.

Jeśli chcesz, aby telewizor zużywał mniej energii w trybie gotowości, inożyc wyłączyć te funkcje, ustawiając opcję **Trybu gotowości z dostępu do sieci jako Wyłączone**.

**Użycie klawiatury i myszy**  
Zostanie wyświetlonego obrazu lub strumienianie nie zostało pomyślnie ustanowione. Jeśli połączenie nie zostało pomyślnie ustanowione, połącz się z trygiem bezprzewodowym, skonfiguruj się z klawiaturą i myszą, opój Input Device w menu i naciśnij przycisk OK, aby włączyć w tryb menu. Kiedy pojawi się menu, może być wykryty podłączony telewizor. Wykrycie telewizora, le sana, lecz nie bezprzewodowa i rozpoczęć ich wykrywanie. Postępuj z instrukcjami pokazującymi się na ekranie. Włącz wykrywanie urządzeń. Zostanie wyświetlona lista dołączonych urządzeń bezprzewodowych. Wybierz urządzenie, które chcesz połączyć z isty w trybie prirowanym OK, aby się połączyć. Jeśli wyświetli się informacja **Urządzenie połączone**, połączenie nie zostało pomyślnie ustanowione. Jeśli połączenie nie zostało pomyślnie ustanowione, połącz się z trygiem bezprzewodowym.

**Użycie klawiatury i myszy**  
Zostanie wyświetlonego obrazu lub strumienianie nie zostało pomyślnie ustanowione. Postępuj z instrukcjami pokazującymi się na ekranie. Ewentualne wykrywanie urządzeń nie zostało pomyślnie ustanowione. Zostanie wyświetlona lista dołączonych urządzeń bezprzewodowych. Wybierz urządzenie, które chcesz połączyć z isty w trybie prirowanym OK, aby się połączyć. Jeśli wyświetli się informacja **Urządzenie połączone**, połączenie nie zostało pomyślnie ustanowione. Jeśli połączenie nie zostało pomyślnie ustanowione, połącz się z trygiem bezprzewodowym.

**Użycie klawiatury i myszy**  
Zostanie wyświetlonego obrazu lub strumienianie nie zostało pomyślnie ustanowione. Postępuj z instrukcjami pokazującymi się na ekranie. Stanu telefonu telewizora, jak to opisano wcześniej, uzyskuj klawiaturę i myszę dołączony na rynku. Aby uzyskać więcej informacji, skonfiguruj się z klawiaturą i myszą, opój Input Device w menu i naciśnij przycisk OK, aby uaktualnić informacje. Wybierz urządzenie, które chcesz połączyć z isty w trybie prirowanym OK, aby się połączyć. Jeśli wyświetli się informacja **Urządzenie połączone**, połączenie nie zostało pomyślnie ustanowione. Jeśli połączenie nie zostało pomyślnie ustanowione, połącz się z trygiem bezprzewodowym.

**Użycie klawiatury i myszy**  
Zostanie wyświetlonego obrazu lub strumienianie nie zostało pomyślnie ustanowione. Postępuj z instrukcjami pokazującymi się na ekranie. Stanu telefonu telewizora, jak to opisano wcześniej, uzyskuj klawiaturę i myszę dołączony na rynku. Aby uzyskać więcej informacji, skonfiguruj się z klawiaturą i myszą, opój Input Device w menu i naciśnij przycisk OK, aby uaktualnić informacje. Wybierz urządzenie, które chcesz połączyć z isty w trybie prirowanym OK, aby się połączyć. Jeśli wyświetli się informacja **Urządzenie połączone**, połączenie nie zostało pomyślnie ustanowione. Jeśli połączenie nie zostało pomyślnie ustanowione, połącz się z trygiem bezprzewodowym.

**Użycie klawiatury i myszy**  
Zostanie wyświetlonego obrazu lub strumienianie nie zostało pomyślnie ustanowione. Postępuj z instrukcjami pokazującymi się na ekranie. Stanu telefonu telewizora, jak to opisano wcześniej, uzyskuj klawiaturę i myszę dołączony na rynku. Aby uzyskać więcej informacji, skonfiguruj się z klawiaturą i myszą, opój Input Device w menu i naciśnij przycisk OK, aby uaktualnić informacje. Wybierz urządzenie, które chcesz połączyć z isty w trybie prirowanym OK, aby się połączyć. Jeśli wyświetli się informacja **Urządzenie połączone**, połączenie nie zostało pomyślnie ustanowione. Jeśli połączenie nie zostało pomyślnie ustanowione, połącz się z trygiem bezprzewodowym.

**Użycie klawiatury i myszy**  
Zostanie wyświetlonego obrazu lub strumienianie nie zostało pomyślnie ustanowione. Postępuj z instrukcjami pokazującymi się na ekranie. Stanu telefonu telewizora, jak to opisano wcześniej, uzyskuj klawiaturę i myszę dołączony na rynku. Aby uzyskać więcej informacji, skonfiguruj się z klawiaturą i myszą, opój Input Device w menu i naciśnij przycisk OK, aby uaktualnić informacje. Wybierz urządzenie, które chcesz połączyć z isty w trybie prirowanym OK, aby się połączyć. Jeśli wyświetli się informacja **Urządzenie połączone**, połączenie nie zostało pomyślnie ustanowione. Jeśli połączenie nie zostało pomyślnie ustanowione, połącz się z trygiem bezprzewodowym.

**Użycie klawiatury i myszy**  
Zostanie wyświetlonego obrazu lub strumienianie nie zostało pomyślnie ustanowione. Postępuj z instrukcjami pokazującymi się na ekranie. Stanu telefonu telewizora, jak to opisano wcześniej, uzyskuj klawiaturę i myszę dołączony na rynku. Aby uzyskać więcej informacji, skonfiguruj się z klawiaturą i myszą, opój Input Device w menu i naciśnij przycisk OK, aby uaktualnić informacje. Wybierz urządzenie, które chcesz połączyć z isty w trybie prirowanym OK, aby się połączyć. Jeśli wyświetli się informacja **Urządzenie połączone**, połączenie nie zostało pomyślnie ustanowione. Jeśli połączenie nie zostało pomyślnie ustanowione, połącz się z trygiem bezprzewodowym.

**Użycie klawiatury i myszy**  
Zostanie wyświetlonego obrazu lub strumienianie nie zostało pomyślnie ustanowione. Postępuj z instrukcjami pokazującymi się na ekranie. Stanu telefonu telewizora, jak to opisano wcześniej, uzyskuj klawiaturę i myszę dołączony na rynku. Aby uzyskać więcej informacji, skonfiguruj się z klawiaturą i myszą, opój Input Device w menu i naciśnij przycisk OK, aby uaktualnić informacje. Wybierz urządzenie, które chcesz połączyć z isty w trybie prirowanym OK, aby się połączyć. Jeśli wyświetli się informacja **Urządzenie połączone**, połączenie nie zostało pomyślnie ustanowione. Jeśli połączenie nie zostało pomyślnie ustanowione, połącz się z trygiem bezprzewodowym.

• Wykonaj procedurę.



- Aplikacja może się zatrzymać i może zostać urochoniona kolejna aplikacja z czwartym pozykiem.
- Przykładem aplikacji HbbTV jest aplikacja na pobrańiu aplikacji, albo z HbbTV zeważna na pobieranie aplikacji, albo z platformą telewizyjną, albo z transmisji TV.
- Należy pamiętać, że dla uzyskania pełnego doświadczenia użytkownika, aplikacja HbbTV powinna działać w tle, aby umożliwić użytkownikowi korzystanie z aplikacji telewizyjnej, ale jednocześnie nie przeszkadzać w korzystaniu z aplikacji HbbTV.

Istnieje również sposób na wyszukanie lub odwiedzenie stron w internecie bez użycia przeglądarki. Wprowadź adres strony www (URL) w pasku adresu klawiatury i podnóżek przycisk Enter na wirtualnej klawiaturze oraz naciśnij przycisk OK, aby wyświetlić stronę. Wprowadź nazwę strony w pasku adresu klawiatury podnóżek przycisk Enter na wirtualnej klawiaturze oraz naciśnij przycisk OK, aby rozpoczęć szukanie od nasłuchu stron.

Podpowiedź: minimalistyczny wybór internetu i naciśnij przycisk OK, aby wyświetlić odszukaną stronę.

Twoj telefon jest kompatybilny z myszką USB. Podłącz myszkę USB do tv w celu aktywacji myszki. Po wejściu na tv w celu aktywacji myszki

czynowym przykładem zapewniająca linki do innych aplikacji. Użytkownik może przełączyć na inną aplikację korzystając z podanych linków. Aplikacje powinny zapewnić sposoby do ich wyłączenia, zwiększenia i zmniejszenia.

Aplikacja HbbTV używa przesyłków na piloci do interakcji z telewizorem. Główne użycie ma piloci do interakcji z HbbTV. W przemyśle oznacza to kontrolę nad aplikacją HbbTV. W przypadku numeryczny wybór kanału możliwe nie działa w aplikacji telewizora.

etow  
ne |  
e ża  
iprz  
itow  
y; m  
h pr  
do

gdzie przyciski będą odnosić się do numerów stron.  
W BWDY wymaga się od platform zdolności stymulowania  
AV. Istnieje też aplikacje dostarczające VOD (video  
na żądanie), które uzyskują przesyłek  
na płacie, aby odwierać zawartość AV, pausować  
zatrzymywać, przejścią do przodku i tyłu.

Uwaga: W celu wykrycia błędów funkcji kodowania z  
systemem Ustawiany powinno być w menu Ustawienia System.

**Szczegóły:** Celi jest mobilna aplikacja uzatrudniona na platformach iOS i Android. Wykorzystując zaawansowaną technologię przekrojową możesz łatwośćą na swoje usługi skierować swoje ulubione programy do swojego telewizora. Możesz także uruchomić swoje aplikacje. Korzystając z urządzenia mobilnego jako pilota do telewizora i wspólnie z aplikacją.

**Uwaga:** Możliwość korzystania ze wszystkich funkcji tej aplikacji zależy od właściwości telewizora używanego.

Podświetlone audio i video zimień na włączonym. Teraz Twoje TV jest gotowy na połączenie z urządzeniem przeznaczonym. Ustalując aplikację Smart Center na swoim urządzeniu przeznaczonym.

Zobaczysz nazwę swojego TV na urządzeniu przyznaczonym. Jeśli nazwa Twojego telewizora nie pojawiła się na liście, odczekaj chwilę i skonfiguruj podświetlenie. Wybierz swój TV z listy.

**Ekrany przesądzające**

Na głównym ekranie odnайдźesz zakładki pozwalające

**MOJE KANAŁY:** Pokazane zostaną programy w których Twoje ulubione kanały pobrano z listy 2. Wszystkie kanały, które dostały się do listy 2, są automatycznie dodane do kategorii "Moje kanały".  
**WYSZUKAJ KANAŁ:** Po uruchomieniu aplikacji pobiera istniejącą listę kanałów z telewizora.

**TV:** Możesz oglądać programy pod zakładek TV. W tym trybie możesz przerwać się po liscie kanałów i wybrac żądany kanał, który chcesz zastąpić.

**NAGRANIA:** Pod tą zakładką, odnajdziesz aktywne nagrania (jeśli dostępne) i zaplanowane nagrania. Aby usunąć określony zapis z elementem po prostu naciśnij na ikonę usuwanego, znajdującej się w każdym rzędle.

**EPGP** (Elektroniczny przewodnik po programach):

Pod tą zakładką możesz znaleźć przewodnik po programach wybranych kanałów. Możesz poruszać się po kanałach, naciśnijcie wybierz kanał na słajcie EPG. Zauważ, że aktualizacja / odświeżanie informacji EPG może chwilę potrwać, w zależności od sieci i jakości serwisu www.

**Ustawienia:** Dla informacji *ERG aparty o Internet, potrzebne do połączenia z Internetem.*

**USTAWIENIA:** Skonfiguruj aplikację według własnych upodobanów. Możesz zmienić:

**Automatyczne uruchamianie FollowMeTV:**  
Funkcja FollowMeTV (jeśli dostępna) uruchomi się automatycznie po uruchomieniu komputera.

**Automatyczne połączenie z TV:** Jeśli właczone, Twoje urządzenie przeniesie automatycznie połączy się z ostatnio podłączonym TV, z pominięciem ekranu wyszukania TV.

**Zmien TV:** Pokazuje aktualne podzialek telewizor. Mózg nacisnij to ustawienie, aby przejść do ekranu "szukania TV" i zmienić na inny telewizor.

**Dydruk** - dydruk wąsną listę kanałów: Przy użyciu tego stawienia możesz edytować swoją własną listę analów.

**Wybierz źródło listy kanałów:** Możesz wybrać kanały z którego aplikacji na bieżąco. Wybierając kanały z "Własnych", dostępne są opcje "Dodać kanały" i "Pamiętaj ostatni wybór". W "Wszystkich" kanałach, po kliknięciu na kanał, pojawi się przycisk "dodać do ulubionego".

**ZAKŁADKA** z "Wideo".  
**ZAKŁADKA GÓŁY:** Zakładka przedstawia streszczenie informacje o wybranym programie.  
**SADA I EKIPA:** Pokazuje wszystkie osoby biorące udział w tworzeniu programu.

**Uwaga:** Odpowiedni wideo z routującą oznaczającą wybrany program. **Aga:** Dla działania niektórych funkcji może być wymagane połączenie z Internetem.

Wyszczególnione na prawej części ekranu Twojego urządzenia wygląd funkcji **FollowMe** domyślnego, aby zmienić wygląd funkcji ikonkowej odtwarzania, aby rozpoczęć emisję treści z TV na Twój urządzenie bez konieczności dostępu do menu. Dostępne jeśli Twój urządzenie znajduje się w zasięgu routera.

Tryb funkcji TV FollowMe jest domyślnie włączony i pozwala na strumieniowe treści z innych wybranych sieci telewizyjnych i przeglądarek mediów.

...są wyłączne kanały cyfrowe (DVB-S), SD i HD, a obslugiwane są wyłączne kanały cyfrowe (DVB-S), SD i HD.

Uzyskać dostęp do widgetu **Współdziaływanie do góra** (widżetów), stuknij na strzałce skierowanej do góry, znajdującej się w prawej, górnej części ekranu.

Następnie ustaw **Współdziaływanie mediów** na właściwy widżet, na którym możesz wybrać, jaka aplikacja się uruchomi, kiedy chcesz współdziaływać z swoim TV.



## Aleksynt Google

Téléwizor współpracuje z Ok Google w zakresie sterowania głosowego podłączonych urządzeń.

### Wyślij poleceń z Ok Google

Za pomocą tej funkcji Alexa może sterować funkcjami sterowymi za pomocą urządzeń Aleksynt Google. W tym celu należy wykonać proces konfiguracji.

### Prowadząca instalacja

Wykonaj następujące czynności przed rozpoczęciem konfiguracji w telewizorze.

- Zainstaluj aplikację Google Home na swoim telefonie komórkowym i zaloguj się do swojego konta
- Dodaj urządzenie pomocnicze do swojego konta
- Wybierz "Smart TV" z listy akcji w aplikacji
- Wyświetl zostanie ekran, na którym naleje się wprowadzić kod użycieli telewizjnego, który został utworzony w celu połączenia telewizora z kontem. Kontynuuj konfigurację telewizora, aby uzyskać kod użycieli telewizjnego.

### Proces konfiguracji

Konfiguracja można przeprowadzić za pomocą opcji Aleksynt Google w menu Ustawienia>System>Aplikacje&Glosowy>Kreator>Przeprowadź Cię poprzez proces konfiguracji.

- Na pierwszym ekranie pojawi się Start i napisz OK, aby kontynuować.
- Zostaniesz poproszony/ogłoszona o określenie nazwy swojego telewizora - Przyjazna nazwa (FN). Przyjazna nazwa to nazwa przypisana do Ciebie telewizora, np.: "Telewizor w pokoju dziennym", "Telewizor w kuchni", "Telewizor w jadalni". Wybierz latawo do wymówienia nazwy. Po zakończeniu podświetli OK, naciśnij OK.

- Zostaniesz ułóżony i wyświetlny na ekranie kod użycieli telewizjnego. Wyszukaj kod widoczny na ekranie telewizora w aplikacji Google Home. Po zakończeniu konfiguracji bieżesz w stanie kontroli: funkcje誓wejego telewizora za pomocą Aleksynt Google.

Uwaga: Upewnij się, że urządzenie jest połączone do internetu. Może być połączony z telewizorem z swoim kontem.

Google jest znakiem towarowym firmy Google LLC.

**FN to skróć od „Przyjaznej nazwy”.**

## Przykładowe polecania

Po prostu powiedz „Ok Google”, aby sterować telewizorem za pomocą głosu.

### Polecanie

Funkcja
turn on FN
turn off FN
pause on FN
resume on FN
stop on FN
volume up on FN
volume down on FN
set mute volume on FN
switch input to input_ name on FN
change channel to chan_ number on FN
channel change channel to chan_ name on FN
channel channel up on FN
channel channel down on FN

### Dane techniczne akumulatora

Czas działania
Około 2,5 godzin (*)

### Informacje o funkcjonalności DVB

Ten odbiornik DVB może używać tylko w kraju, dla którego został zaprojektowany. Chociaż ten odbiornik DVB spełnia najwyższe normy obowiązujące w czasie jego produkcji, nie możemy gwarantować, że będzie on kompatybilny z przyszłymi transmisjami DVB w związku ze zmianami w sygnatach audyjnych i technologii, które mogą zostać wprowadzone.

Niektóre funkcje telewizji cyfrowej mogą być niedostępne we wszystkich krajach. Ciągle dążymy do tego, aby udoskonalać nasze produkty, w związku z czym specyfikacje mogą zmieniać się bez uprzedzenia.

Informacje o zakupie akcesoriów można uzyskać w sklepie, w którym nabyli Państwo swój sprzęt.

### FN to skróć od „Przyjaznej nazwy”.

Google jest znakiem towarowym firmy Google LLC.

### Producent

SHENZHEN HUNTEK ELECTRIC CO., LTD

### Identyfikator modelu

HKA1202A03B-6B

### Napięcie wejściowe (V)

100-240

### Częstotliwość wejścia AC (Hz)

50-60

### Napięcie wyjściowe (V)

24,0

### Prąd wyjściowy (A)

3,75

### Średnia efektywność podczas pracy (%)

98,80

### Skuteczność przy niskim obciążeniu (%)

95,0

### Użycie energii bez obciążenia (W)

0,21

## Specyfikacja zasilacza sieciowego

Polecanie	Funkcja
turn on FN	Włączanie TV
turn off FN	Wyłączanie TV
pause on FN	Wstrzymywanie odwzorowania
resume on FN	Wstrzymywanie odwzorowania
stop on FN	Zatrzymywanie odwzorowania
volume up on FN	Zwiększa głośność
volume down on FN	Zmniejsza głośność
set mute volume on FN	Wyciszenie dźwięku
switch input to input_ name on FN	Téléwizor przełącza się na zadaną wejściową o określonej nazwie (np. HDMI 1)
change channel to chan_ number on FN	Téléwizor przełącza się na kanał o określonym numerze (np.: kanał 200)
change channel to chan_ name on FN	Téléwizor przełącza się na kanał o określonej nazwie
channel up on FN	Téléwizor przełącza się na następny kanał, jeśli jest dostępny
channel down on FN	Téléwizor przełącza się na poprzedni kanał, jeśli jest dostępny

Dane techniczne akumulatora	Czas działania
Ok. 2,5 godziny (*)	Czas pracy możliwy wynikający z ustawienia trybu zasilania w menu Ustawienia>Bateria

Polecanie	Czas działania
Typ ogniwa	Około 2,5 godziny (*)

(\*) Czas pracy możliwy wynikający z ustawienia trybu zasilania w menu Ustawienia>Bateria

<b>Contents</b>	32
Wireless Display .....	32
Connecting Other Wireless Devices .....	32
Safety Information .....	32
Markings on the Product .....	32
Environmental Information .....	33
Features .....	33
Accessories Included .....	33
TV Control Switch & Operation .....	34
Using Main TV Menu .....	34
Inserting the Batteries into the Remote .....	34
Charging TV's Battery .....	34
Antenna Connection .....	34
License Notification .....	35
DVB Functionality information .....	35
Disposal Information .....	36
Specification .....	36
Remote Control .....	36
Remote Control - 2 .....	36
Connections .....	36
Switching On/Off .....	36
First Time Installation .....	36
Media Playback via USB Input .....	36
USB Recording .....	36
Media Browser .....	36
CEC .....	36
E-Manual .....	37
Settings Menu Content .....	37
General TV Operation .....	38
Using the Channel List .....	38
Configuring Parental Settings .....	38
Electronic Programme Guide .....	38
Teletext Services .....	38
Software Upgrade .....	38
Troubleshooting & Tips .....	38
PC Input/Typical Display Modes .....	38
AV and HDMI Signal Compatibility .....	38
Supported File Formats for USB Mode .....	38
Video File Formats .....	38
Picture File Formats .....	38
Audio File Formats .....	38
Subtitle File Formats .....	38
Supported File Resolutions .....	38
Connectivity .....	38
Wired Connectivity .....	38
Wireless Connectivity .....	38
Networked Standby Mode .....	38

## Safety Information



CAUTION

RISK OF ELECTRIC SHOCK

DO NOT OPEN

**CAUTION: TO REDUCE THE RISK OF ELECTRIC SHOCK DO NOT INSERT POWER CORD INTO AN OUTLET UNTIL INSIDE SERVICING IS COMPLETED AND INSPECTION AND SERVICING TO QUALIFIED SERVICE PERSONNEL.**

In extreme weather (storms, lightning) and long inactive periods (going on holiday) disconnect the TV set from the mains. The mains plug is used to disconnect TV set from the mains and therefore it must remain readily operable. If the TV set is not disconnected electrically from the mains, the device will still draw power for all situations even if the TV is in standby mode or switched off.

*Note: Follow the on screen instructions for operating the related features.*

### IMPORTANT - Please read these instructions fully before installing or operating

**WARNING:** This device is intended to be used by persons (including children) who are capable / experienced of operating such a device unsupervised, unless they have been given supervision or instruction concerning the use of the device by a person responsible for their safety.

• Use this TV set at an altitude of less than 5000 meters above the sea level, in dry locations and in regions with moderate or tropical climates.

• The TV set is intended for household and similar indoor use but may also be used in public places.

• For ventilation purposes, leave at least 5cm of free space around the TV.

• The ventilation should not be impeded by covering or blocking the ventilation openings with items, such as newspapers, table-cloths, curtains, etc.

• The power adaptor cord plug should be easily accessible. Do not place the TV furniture, etc. on top of power adaptor cord. Damaged power cord can cause fire or give you an electric shock. Handle the power adaptor cord by the plug so as not to tangle the TV by pulling the power adaptor cord. Never touch the power adaptor cord/plug with wet hands as this could cause a short circuit or electric shock. Never make a knot in the power adaptor cord or tie it with other cords. When damaged it must be replaced, this should only be done by qualified personnel.

• Do not expose the TV to dripping or splashing of liquids and do not place objects filled with liquids, such as vases, cups, etc. on or over the TV (e.g., on shelves above the unit).

• Do not expose the TV to direct sunlight or do not place open flames such as lit candles on the top of or near the TV.

- Do not place any heat sources such as electric heaters, radiators, etc. near the TV set.
- Do not place the TV on the floor and inclined surfaces.
- To avoid danger of suffocation, keep plastic bags out of the reach of the babies, children and domestic animals.
- Do not dispose of the batteries in fire or with hazardous or flammable materials.
- This TV is designed for mobile use in vehicles such as caravans, motorhomes, boats, etc. However, it should never be installed in any position where it may be visible to the driver or may interfere with the driver operating of the vehicle.
- The product contains a rechargeable internal battery and replacing this battery with an incorrect type may disable protection (for example, with some types of lithium batteries). Battery removal or replacement should be performed by authorised service personnel.
- The temperature conditions in which the battery operates should be in the range of 0 – 45°C when charging and -10 – 50°C when discharging.
- When the TV is not in use, make sure the main switch is turned off. Even if the main switch is turned off, it is recommended not to disconnect the power adapter to prevent battery from draining.
- When storing the product for a long period of time, be sure to fully charge the battery at least once a year. Battery life may vary depending on usage.
- Leaving the battery in an extremely high temperature environment or exposing the battery to extremely low air pressure may cause an explosion or leakage of flammable liquid or gas.
- Noncompletely installed batteries may result in a risk of leakage or explosion and physical injury.
- Do not disassemble, crush or puncture the battery. Do not short-circuit the terminals; do not expose to fire or water.
- Rechargeable batteries may pose a risk of fire and chemical burns if handled incorrectly.
- Do not use or change the battery if it is leaking, discoloured, deformed or otherwise does not appear normal.

### WARNING

Supplied AC/Adaptor is for use with the product only, do not use for any other purpose.

Batteries must not be exposed to excessive heat such as sunshine, fire or the like.

Excessive sound pressure from earphones or headphones can cause hearing loss.

**ABOVE ALL - NEVER let anyone, especially children, push or hit the screen, push anything into holes, slots or any other openings in the case.**

<b>Accessories Included</b>	<ul style="list-style-type: none"> <li>• Remote controlled colour TV</li> <li>• Fully integrated digital terrestrial/cable/satellite TV (DVB-T/T2/C/S/S2)</li> <li>• USB input</li> <li>• OSD menu system</li> <li>• Back AV inputs for external devices (such as DVD Players, PVR, video games, etc.)</li> <li>• Stereo sound system</li> <li>• Teletext</li> <li>• Headphone connection</li> <li>• Automatic programming system</li> <li>• Manual tuning</li> <li>• Automatic power down after up to eight hours</li> <li>• Sleep timer</li> <li>• Child lock</li> <li>• Automatic sound mute when no transmission</li> <li>• NTSC playback</li> <li>• AVL (Automatic Volume Limiting)</li> <li>• PLL (Frequency Search)</li> <li>• PC input</li> <li>• Game Mode (Optional)</li> <li>• Picture of function</li> <li>• Programme recording</li> <li>• Programme timeshifting</li> <li>• Ethernet (LAN) for Internet connectivity and service</li> <li>• 802.11 abgn built in WLAN Support</li> <li>• Audio Video Sharing</li> <li>• HbbTV</li> </ul>
<b>Features</b>	<p>anchoring both the furniture and the television set to a suitable support.</p> <ul style="list-style-type: none"> <li>• NEVER place the television set on cloth or other materials that may be located between the television set and supporting furniture.</li> <li>• NEVER place items that might tempt children to climb, such as toys and remote controls, on the top of the television or furniture on which the television is placed.</li> <li>• The equipment is only suitable for mounting at heights &lt;2 m. If the existing television set is going to be retained and relocated, the same considerations as above should be applied.</li> </ul> <p>Appliances connected to the protective earthing of the building installation through the MAINS connection or through other apparatus with a connection to protective earthing—and/or a television distribution system using coaxial cable, may in some circumstances create a fire hazard. Connection to a television distribution system has therefore to be provided through a device providing electrical isolation below a certain frequency range (galvanic isolator).</p> <p>Figures and illustrations in this user manual are provided for reference only and may differ from the actual product appearance. Product design and specifications may be changed without notice.</p>
<b>Markings on the Product</b>	<p>The following symbols are used on the product as a marker for restrictions and precautions and safety instructions. Each explanation shall be considered where the product bears related marking only. Note such information for security reasons.</p> <p><b>Class II Equipment:</b> This appliance is designed in such a way that it does not require a safety connection to electrical earth.</p> <p><b>Caution, See Operating Instructions:</b> The marked area(s) contains user replaceable coin or button cell batteries.</p> <p><b>Class 1 Laser Product:</b> This product contains Class 1 laser source that is safe under reasonable foreseeable conditions of operation.</p> <p><b>Warning</b> Do not ingest the battery. <b>Chemical Burn Hazard</b> This product or the accessories supplied with the product may contain a coin/button cell battery. If the coin/button cell battery is swallowed, it can cause severe internal burns in just 2 hours and can lead to death. Keep new and used batteries away from children. If the battery compartment does not close securely, stop using the product and keep it away from children. If you think batteries might have been swallowed or placed inside any part of the body, seek immediate medical attention.</p> <p>A television may fall, causing serious personal injury or death. Many injuries, particularly to children, can be avoided by taking simple precautions such as:</p> <ul style="list-style-type: none"> <li>• ALWAYS use cabinets or stands or mounting methods recommended by the manufacturer of the television set.</li> <li>• ALWAYS use furniture that can safely support the television set.</li> <li>• ALWAYS ensure the television set is not overhanging the edge of the supporting furniture.</li> <li>• ALWAYS educate children about the dangers of climbing on furniture to reach the television set or its controls.</li> <li>• ALWAYS route cords and cables connected to your television so they cannot be tripped over, pulled or grabbed.</li> <li>• NEVER place a television set on tall furniture (for example, cupboards or bookcases) without disconnecting the power adaptor from the mains plug. This will also reduce energy consumption.</li> </ul>
<b>Caution</b>	Serious injury or death risk
<b>A Risk of electric shock</b>	Dangerous voltage risk
<b>⚠ Maintenance component</b>	Important maintenance component
<b>CLASS 1 LASER PRODUCT</b>	CLASS 1 LASER PRODUCT

<b>Standby Mode Picture</b>	<p>You can use your TV as a digital picture frame using the Standby Mode Picture feature. In order to do this follow the steps below.</p> <ul style="list-style-type: none"> <li>• Set the <b>Standby Mode Picture</b> option in the <b>Settings&gt;System&gt;Default</b> menu as <b>On</b>. This option is set as <b>Off</b> by default.</li> <li>• Create a separate folder named as <b>standby_picture</b> in the USB storage device's root directory and copy the files you want to use into that folder and then connect the USB storage device to your TV.</li> <li>• Press the <b>Standby</b> button on the remote briefly to switch your TV into standby mode picture state. Note that once the <b>Standby Mode Picture</b> option is set as <b>On</b>, the function of the <b>Standby</b> button on the remote will change. After this you will need to press the <b>Standby</b> button to switch the TV into standby mode while the TV is in normal operating mode.</li> <li>• If there are more than 1 picture file available in the folder all picture files will be displayed as a slide show in succession. If the necessary folder is not created or there isn't any picture file in the folder, a warning message will be displayed on the screen for a few seconds and then disappear.</li> <li>• In standby mode picture state the backlight level of the screen will be decreased by 50 % and Smart Center features will not be usable. iSmart Center is available for your TV model.</li> <li>• To switch your TV from standby mode picture state back to normal operating mode press the <b>Standby</b> button on the remote briefly.</li> </ul> <p>Beside the remote control you can also use the control unit on the TV to switch into standby mode picture state and back to normal operating mode. In order to do that follow the same instructions as described in the <b>TV Control &amp; Operations</b> section for switching the TV into the standby mode. Note that you will not be able to switch the TV into standby mode using the control unit on the TV while the TV is in standby mode picture state.</p> <p><b>Note:</b> The availability of this feature depends on the TV model and its features.</p>
<b>High Dynamic Range (HDR) Hybrid Log-Gamma (HLG)</b>	<p>Using this feature the TV can reproduce greater dynamic range of luminosity by capturing and then combining several different exposures. HDR/HLG promises better picture quality thanks to brighter, more realistic highlights, more realistic colour and other improvements. It delivers the look that filmmakers intended to achieve showing the hidden areas of dark shadows and sunlight with full clarity, colour and detail. HDR/HLG contents are supported via native and market applications. HDMI, USB inputs and over DVB-S broadcasts.</p>
<b>Energy Saving</b>	<p>If you set the <b>Energy Saving to Minimum, Medium, Maximum</b> or <b>Auto</b> the TV will reduce the energy consumption accordingly. If you like to set the <b>Backlight</b> to a fixed value set as <b>Custom</b> and adjust the <b>Backlight</b> (located under the <b>Energy Saving</b> setting) manually using Left or Right buttons on the remote. Set <b>Off</b> to turn this setting off.</p> <p><b>Note:</b> Available <b>Energy Saving</b> options may differ depending on the <b>Selected Mode</b> in the <b>Settings&gt;Picture</b> menu.</p> <p><b>Energy Saving</b> settings can be found in the <b>Settings&gt;Picture</b> menu. Note that some picture settings will be unavailable to be changed.</p> <p>If pressed Right button or Left button consecutively "Screen will be off in 15 seconds" message will be displayed on the screen. Select <b>Proceed</b> and press <b>OK</b> to turn the screen off immediately. If you don't press any button, the screen will be off in 15 seconds. Press any button on the remote or the TV to turn the screen on again.</p> <p><b>Note:</b> Screen <b>Off</b> option is not available if the Mode is set to <b>Game</b>.</p> <p>When the TV is not in use, please switch off or disconnect the power adaptor from the mains plug. This will also reduce energy consumption.</p>
<b>Supported File Formats for USB Mode</b>	For the supported media file formats.

## Standby Notifications

If the TV does not receive any input signal (e.g. from an aerial or HDMI source) for 3 minutes, it will go into standby. When the next switch-on, the following message will be displayed: "TV switched to Standby mode automatically because there was no signal for a long time." You can disable this functionality by setting the **Timer of No Signal** option in the **Settings>Devices** menu accordingly.

The **Auto Power Down** option in the **Settings>System >More** menu) could have been set to a value between 1 and 12 hours by default. If this setting is not set as **Off** and the TV has been left on and not been operated during the set time, it will switch into standby mode after the set time has expired. When you next switch-on the TV, the following message will be displayed: "TV switched to Standby mode automatically because no power was made for a long time." Before the window will be displayed, if you do not press any key on the TV screen, it will switch into the standby mode after a waiting period of about 5 minutes. You can highlight **Yes**, and press **OK** to switch the TV into stand-by mode immediately. You can also choose to cancel the **Auto Power Down** function from this dialogue. Highlight **Disable** and press **OK**, the TV will remain on and the function will be cancelled. You can enable this function again by changing the setting of the **Auto Power Down** option from the **Settings>System>More** menu.

## TV Control Switch & Operation

Press the **Menu** button on your remote control to display main menu. Use the directional buttons and **OK** button to navigate and set. Press **Return/Back or Menù** button to quit a menu screen.

### Input Selection

Once you have connected external systems to your TV, you can switch to different input sources. Press the **Source** button on your remote control consecutively to select the different sources.

### Changing Channels and Volume

You can change the channel and adjust the volume by using the **Programme +/-** and **Volume +/-** buttons on the remote.



1. Up direction

2. Down direction

3. OK button

### Reset and Power Off /& Standby Button

Press and hold the **Standby** button to see additional actions for this button. **Reset** (Reset), **Standby** (Normal Standby), and **Power off** (Forced Standby) options

## 2. Search

When the **Menu** button is pressed, the main TV menu will appear on the screen. You can navigate through the menu items using the directional buttons on the remote. To select an item or see the submenu options of the highlighted menu press **OK**. When you highlight a menu option some of the submenu items of this menu may appear on the upper side of the menu bar for quick access. To use a quick access item highlight it, press **OK** and set as desired using the Left/Right directional buttons. When finished press **OK** or **Back/Return** button to exit.

### Using Main TV Menu

When the **Menu** button is pressed the main TV menu will appear on the screen. You can navigate through the menu items using the directional buttons on the remote. To select an item or see the submenu options of the highlighted menu press **OK**. When you highlight a menu option some of the submenu items of this menu may appear on the upper side of the menu bar for quick access. To use a quick access item highlight it, press **OK** and set as desired using the Left/Right directional buttons. When finished press **OK** or **Back/Return** button to exit.

You can also see information on location, weather, time, date and TV's battery life remaining on the main TV menu screen. The green small icons indicate the current status for time, network and sync for apps. If these icons appear in green, it means that the time information is updated, network is connected and sync is completed in success. Otherwise the icons will appear in white.

Depending on the country selection made during first time installation, TV's time information in the menu bar will be displayed by pressing the **Menu** button and then the **Blue** button. Concerned about the quality of our products, televisions are subject to rigorous checks before being put on the market, therefore it is possible that this value is not at 0 during the first installation. Press **Exit** button to close the main menu.

### 3. 1. Guide

You can access the electronic programming guide menu using this option. Refer to **Electronic Programme Guide** section for more information.

### 3. 2. Channels

You can access the **Channels** menu using this option. Refer to **Using the Channel List** section for more information.

### 3. 3. Timers

You can set timers for future events using the options of this menu. You can also review the previously created timers under this menu.

To add a new timer select the **Add Timer** tab using the Left/Right buttons and press **OK**. Set the sub-menu options as desired and when finished press **OK**. A new timer will be created.

To edit a previously created timer, highlight that timer, select the **Edit Selected Timer** tab and press **OK**. Change the sub-menu options as desired and press **OK** to save your settings.

To cancel an already set timer, highlight that timer, select **Delete Selected Timer** tab and press **OK**. A confirmation message will be displayed. Highlight **Yes** and press **OK** to proceed. The timer will be cancelled.

It is not possible to set timers for two or more events that will be broadcasted in different channels at the same time interval. In this case you will be asked to choose one of these timers and cancel others. Highlight the timer you want to cancel and press **OK Options** menu will be displayed. Then highlight **Set/Cancel** and press **OK** to cancel that timer. You will have to save changes after that. In order to do that, press **OK**, highlight **Save Changes** and press **OK** again.

### 3. 4. Recordings

You can manage your recordings using the options of this menu. You can playback, edit, delete or sort previously recorded events. Highlight a tab by using the Left or Right direction button and press **OK** to see available options.

### 3. 5. More Apps

In order to manage the apps installed on your TV, you can use this option. Highlight and press **OK**. You can add an installed app to **Home** menu, launch or

will be available. Highlight one and press **OK** to perform the selected action. If a problem occurs that prevents the TV from switching into standby mode properly you can use the **Power off** option to force the TV to switch into standby mode.

If your TV stops responding to commands and the action menu can not be displayed, the TV will be forced to restart when the button is kept pressed for about 5 seconds. This will terminate the process.

### 4. 1. Remote

Note: The position of the power switch may differ depending on the model.

To **change volume**: Increase the volume by pushing the button up. Decrease the volume by pushing the button down.

To **change channel**: Press the middle of the button in the information banner will appear on the screen. Scroll through the stored channels by pushing the button up or down.

To **change source**: Press the middle of the button twice on the second line in total, the source list will appear on the screen. Scroll through the available sources by pushing the button up or down.

To **turn the TV off**: Press the middle of the button in and hold it down for a few seconds, the TV will turn into standby mode.

To **turn on the TV**: Press the middle of the button in, the TV will turn on.

### Notes:

If you turn the TV off, this cycle starts again beginning with the volume setting.

Main menu OSD cannot be displayed via control button.

### Operation with the Remote Control

Press the **Menu** button on your remote control to display main menu. Use the directional buttons and **OK** button to navigate and set. Press **Return/Back or Menù** button to quit a menu screen.

### Input Selection

Once you have connected external systems to your TV, you can switch to different input sources. Press the **Source** button on your remote control consecutively to select the different sources.

### Changing Channels and Volume

You can change the channel and adjust the volume by using the **Programme +/-** and **Volume +/-** buttons on the remote.

### Reset and Power Off /& Standby Button

Press and hold the **Standby** button to see additional actions for this button. **Reset** (Reset), **Standby** (Normal Standby), and **Power off** (Forced Standby) options

## Disposal Information

**Notification** The terms HDMI, High-Definition Multimedia Interface, HDMI trade dress and the HDMI Logo are trademarks or registered trademarks of HDMI Licensing Administrator, Inc.

**HDMI™**  
HDMI logo is a trademark of HDMI Licensing Administrator, Inc.

Manufactured under licence from Dolby Laboratories Licensing Corporation. Dolby, Dolby Audio, and the double-D symbol are trademarks of Dolby Laboratories Licensing Corporation.

**YouTube** and the YouTube logo are trademarks of YouTube Inc.

This product contains technology subject to certain intellectual property rights of Microsoft. Use or distribution of this technology outside of this product is prohibited without the appropriate license(s) from Microsoft.

Content owners use Microsoft PlayReady™ content access technology to protect their intellectual property, including copyrighted content. This device uses PlayReady technology to access PlayReady-protected content, and/or WMRM-protected content. If the device fails to properly enforce restrictions on content usage, content owners may require Microsoft to revoke the device's ability to consume PlayReady-protected content. Revocation should not affect unprotected content or content protected by other content access technologies. Content owners may require you to upgrade PlayReady to access their content. If you consent that requires the upgrade.

The terms Symbols indicate that the electrical and electronic equipment and the battery with this symbol should not be disposed of as general household waste at its end-of-life. Instead, the products should be handed over to the applicable collection points for the recycling of electrical and electronic equipment as well as batteries for proper treatment, recovery and recycling in accordance with your national legislation and the Directive 2012/19/EU and 2013/56/EU. By disposing of these products correctly, you will help to conserve natural resources and will help to prevent potential negative effects on the environment and human health which could otherwise be caused by inappropriate waste handling of these products.

For more information about collection points and recycling of these products, please contact your local municipal office, your household waste disposal service or the shop where you purchased the product. Penalties may be applicable for incorrect disposal of this waste, in accordance with national legislation.

**Business users**

If you wish to dispose of this product, please contact your supplier and check the terms and conditions of the purchase contract.

**Other Countries outside the European Union**

These symbols are only valid in the European Union. Contact your local authority to learn about disposal and recycling.

The product and packaging should be taken to your local collection point for recycling.

Some collection points accept products free of charge.

**Note:** The sign indicates that this battery contains a lead.

1. Products

2. Battery

To power the TV. Fully charge the battery before using the TV for the first time. To charge your TV's battery, plug the power adaptor into the power adaptor port on the rear side of the TV. The supplied adaptor gives 24 V power. The battery will start charging as soon as the power adaptor is connected to an external power source. The red LED near the power adaptor port will illuminate to indicate active charging. When the battery is fully charged, the LED will turn off. Connect the adaptor to a system that supplies **100-240V AC, 50/60Hz**. After unpacking, allow the TV set to reach the ambient temperature before you connect the set to the mains.

### Important safety information

**Be sure to ground the connection properly**


Connect the round terminal of the AC adaptor with the ground terminal provided with the power outlet using the supplied power adaptor cord. If the provided plug does not fit your outlet, consult an electrician for replacement of the obsolete outlet.



Surely connect the ground wire.

**Antenna Connection**  
Connect the aerial or cable TV plug to the aerial input (ANT) socket or satellite plug to the satellite input (LN) socket located on the rear side of the TV.

**Rear side of the TV**



1. Satellite
2. Aerial or cable

If you want to connect a device to the TV, make sure that both the TV and the device are turned off before making any connection. After the connection is done, you can turn on the units and use them.

remove it. Highlight an app and press **OK** to see the available options.

### 3.6. Market

You can add new apps from the application market using this option. Highlight and press **OK**. Available apps will be displayed. You can also access the application market from within the **More Apps** menu.

### 3.7. Accessibility

You can access the accessibility settings menu directly using this option.

### 3.8. Privacy Settings

You can access the privacy settings menu directly using this option. This option may not be available depending on the model of your TV and the selected country during the first time installation process.

### 4. Settings

You can manage the settings of your TV using the options of this menu. Refer to **Settings Menu Content** section for more information.

You can reset your customisations on the **Home** menu to defaults using the **Reset Apps** option (availability depends on TV model and its features). Highlight and press **OK**. A confirmation message will be displayed. Highlight **Yes** and press **OK** to proceed. Note that you will not be able to perform this operation again within the next few minutes.

### 5. Sources

You can manage your input source preferences using the options of this menu. To change the current source highlight the name and press **OK**.

### 5.1. Source Settings

You can access the source settings menu directly using this option. Edit the names, enable or disable selected source options.

### Inserting the Batteries into the Remote

The remote may have a screw that secures the battery compartment cover to the remote control (if this may be in separate bag) remove the screw. Then remove the battery compartment cover on previous. Then remove the battery compartment cover to reveal the battery compartment. Insert two 1.5V "size AAA" batteries. Make sure the (+) and (-) signs match (observing correct polarity). Do not mix old and new batteries. Replace only with same or equivalent type. Place the cover back on. Secure the cover again with the screw, if any.

A message will be displayed on the screen when the batteries are low and must be replaced. Note that when the batteries are low, the performance of the remote control may be affected.

Batteries should not be exposed to excessive heat such as sunshine, fire or like.

### Charging TV's Battery

The TV is designed to operate on battery power. You may need to charge your TV's battery before using it for the first time as it may not have enough charge


## Country Restrictions

The Wireless LAN equipment is intended for home and office use in all EU countries, the UK and Northern Ireland (and other countries following the relevant EU and/or UK directive). The 5.15 - 5.35 GHz band is restricted to indoor operations only in the EU countries, in the UK and Northern Ireland (and other countries following the relevant EU and/or UK directive). Public use is subject to general authorisation by the respective service provider.

Country	Restriction
Russian Federation	Indoor use only

The requirements for any country may change at any time; it's recommended that user checks with local authorities for the current status of their national regulations for both 2.4 GHz and 5 GHz wireless LANs.

## Remote Control



## Specification


TV Broadcasting	PAL, SECAM, NTSC
Receiving Channels	VHF (BAND III) - UHF (BAND IV) - HYPERBAND (BAND U)
Digital Reception	Fully integrated digital terrestrial-cable-satellite TV(DVB-T/C/S) (DVB-T2, DVB-S2 compliant)
Number of Preset Channels	11,000
Channel Indicator	On Screen Display
RF Aerial Input	75 Ohm (unbalanced)
Operating Voltage	100-240V AC, 50/60Hz.
Audio	German+Nicam Stereo
Audio Output Power (WRMS), (10% THD)	2x6
Power Consumption (W)	75W
Networked Standby Mode	< 2
Power Consumption (W)	Power consumption (W)
TV Dimensions DxDxH (without stand) (mm)	125 x 734 x 467
Display	32"
Operation temperature and operation humidity	0°C up to +40°C, 85% humidity max

## Wireless LAN Transmitter Specifications

Frequency Ranges	Max. Output Power
2400 - 2483.5 MHz (CH1-CH13)	< 100 mW
5150 - 5250 MHz (CH36 - CH48)	< 200 mW
5280 - 5350 MHz (CH52 - CH64)	< 200 mW
5470 - 5725 MHz (CH100 - CH140)	< 200 mW

- Standby (\*): Reset / Power Off (press briefly)
- Numeric buttons: Switches the channel, enters a number or a letter in the text box on the screen
- Language: Switches among sound modes (analogue TV), displays and changes audio/subtitle language and turns subtitles on or off (digital TV, where available)
- Mute: Completely turns off the volume of the TV
- Volume +/-
- Guide: Displays the electronic programme guide
- Directional buttons: Helps navigate menus, content etc., and displays the subpages in TXT mode when pressed Right or Left
- OK: Confirms user selections, holds the page (in TXT mode), views **Channels** menu (DTV mode)
- Back/Return: Returns to previous screen, previous menu, opens index page (in TXT mode), quickly cycles between previous and current channels or sources
- Netflix: Launches the Netflix application
- Prime Video: Launches the Amazon Prime Video application
- Twitch: Launches the Twitch application
- Coloured Buttons: Follow the on-screen instructions for coloured button functions
- Rewind: Moves frames backwards in media such as movies
- Record: Records programmes
- Play: Starts to play selected media
- Stop: Stops the media being played
- Pause: Pauses the media being played, starts timeshift recording
- Fast Forward: Moves frames forward in media such as movies
- My Button 1 (\*)
- Rakuten TV: Launches the Rakuten TV application
- YouTube: Launches the YouTube application
- Exit: Closes and exits from displayed menus or returns to previous screen
- Info: Displays information about on-screen content, shows hidden information (reveal - in TXT mode)
- Menu: Displays TV menu
- Source: Shows available broadcast and content sources
- Programme +/-
- Text: Displays teletext (where available), press again to superimpose the teletext over a normal broadcast picture (mix)

- Standby Button  
Press and hold the **Standby** button to see an additional action for this button. Highlight one of the **Reset** (Reset), **Standby** (Normal Standby), and **Power** (Force Standby) options and press **OK** to perform the selected action. If your TV stops responding to commands and the actions menu can not be displayed, the TV will be forced to restart when the button is kept pressed for about five seconds.
- Fast Forward  
Press briefly and release the button to switch the TV into standby mode or to switch it on when it's in standby mode.
- My Button 1  
This button may have a default function depending on the model. However you can set a special function to this button by pressing on it for three seconds when on a desired source, channel or application. A confirmation message will be displayed on the screen. Now the My Button 1 is associated with the selected function.
- Programme +/-
- Text: Displays teletext (where available), press again to superimpose the teletext over a normal broadcast picture (mix)
- First Time Installation  
Note that if you perform **First Time Installation**, My Button 1 will return to its default function.



1. Standby ('): Standby / On (press briefly)
2. Reset / Power Off (press and hold)
3. Directional buttons: Helps navigate menus, content, etc. and displays the subpages in TXT mode when pressed Right or Left
4. OK: Confirms user selections; holds the page (in TXT mode), views Channels menu (DTV mode)
5. Back/Return: Returns to previous screen, previous menu, opens index page (in TXT mode). Quickly cycles between previous and current channels or sources
6. Volume +/-
7. Netflix: Launches the Netflix application
8. Prime Video: Launches the Amazon Prime Video application
9. My button 1 (\*)
10. YouTube: Launches the YouTube application
11. Programme +/-
12. Mute: Completely turns off the volume of the TV
13. Exit: Closes and exits from displayed menus or returns to previous screen
14. Source: Shows available broadcast and content sources
15. Internet: Opens the internet browser

#### Inserting the Batteries into the Remote

Remove the battery compartment cover to reveal the battery compartment. Insert two size AAA batteries. Make sure the (+) and (-) signs match (observing correct polarity). Do not mix old and new batteries. Replace only with same or equivalent type. Place the cover back on.

#### To pair remote with the TV

Press and hold the Source button on the remote until the LED on the remote starts to blink, then release the Source button. That means the remote is in pairing mode.

#### Start device discovery on the TV. Refer to Connecting Other Wireless Devices section for further information.

Now you will wait for the TV to find your remote. Select the name of your remote and press OK when it appears on the TV screen.

When the pairing process is successful, the LED on the remote will go off. If the pairing process fails the remote will enter sleep mode after 30 seconds.

#### See the illustrations on the left side. You can use YPbPr to VGA cable to enable YPbPr signal via VGA input. You cannot use VGA and YPbPr at the same time. If you want to use YPbPr, you will need to disconnect the YPbPr cable from the YPbPr/Audio cable for audio connection. Insert one end of the Cr module only when the TV is SWITCHED OFF. You should refer to the module instruction manual for details of the settings. The Ench USB port of your TV supports devices up to 500mA. Connecting devices that have current value above 500mA may damage your TV. When connecting equipment using a HDMI cable to your TV, to guarantee sufficient immunity against parasitic frequency induction, you have to use a high speed shielded ('high grade') HDMI cable with ferrites.

Connector	Type	Cables	Device
	VGA Connection (back)		
AUDIO IN	PC/YPbPr Audio Connection (back)		
	HDMI Connection (side/back)		
SPDIF	SPDIF (Optical Out) Connection (back)		
	BACK AV (Audio/Video) Connection (back)		
HEADPHONE	Headphone Connection (side)		
	YPbPr Video Connection (back)		
	USB Connection (side)		
LAN	Ethernet Connection (back)		
	24V DC Connection (back)		

If you want to connect a device to the TV, make sure that both the TV and the device are turned off before making any connection. After the connection is done, you can turn on the units and use them.

## Switching On/Off

### To Switch the TV On

Connect the power adapter to a power source such as a wall socket (100-240V AC, 50 Hz), if the TV battery is drained. Turn on the main switch  located on the TV - position 1<sup>1</sup>. The TV will switch into standby mode and the standby LED will light up.

**Note:** Main switch position/way/choice depending on the model. To switch on the TV from standby mode either:

- Press the Standby button. Programme +/- or a numeric button on the remote control.
- Press the middle of the side function switch on the TV in.

### To Switch the TV Off

Press the Standby button on the remote control or press the middle of the side function switch on the TV in and hold it down for a few seconds, the TV will switch into standby mode. Turn off the main switch  - position 2<sup>1</sup>. The TV will switch off.

**Note:** When the TV is switched into standby mode the standby LED can blink to indicate that features such as Standby Mode Search, Over Air Download or Timer is active. The LED can also blink when you switch on the TV from standby mode.

### First Time Installation

When turned on for the first time, the language selection screen is displayed. Select the desired language and press OK. In the following steps of the installation guide, set your preferences using the directional buttons and OK button. After the language selection, you will be asked whether you want to change accessibility settings. Highlight Yes and press OK to change. Refer to **System Menu Content** section for detailed information on available options.

Set your country preference on the next screen. Depending on the **Country** selection you will be asked to set and confirm a PIN at this point. The selected PIN cannot be 0000. You have to enter it if you are asked to enter a PIN for any menu operation later.

You can activate **Store Mode** option in the next step. This option will configure your TV's settings for store environment and depending on the TV model being used, the supported features of it may be displayed on the screen as an info banner or the pre-installed video file may be played back. This option is intended only for store use. It is recommended to select **Home Mode** for home use. This option will be available in **Settings->System->Mode** menu and your preference for this setting can be changed later. Make your selection and press OK to continue.

The picture mode selection screen will then be displayed. In order for your TV to consume less energy and be more environmentally friendly select **Natural** and press OK to continue. You can change your selection later using the **Mode** option in the **Settings->Picture** menu.

Depending on the model of your TV and the country selection **Privacy Settings** menu may appear at this point. Using this menu you can set your privacy privileges. Highlight a feature and press OK to enable or disable. Read the brief explanations displayed on the screen for each highlighted feature before making any changes. You can press the Right directional button to highlight the text and use the Programme +/- or Up/Down directional buttons to scroll up and down to read the entire text. You will be able to change your preferences at any time later by using the **Settings->System->Privacy Settings** menu. If the **Network Connection** option is disabled **Network Internet Settings** screen will be skipped and not displayed. If you have any questions, complaints or comments regarding this privacy policy or its enforcement, please contact by email at smartexperience@vostu.com.

Highlight **Next** and press OK, button on the remote control to continue and the **Network/Internet Settings** menu will be displayed. Please refer to **Connectivity** section to configure a network connection. If you want your TV to consume less power in standby mode, you can disable the **Networked Standby Mode** option by setting it to Off. After the settings are completed highlight **Next** and press OK to continue.

Depending on the model of your TV and supplied remote controls, an automatic pairing screen may be displayed at this point. Follow the on-screen instructions to pair your wireless remote control (depends on the model of the remote control) to your TV. Refer to the **Remote Control - 2** section for more information. If you want to pair your remote control at a later time, highlight **Setup Later** and press OK.

On the next screen the **Devices** menu will be displayed. You can connect external wireless audio devices, keyboards and mice to your TV. For audio devices use the **Audio Link** option, for wireless keyboards and mice use the **Input Device** option. Refer to the **Connectivity** section for more information on connecting wireless devices. To continue highlight **Next** and press OK.

On next screen, you can set broadcast types to be searched, set your encrypted channel searching and time zone (depending on the country settings) preferences. Additionally you can set a broadcast type as your favourite one. Priority will be given to the selected broadcast type during the search process and the channels of it will be listed on the top of the

channel list. When finished, highlight **Next** and press OK to continue.

### About Selecting Broadcast Type

To turn a search option for a broadcast type highlight and press OK. Then checkbox next to the selected option will be checked. To turn the search option off clear the checkbox by pressing OK after moving the focus on the desired broadcast type option.

**Digital Aerial:** If D. **Aerial** broadcast search option is turned on, the TV will search for digital terrestrial broadcasts after other initial settings are completed.

**Digital Cable:** If D. **Cable** broadcast search option is turned on, the TV will search for digital cable broadcasts after other initial settings are completed. A message will be displayed before starting to search asking if you want to perform cable network search. If you select Yes and press OK you can select **Network** or set values such as **Frequency**, **Network ID** and **Search Step** on the next screen. If you select No and press OK, you can set **Start Frequency**, **Stop Frequency** and **Search Step** on the next screen. When finished, highlight **Next** and press OK to continue.

**Note:** Searching duration will change depending on the selected **Search Step**.

**Satellite:** If Satellite broadcast search option is turned on, the TV will search for digital satellite broadcasts after other initial settings are completed. Before satellite search is performed some settings should be made. **Antenna Type** menu will be displayed first. You can select **Antenna Type** as **Direct**, **Single Satellite Cable** or **DISEqC Switch** by using Left or Right buttons. After selecting your antenna type OK to see the options to proceed. **Continua Transponder List** and **Configure LNB** options will be available. You can change the transponder and LNB settings using the relevant menu options.

**• Direct:** If you have a single receiver and a direct satellite dish select this antenna type. Press OK to continue. Select an available satellite on the next screen and press OK to scan for services.

**• Single Satellite Cable:** If you have multiple receivers and a single satellite cable system, select this antenna type. Press OK to continue. Configure settings by following instructions on the next screen.

**• DISEqC switch:** If you have multiple satellite dishes and a DISEqC switch, select this antenna type. Then set the DISEqC version and press OK to continue. You can set up to four satellites (if applicable) for version v1.0 and sixteen satellites for version v1.1 on the next screen. Press OK button to scan the first satellite in the list.

**IMPORTANT:** When using a new USB hard disk drive it is recommended that you first format the disk using your TV's **Format Disk** option in the **TV->Recordings->Settings** menu.

**Analogue:** If Analogue broadcast search option is turned on, the TV will search for analogue broadcasts after other initial settings are completed.

After the initial settings are completed TV will start to search for broadcast stations of the selected broadcast types.

The search continues current scan results will be displayed at the bottom of the screen. After all the available stations are stored, the **Channels** menu will be displayed. You can edit the channel list according to your preferences using the **Edit** tab options or press the **Menu** button to quit and watch TV.

**(LCN)** is **Logical Channel Number** system that organizes available broadcasts in accordance with a recognizable channel number sequence (*if available*).

**IMPORTANT:** Do not turn off the TV while initializing first time installation. Note that, some options may not be available on the country selection.

### Media Playback via USB Input

You can connect 2.5" and 3.5" inch HDD with external power supply or external hard disk drives on USB memory stick to your TV by using the **USB** inputs of the TV.

**IMPORTANT:** Back-up the files on your storage devices before connecting them to the TV. Manufacturer will not be responsible for any file damage or data loss. Certain types of USB devices (e.g. MP3 Players or USB hard disk drives/memory sticks may not be compatible with this TV. The TV supports FAT32 and NTFS file formats but recording will not be available with NTFS formatted disks.

While forming USB hard drives which have more than 1TB (Tera Byte) storage space you may experience some problems in the formatting process. Wait a little while before each plugging and unplugging as the player may still be reading files. Failure to do so may cause physical damage to the USB player or the USB device itself. Do not pull out your drive while playing a file.

You can use USB hubs with your TV's USB inputs. External power supplied USB hubs are recommended in such a case.

It is recommended to use the TV's **USB** inputs directly if you are going to connect a USB hard disk drive. When viewing image files the **Media Browser** menu can display 1000 image files stored on the connected USB device.

### Recording a Programme

**IMPORTANT:** When using a new USB hard disk

drive it is recommended that you first format the disk using your TV's **Format Disk** option in the **TV->Recordings->Settings** menu.

To record a programme, you should first connect a USB disk to your TV while the TV is switched off. You should then switch on the TV to enable the recording feature. To save recording to a USB disk it should have 2GB free space and be USB 2.0 compatible. If the USB drive is not compatible an error message will be displayed. To recording duration programmes as more, it is recommended to use USB hard disk drives (HDD's). Recorded programmes are saved in the connected USB disk. If desired, you can store/copy recordings onto a computer; however, these files will not be available to be played on a computer. You can play the recordings only via your TV. Lip Sync delay may occur during the timeshifting. Radio record is supported. The TV can record programmes up to ten hours.

Recorded programmes are split into 4GB partitions. If the writing speed of the connected USB disk is not sufficient, the recording may fail and the timeshifting feature may not be available. It is recommended to use USB hard disk drives for recording HD programmes. Do not pull out the USB/HDD during a recording. This may harm the connected USB/HDD. Multithread support is available. A maximum of two different partitions are supported. The first partition of the USB disk is used for USB Recording ready features. It also must be formatted as the primary partition to be used for the USB Recording ready features.

Some stream packets may not be recorded because of sync problems, as a result sometimes videos may freeze during playback. Record, Play, Pause, Delete (or playlist dialogue) keys can not be used when teletext is on. If a recording starts from timer when teletext is on, teletext is automatically turned off. Also teletext usage is disabled when there is an ongoing recording or playback.

While recording a programme in the background, you can use menu options, switch to another source or use **Media Browser** functions, such as viewing pictures, playing video and music files, and even play back the ongoing recording.

**Timeshift Recording**  
Press **Pause** button while watching a broadcast to pause recording. In timeshifting mode, the programme is paused and simultaneously recorded to the connected USB disk.

Press **Play** button again to resume the paused programme from where you stopped. Press the **Stop** button to stop timeshift recording and return to the live broadcast.

Timeshift cannot be used while in radio mode. You can use the timeshift/rewind feature after resuming normal playback or fast forward option.

## Instant Recording

Press **Record** button to start recording an event instantly while watching a programme. Press **Stop** button to cancel instant recording.

You can not switch broadcasts during the recording mode. While switching a programme or during the timeshifting, a warning message appears on the screen if your USB device speed is not sufficient.

### Watching Recorded Programmes

Select **Recordings** from the **TV** menu. Select a recorded item from the list (if previously record), Press the **OK** button to view the **Options** menu. Select an option then press **OK** button.

Note: Viewing main menu and items will not be available during the playback.

Press the **Stop** button to stop a playback and return to the **Recordings**.

### Slow Forward

If you press **Pause** button while watching recorded programmes, the slow forward feature will be available. You can use **Fast Forward** button to slow forward. Pressing **Fast Forward** button consecutively will change slow forward/browsing speed.

### Recording Settings

You can configure your recording preferences using the **Settings** tab in the **TV>Recordings** menu. Highlight **Settings** tab by using **Left** or **Right** button and press **OK**. Then select the desired item in the sub-menu and end by using **Left** or **Right** button.

**Start early:** You can set recording timer's starting time to start earlier by using this setting.

**End late:** You can set recording timer's end time to end later by using this setting.

**Max Timeshift:** This setting allows you to set the maximum duration for the timeshift recording. Available options are approximate and the actual recording time may change in practice depending on the broadcast. The reserved and free storage space values will change according to this setting. Make sure that you have enough free space otherwise instant recording may not be possible.

**Auto discard:** You can set the **Discard type** as **None**, **Oleat**, **Longest** or **Shortest**. If it is not set to **None** you can set the **Unplayed** option as **Included** or **Excluded**. These options determine the preferences for deleting the recordings in order to obtain more storage space for ongoing records.

**Hard disk information:** You can view detailed information about the USB storage device connected to your TV. Highlight and press **OK** to see and press **Back/Return** to close.

**Format Disk:** If you want to delete all files on the connected USB storage device and convert the disk format to FAT32, you can use this option. Press **OK**

button while the **Format Disk** option is highlighted. A menu will appear on the screen requiring you to enter the PIN#). After you enter the PIN, a confirmation message will be displayed. Select **Yes** and press **OK** to start formating the USB storage device. Select **No** and press **OK** to cancel.

(<sup>1</sup> Default PIN could have been set to 0000 or 1234. If you have defined the PIN (is requested depending on the country selection) during the **First Time Installation** use the PIN that you have defined.)

**IMPORTANT:** Formatting your USB drive will erase ALL the data on it and it's system will be converted to FAT32. In most cases operation will be fixed after a format but you will lose ALL your data.

If **"USB disk writing speed too slow to record"** message is displayed on the screen, while starting a recording, try restarting the recording. If you still get the same error, it is possible that your USB disk does not meet the speed requirements. Try connecting another USB disk.

### Media Browser

You can play back music and movie files and display photo files stored on a USB storage device by connecting it to your TV. Connect a USB storage device to one of the USB inputs located on the side of the TV. After connecting a USB storage device to your TV, the **Sources** bar will be displayed with USB highlighted. Press **OK**, **Media Browser** menu will be displayed on the screen. Select either of your choices and press **OK** to display or play back. You can access the content of the connected USB device any time later from the **Sources** menu. You can also press the **Source** button on the remote and then select your USB storage device from the list of sources.

You can set your media browser preferences by using the **Settings** menu. **Settings** menu can be accessed via the **Information** bar, which is displayed on the bottom of the screen while playing back a video or an audio file or displaying a picture file. Press the **Info** button if the information bar has disappeared, highlight the gear wheel symbol positioned on the right side of the information bar and press **OK**. **Picture Settings**, **Sound Settings**, **Media Browser Settings** and **Options** menus may be available depending on the media file type and the model of your TV and its features. The content of the menus may also differ according to the type of the currently open media file. Only **Sound Settings** menu will be available while playing back audio files.

**(<sup>1</sup> Images should be in jpg file formats. Only files with sizes no greater than 1MB are supported. FollowMe TV**

With your mobile device you can stream the current broadcast from your smart TV using the **FollowMe TV** feature. Install the appropriate Smart Center application to your mobile device. Start the application. For further information on using this feature refer to the instructions of the application you use.

**Note:** Depending on model, your TV may not support this function. The application may not be compatible with all mobile devices. **UHD(4K, Ultra HD)** channels are not supported and both of the devices must be connected to the same network.

## Loop/Shuffle Mode Operation

Start playback and activate <b>□</b>	All files in the lis will be continuously played in order
Start playback and activate <b>□</b>	The same file will be played continuously (repeat)
Start playback and activate <b>□</b>	All files in the lis will be played once in random order

Tools on the screen information bar highlight the symbol of the function and press **OK**. To change the status of a function/highlight the symbol of the function and press **OK** as much as needed. If the symbol is marked with a red cross, that means it is deactivated.

### Custom Boot Up Logo

You can personalise your TV and see your favourite image or photo on the screen each time your TV boots up. To do this, copy your favourite image files into a USB disk and open them in the **Media Browser**. Select **USB** input from the **Sources** menu and press **OK**. When you have chosen the desired image, highlight it and press **OK** to view it in full screen. Press the **Info** button, highlight the gear wheel symbol on the information bar and press **OK**. Select **Options** and press **OK** to enter. Set **Boot Logo** option will be available. Highlight it and press **OK** again to choose the image as custom boot logo. A confirmation message will be displayed. Select **Yes** and press **OK** again if the image is suitable (<sup>1</sup>). You will see it on the screen during the TV's next boot up.

**Notes:** You can use the **Restore Default Boot Logo** option in the **Settings>System>Management** to restore the boot logo if the image is suitable (<sup>1</sup>) or perform **First Time Installation** the boot logo will be restored to its default.

**English** - 16 -

## Settings Menu Content

<b>CEC</b>	This function allows to control the CEC-enabled devices, that are connected through HDMI ports by using the remote control of the TV. The <b>CEC</b> option in the <b>Settings&gt;Devices</b> menu should be set as <b>Enabled</b> at first. Press the <b>Source</b> button and select the <b>HDMI</b> input or the connected CEC device from the <b>Sources List</b> menu. When new CEC source device is connected, it will be listed in source menu with its own name instead of the connected HDMI port's name such as <b>DVD Player</b> , <b>Recorder 1</b> etc.). The TV remote is automatically able to perform the main functions after the connected HDMI source has been selected. To terminate this operation and control the TV via the remote again, press and hold the <b>Zero/c</b> button on the remote control for 3 seconds. This feature is an audio link meant to replace other cables between the TV and an audio system (A/V receiver or speaker system). When ARC is active, the TV will mute its other audio outlets except the headphone jack, automatically and volume control buttons are directed to connected audio device. To activate ARC set the <b>Sound Output</b> option in the <b>Settings&gt;Sound</b> menu as <b>HDMI ARC</b> . <b>Note:</b> ARC is supported only via the <b>HDMI2</b> input.	<b>Battery Menu Content</b> Set your Power Mode preference. <b>Normal</b> , <b>Eco</b> and <b>Eco Plus</b> options are available. If the power adapter is connected, TV will operate as if in normal mode without any restriction. <b>Normal</b> : TV will operate without any restriction. <b>Eco</b> : The backlight level will be set to 12 (72um). <b>Eco Plus</b> : The backlight level will be set to 0 (50um) and the volume level value will be limited to a maximum of 50.  <b>Remaining Charge</b> Displays the TV's battery life remaining.
<b>Devices Menu Content</b>	<b>Audio Link</b> Press <b>OK</b> to open the Audio Link menu screen. Using this screen you can discover and connect the sound devices to your TV wirelessly.  <b>Input Device</b> Press <b>OK</b> to open the Input Device menu screen. Using this screen you can discover and connect keyboards and mice to your TV wirelessly.  <b>Virtual Remote</b> Note: You TV may not be compatible with all keyboard and mouse models in the market. For more information contact your local dealer or visit our website where you bought your TV.  <b>Audio Video Sharing</b> Enable or disable the virtual remote feature.  <b>Timer of No Signal</b> This feature allows you to share files stored on your smartphone or tablet pc. If you have a compatible smartphone or tablet pc and the appropriate software is installed, you can share/paly photos on your TV. See instructions of your sharing software for more information.  <b>CEC</b> With this setting you can enable and disable CEC functionality completely. Press <b>Left</b> or <b>Right</b> button to enable or disable the feature.  <b>CEC Auto Power On</b> This function allows the connected HDMI/CEC compatible device to turn on the TV and switch to its input source automatically. Press <b>Left</b> or <b>Right</b> button to enable or disable the feature.	
<b>Picture Menu Content</b>	<b>Mode</b> You can change the picture mode to suit your preference or requirements. Picture mode can be set to one of these options: <b>Cinema</b> , <b>Gaming</b> (optional), <b>Sports</b> , <b>Drama</b> and <b>Natural</b> .  <b>Contrast</b> Adjusts the light and dark values on the screen.  <b>Brightness</b> Adjusts the brightness values on the screen.  <b>Sharpness</b> Sets the sharpness value for the objects displayed on the screen.  <b>Colour</b> Sets the colour value, adjusting the colours.  <b>Energy Saving</b> For setting the <b>Energy Saving</b> to <b>Custom</b> , <b>Minimum</b> , <b>Medium</b> , <b>Maximum</b> , <b>Auto</b> , <b>Screen Off</b> , or <b>None</b> . Available options may differ depending on the selected <b>Mode</b> .  <b>Backlight</b> This setting controls the backlight level. The backlight function will be inactive if the <b>Energy Saving</b> is set to an option other than <b>Custom</b> .  <b>Picture Zoom</b> Select the desired image size format.  <b>Picture Shift</b> This option may be available depending on the <b>Picture Zoom</b> setting. Highlight and press <b>OK</b> , then use directional buttons to shift the picture upwards or downwards.  <b>PC Position</b> Appears only when the input source is set to <b>VGA/PC</b> .  <b>Autoposition</b> <b>Note:</b> If the image is not centred in VGA mode use this option to automatically adjust the position of the image. Press <b>OK</b> to start the auto adjustment.	

Sound Menu Content	
H Position	This item shifts the image horizontally to the right hand side or left hand side of the screen.
V Position	This item shifts the image vertically towards the top or bottom of the screen.
Dot Clock	Dot Clock adjustments correct the interference that appear as vertical banding in dot intensive presentations like spreadsheets or paragraphs or text in smaller fonts.
Phase	Depending on the input source/computer etc. you may see a hazy or noisy picture on the screen. You can use phase to get a clearer picture by trial and error.
Advanced Settings	
Dynamic Contrast	You can change the dynamic contrast ratio to desired value.
Colour Temp	Sets the desired colour temperature value. Cool, Normal, Warm and Custom options are available.
White Point	If the Colour Temp option is set as Custom, this setting will be available. Increases the warmth or coolness of the picture by pressing Left or Right buttons.
Blue Stretch	White colour enhancement function that makes white colour more cooler in order to make more bright picture. Set as On or Off enable.
Micro Dimming	Low, Medium, High and Off options are available. While Micro Dimming is active, it will enhance contrast locally for each defined zone.
Noise Reduction	Low, Medium, High and Off options are available. If the signal is weak and the picture is noisy, use the Noise Reduction setting to reduce the amount of noise.
Film Mode	Films are recorded at a different number of frames per second in normal television programmes. Turn this feature on when you are watching films to see the fast motion scenes clearly.
Skin Tone	Skin tone can be changed between -5 and 5.
Colour Shift	Adjust the desired colour tone.
Colour Tuner	Opens colour tuner settings. Set the Colour Tuner as enabled to adjust the Hue, Colour and Brightness values manually.
Gamut Mapping	You can use this option to set the range of colours displayed on your TV screen. When set as On, colours are set according to the source signal. When set as Off, the TV's maximum colour capacity is used by default (recommended option). Note: This option may not be available depending on the TV model and its features.
HDMI Full Range	While watching from a HDMI source, this feature will be visible. You can use this feature to enhance blackness in the picture.
Reset	Resets the picture settings to factory default settings (except Game mode). While in VGA (PC) mode, some items in Picture menu will be unavailable. Instead, VGA mode settings will be adopted to the Picture menu while in PC mode.

Dolby Audio	Smart, Movie, Music, News and Off options will be available. Set as Off to disable. Note: Some items in Sound menu will be grayed out and unavailable if set to an option other than Off.
Surround Sound	Surround Sound mode can be changed as On or Off.
Audio Link	Press OK to open the Audio Link menu screen. Using this screen you can discover and connect the sound devices to your TV wirelessly.
Sound Output	Sets the source output preference. TV, SPDIF, HDMI ARC, Headphone Only and Lineout options will be available. There will be no sound output except through the selected option and the headphone jack.
AVL (Automatic Volume Limiting)	When you connect an external amplifier to your TV using the headphone jack, you can select this option as Lineout. If you have connected headphones to the TV, set this option as Headphone Only. Please ensure before using headphones that this menu item is set to Headphone Only. If it is set to Lineout, the output from the headphone socket will be set to maximum which could damage your hearing.
Advanced Settings	If HDMI ARC option is selected, CEC Feature will be enabled. Note: Disenabling an selected option some items in Sound menu will appear as grayed out and will be unavailable.
Equalizer	Sets the sound to obtain fixed output level between programmes.
Dynamic Bass	If the Dolby audio menu item is set to an option other than Off, the AVL setting options will change. Auto, Night, Normal and Off modes will be available. In Auto mode the TV will switch to Normal or Night mode automatically according to the current time information. Info line information is available this option will always function as Normal. When the TV switches to Night mode for the first time after setting this option as Auto.
Sound Mode	Please note that compared to Normal mode, Night mode provides more aggressive dynamic compression control which is suitable for silent environments.
Digital Out	Sets digital out audio type.
Headphone	Sets headphone volume. This option will not be available if the Sound Output option is set as Lineout. Please ensure before using headphones that the headphone volume is set to a low level, to prevent damage to your hearing.
Reset	Resets some of the sound settings to factory defaults.

<b>Network Menu Content</b>	Disable the network connection or change the connection type.
<b>Network Type</b>	Start a search for wireless networks. This option will be available if the <b>Network Type</b> is set as <b>Wireless Device</b> .
<b>Scan Wireless Networks</b>	Disconnect from a wireless network and delete your saved wireless network profile (if previously saved), highlight this option and press <b>OK</b> . This option will not be available if you did not connect to a wireless network. Refer to <b>Connectivity</b> section for more information.
<b>Disconnect</b>	Press <b>WPS</b> on your <b>wifi router</b> Highlight this option and press <b>OK</b> . Go to your modem/router device and press the <b>WPS</b> button on it to make the connection. This option will be available if the <b>Network Type</b> is set as <b>Wireless Device</b> .
<b>Internet Speed Test</b>	Start a speed test to check your connection bandwidth. The result will be displayed on the screen.
<b>Advanced Settings</b>	Change the IP and DNS configurations of your TV.
<b>Networked Standby Mode</b>	Enable or disable this feature by setting it as <b>On or Off</b>
<i>Note:</i> For detailed information on the options of this menu refer to the <b>Connectivity</b> section.	
<b>Installation Menu Content</b>	Disable automatic tuning options. <b>D. Aerial:</b> Searches and stores aerial DVB stations. <b>D. Cable:</b> Searches and stores cable DVB stations. <b>Analogue Searches</b> and stores analogue stations. <b>Satellite:</b> Searches and stores satellite stations.
<b>Automatic channel scan (Retune)</b>	This feature can be used for direct broadcast entry.
<b>Manual channel scan</b>	Searches for the linked channels in the broadcast system. <b>D. Aerial:</b> Searches for aerial network channels. <b>D. Cable:</b> Searches for cable network channels. <b>Satellite:</b> Searches for satellite network channels.
<b>Network channel scan</b>	You can use this setting for fine tuning a analogue channels. This feature is not available if no analogue channels are stored and it currently watched channel is not an analogue channel.
<b>Analogue fine tune</b>	Displays satellite settings. <b>Satellite list:</b> Displays available satellites. You can <b>Add</b> <b>Delete</b> satellites or <b>Edit</b> satellite settings on the list. <b>Antenna Installation:</b> You can change a satellite antenna settings and/or start a satellite scan...
<b>Satellite Settings (optional)</b>	Displays installation settings menu. <b>Standby Mode Search (*):</b> Your TV will search for new or missing channels while in standby. Any new found broadcasts will be shown. <b>Dynamic Channel Update(*)</b> : If this option is set as Enabled, the changes on the broadcasts such as frequency, channel name, subtitle language etc., will be applied automatically while watching. <small>(* Availability depends on model)</small>
<b>Installation Settings (optional)</b>	Use this setting to clear channels stored. This setting is visible only when the <b>Country</b> option is set to Denmark, Sweden, Norway or Finland.
<b>Clear Service List</b>	This setting allows you to select only the broadcasts within the selected network to be listed in the channel list. This feature is only for the country option of Norway.
<b>Select Active Network</b>	You can use this menu item to monitor signal related information such as signal level/ frequency, network name etc for available frequencies.
<b>Signal Information</b>	Deletes all stored channels and settings, results TV to factory settings.
<b>Firsttime installation</b>	Deletes all stored channels and settings, results TV to factory settings.

<b>System Menu Content</b>	Displays accessibility options of the TV.
<b>Accessibility</b>	Increase the contrast of the menu options and texts to make them easier to read. <b>White Text, Yellow Text and Off</b> will be available.
<b>High Contrast</b>	Enables any special feature sent from the broadcaster.
<b>Hard of Hearing</b>	A narration track will be played for the blind or visually impaired audience. Press <b>OK</b> to see all available <b>Audio Description</b> menu options. This feature is available only if the broadcaster supports it. <small>Note: Audio Description source feature is not available in recording or time shifting mode.</small>
<b>Audio Description</b>	This feature provides sound post-processing options for speech-based dialogue enhancement. <b>Off, Low, Medium</b> and <b>High</b> options will be available. Set according your preference. <small>Note: This feature has an effect only if audio formats AC-3 and DTS effect only applies to TV/sound output.</small>
<b>Dialogue Enhancement</b>	Default preference of spoken subtitles is selected with this setting option. To make spoken subtitles priority higher than normal ones, this option should be set to <b>On</b> .
<b>Spoken Subtitles</b>	This option may not be available depending on the model of your TV and is only visible when the source is set to <b>TV</b> .
<b>Magnification</b>	Enables the use of button combinations to magnify the screen. <b>On</b> and <b>Off</b> options will be available. Set to <b>On</b> to enable.
<b>Minimap</b>	Magnification support will be enabled or disabled with long-press of the numeric button 5. First top-left quadrant of the screen will be zoomed. After the magnification support is enabled, long-press of the numeric buttons 2, 4, 6, 8 will move the zoomed area to up, left, right and down.
<b>Click Sound</b>	Minimap is enabled and deactivated by default. It will be activated when <b>Magnification</b> feature is enabled. With this option, you can prevent magnification feature from displaying the minimap.
<b>Highlight programmes</b>	This option enables the key click sound on TV menu. Set to <b>On</b> to enable.
<b>[S] Subtitle</b>	If this option is enabled and if any electronic programme guide event has "Subtitle" access service, this events will be highlighted with another colour.
<b>[SL] Sign Language</b>	If this option is enabled and if any electronic programme guide event has "Sign Language" access service, this events will be highlighted with another colour.
<b>[AD] Audio Description</b>	If this option is enabled and if any electronic programme guide event has "Audio Description" access service, this events will be highlighted with another colour.
<b>Language</b>	You may set a different language depending on the broadcasters and the country.
<b>Conditional Access</b>	Controls conditional access modules when available.
<b>Privacy</b>	Manage your privacy privileges for smart TV related applications. Press <b>OK</b> to enter the menu and set according to your preferences.
<b>Privacy Settings</b>	Manage your privacy privileges for smart TV related applications. Press <b>OK</b> to enter the menu and set according to your preferences.
<b>Show All Cookies</b>	Displays all saved cookies.
<b>Delete All Cookies</b>	Deletes all saved cookies.
<b>Do Not Track</b>	You can set your preference regarding the tracking behaviour for HbbTV services using this option.

<b>Parental</b>	Enter correct password to change parental settings. You can easily adjust <b>Menu Lock</b> , <b>Maturity Lock</b> , <b>Child Lock</b> or <b>Guidance</b> in the menu. You can also set a new <b>PIN</b> or change the <b>Default CICAM PIN</b> using the related options.	<b>Google Assistant</b>	Starts the setup process to enable your TV to work with Google Assistant devices. Highlight <b>Start</b> and press <b>OK</b> . If the setup is priority completed <b>Sign Out</b> option will be available. You sign out <b>Google Assistant</b> feature will be disabled. Refer to <b>Google Assistant</b> section for more information.
<b>Date/Time</b>	Installation. Default PIN could have been set to 0000 or 1234. If you have entered the PIN required on the country selection during the <b>First Time Installation</b> use the PIN that you have defined.	<b>More</b>	Displays other setting options of the TV.
<b>Sources</b>	Set date and time.	<b>Menu Timeout</b>	Changes timeout duration for menu screens.
<b>Netflix</b>	Edit the names, enable or disable selected source options.	<b>Standby Mode</b>	If set as <b>Off</b> the standby mode LED will not light up when the TV is in standby mode.
	If this feature is supported by your TV, you can view your ESN(*) number and deactivate Netflix.	<b>Software Upgrade</b>	Ensures that your TV has the latest firmware. Press <b>OK</b> to see the menu options.
	(*) ESN number is a unique ID number for Netflix, created especially to identify your TV.	<b>Application Version</b>	Displays current software version.
<b>Samba ACR</b>	Samba, interactive TV powers recommendations and other apps by gathering data regarding consumption of specific screen content to enhance your viewing experience. Using this option you can access Samba interactive TV's settings menu, review Samba TV's Terms of Service, Privacy Policy and manage your advertising preferences, etc. Internet connection will be required in order to access HTML based settings. You can enable or disable interactive TV and avail from the <b>Settings-&gt;System&gt;Privacy&gt;Privacy Settings</b> menu by checking or unchecking the check box next to the related item. This option may not be available depending on the selected country during the First Time Installation process, model of your TV and its features.	<b>Auto Power Down</b>	Sets the desired time for the TV to automatically go into standby mode when not being operated. This option can be set from 1 to 8 hours in steps of 1 hour. You can also disable this option by setting <b>Off</b> .
<b>Device Settings</b>		<b>Subtitle Mode</b>	This option is used to select which subtitle mode will be on the screen (DVB subtitle / Teletext) if both is available. Default value is <b>DVB</b> subtitle. This feature is available only for the country option of Norway.
<b>CEC</b>	With this setting you can enable and disable CEC functionality completely. Press <b>Left</b> or <b>Right</b> button to enable or disable the feature.	<b>Bliss Key</b>	This is a satellite signal broadcasting system that is used for some broadcasts. If you need to enter Bliss keys on the desired broadcast, you can use this setting. Highlight <b>Bliss Key</b> and press <b>OK</b> to enter keys on the desired broadcast.
<b>CEC Auto Power On</b>	This function allows the connected HDMI-CEC compatible device to turn on the TV and switch to its input source automatically. Press <b>Left</b> or <b>Right</b> button to enable or disable the feature.	<b>Store Mode</b>	Select this mode for store display purposes. Whilst <b>Store Mode</b> is enabled, some items in the TV menu may not be available.
<b>Input Device</b>	Press <b>OK</b> to open the Input Device menu screen. Using this screen you can discover and connect keyboards and mice to your TV wirelessly. Your TV may not be compatible with keyboard and mouse models in the market. For more information contact your local dealer or retail outlet where you bought your TV.	<b>Audio Video Sharing</b>	This feature allows you to share files stored on your smartphone or tablet pc. If you have a compatible smartphone or tablet pc and the appropriate software is installed, you can share/paly photo or video on your TV. See instructions of your sharing software for more information.
<b>No Signal Timer</b>	If your TV does not receive any input signal (e.g. from an aerial or HDMI source) for 3 minutes, it will go into standby mode. You can enable or disable this functionality by setting this option accordingly.	<b>Power Up Mode</b>	This setting configures the power up mode preference. <b>Last State and Standby Mode</b> options are available.
<b>Voice Assistant</b>	Starts the setup process for this feature manually. If the setup is priority completed <b>Alexa Language</b> , <b>Alexa On Standby Mode</b> , <b>Alexa Alarm Volume</b> and <b>Sign Out</b> options will be available. Refer to <b>Alexa Ready</b> section for more information.	<b>Virtual Remote</b>	Enable or disable the virtual remote feature.
<b>Alexa Built-in</b>	Alexa sets the language preference for Alexa.	<b>OSS</b>	Displays Open Source Software & license information.
<b>Alexa Language</b>	Enables or disables Alexa On Standby Mode feature. If enabled Alexa will be available while the TV is in standby mode. <small>Note: This feature may affect your TV's power/consumption.</small>	<b>Application Priority</b>	You can set your preference regarding the priority between the broadcast applications and CICAM (MMMI) applications using this option. In case a CICAM is inserted into the TV and a contention occurs between the applications the priority will be given to the selected type of application.
	Set as <b>Off</b> to disable this feature or choose one of the inactivity periods to enable 15 min, 30 min, 1 hour and 2 hour options will be available.		<small>Note: Some options may not be available depending on the model of your TV and the selected country in the First Time Installation.</small>
<b>Alexa Home Screen</b>	Sets the volume level for Alexa alarms.		
<b>Alexa Alarm Volume</b>	You can use this option to sign out. If you sign out Alexa Built-in feature will be disabled.		
<b>Sign Out</b>	Starts the setup process for this feature manually. If the setup is priority completed <b>Sign Out</b> option will be available. Refer to <b>Alexa Ready</b> section for more information.		
<b>Works With Alexa</b>	You can use this option to sign out. If you sign out Works With Alexa feature will be disabled.		
<b>Sign Out</b>			

## General TV Operation

### Using the Channel List

**Child Lock:** If this option is set to **On**, the TV can only be controlled by the remote control. In this case the control buttons on the TV will not work.

**Internet Lock:** If this option is set to **ON**, the internet using applications will be disabled. Set to **OFF** to release these applications again.

**Set PIN:** Defines a new PIN number.

**Default/CAM PIN:** This option will appear as greyed out if no CI module is inserted into the CI slot of the CI CAM using this option.

**Note:** Default PIN could have been set to **0000** or **1234**. If you have defined the PINs requested depending on the country selection during the **First Time Installation** use the PIN that you have defined. In case the PIN is entered incorrectly the times in succession, PIN entry will be blocked and it will no longer be possible to make a selection for 30 minutes. However, you can release the PIN entry or reset the entry count to zero by turning the TV off and on again.

Some options may not be available depending on the model and/or on the country selection in the **First Time Installation**.

### Electronic Programme Guide

By means of electronic programme guide function of your TV you can browse the event schedule of the currently installed channels on your channel list. It depends on the related broadcast whether this function is supported or not.

To access the programme guide, press the **Guide** button on your remote. You can also use the **Guide** option under TV menu.

There are 2 different types of schedule layouts available, **Timeline Schedule** and **New/Next**. To switch between these layouts highlight the tab with the name of the alternative layout on the upper side of the screen and press **OK**.

Use the directional buttons to navigate through the programme guide. Use the **Back/Return** button to switch back to the previous screen. To use the tabs options on the upper side of the screen.

### Timeline Schedule

In this layout option, all events of the listed channels will be displayed by timeline. You can use the directional buttons to scroll through the list of the events. Highlight an event and press **OK** to display event options menu.

Press **Back/Return** button to use available tab options. Highlight **Filter** tab and press **OK** to see the filtering options. To change the layout highlight **New/Next** and press **OK**. You can use the **Previous Day** and **Next Day** options to display the events of the previous and next day.

Highlight **Extras** tab and press **OK** to access below highlights.

**Highlight Genre:** Displays **Highlight Genre** menu. Select a genre and press **OK**. The events in the programme guide matching the selected genre will be highlighted.

**Guide Search:** Displays searching options. Using these options, you can search the programme guide database in accordance with the selected criteria. Matching results will be listed.

**Now:** Displays current event of the highlighted channel.

**Zoom:** Highlight and press **OK** to see events in a wider time interval.

### Now/Next Schedule

In this layout option, only the current and next events of the listed channel will be displayed. You can use the directional buttons to scroll through the list of the events.

Press **Back/Return** button to use available tab options. Highlight **Filter** tab and press **OK** to see the filtering options. To change the layout highlight **Timeline Schedule** and press **OK**.

### Event Options

Use the directional buttons to highlight an event and press **OK** button to display **Options** menu. The following options are available:

### Select Channel

Using this option, you can switch to the selected channel in order to watch it. The programme guide will be closed.

### More Info:

Display detailed information on the selected event. Use up and down directional buttons to scroll through the text.

### Record

**Record / Delete Rec. Timer:** Select **Record** event and press the **OK** button if the event is going to be broadcast at a future time. It will be added to **Timers** list to be recorded. To cancel an already set timer, highlight that event and press the **OK** button. Then select **Delete Timer on Event** option. The timer will be cancelled.

### Delete

**Record / Delete Rec. Timer:** Select **Record** event and press the **OK** button. The record timer will be cancelled. **IMPORTANT:** Connect a USB disk to your TV while the TV is switched off. You should then switch on the TV to enable the recording feature.

### Notes:

You cannot switch to another channel while there is an active recording or timer on the current channel. It is not possible to set timer or record timer to two or more individual events at the same time interval.

### Teletext Services

Press the **Text** button to enter. Press again to activate mix mode. This allows you to see the teletext page and the TV broadcast at the same time. Press once more to exit. If available, at the sections in the teletext pages will become colour-coded and can be selected by

pressing the coloured buttons. Follow the instructions displayed on the screen.

### Digital Teletext

Press the **Text** button to view digital teletext information. Operate it with the coloured buttons, cursor buttons and the **OK** button. The operation method may differ depending on the content of the digital teletext. Follow the instructions displayed on the digital teletext screen. When the **Text** button is pressed again, the TV returns to television broadcast.

### Software Upgrade

Your TV is capable of finding and updating the firmware automatically via the broadcast signal or via Internet.

### Software upgrade search via user interface

On the main menu select **Settings**, then navigate to **Software Upgrade** and press the **OK** button. Then select **Search for upgrade** and press **OK** button to check for a new software upgrade. The **Software Upgrade** option is also available in the **Settings>System>More** menu.

If a new upgrade is found, it starts to download the upgrade. After the download is completed, a warning will be displayed press **OK** button to complete software upgrade process and restart TV.

### 3D search and upgrade mode

Your TV will search for new upgrades at 3:00 o'clock

if automatic scanning option is set to Enabled and if TV is connected to an aerial signal or to Internet. If a new software is found and downloaded successfully, it will be installed at the next power on.

**Note:** Make sure that the power adaptor is connected to prevent the TV to turn off while the standby LED is blinking during the reboot process. If the TV fails to come on after the upgrade, unplug wait for two minutes then plug it back in.

All updates are automatically controlled. If a manual search is carried out and no software is found then this is the current version.

### Troubleshooting & Tips

### TV will not turn on

Check if the main power switch on the rear side of the TV is turned on.

Made sure that either the power adaptor is connected or that there is enough battery power. Press the **Standby** button on the remote.

### Poor picture

• Check if you have correctly tuned the TV.

### Lows signal level can cause picture distortion. Please signalevel connection.

• Check if you have entered the correct channel frequency if you have performed manual tuning.

**No picture**

- TV is not receiving any signal. Make sure the correct source has been selected.
- Is the antenna connected properly?
- Is the antenna cable damaged?
- Are suitable plugs used to connect the antenna?
- If you are in doubt, consult your dealer.

**No sound**

- Check if the TV sound is muted. Press the **Mute** button or increase the volume to check.
- Sound may be coming from only one speaker. Check the balance settings from Sound menu.
- Remote control - no operation**
- The batteries may be exhausted. Replace the batteries.
- The batteries maybe inserted incorrectly. Refer to the section "Inserting the Batteries into the Remote".

**No signal on an input source**

- It is possible that no device is connected.
- Check the AV cables and connections from your device.
- Check if the device is switched on.

**The Image is not centered in VGA source**

To have your TV automatically center the image, enter the **PC Position** menu in **Picture** menu, highlight **AutoPosition** and press **OK**. Wait for it to finish, in order to set the position of the image manually you can use **H Position** and **V Position** options. Select the desired option and use Left and Right directional buttons on the remote to set.

**PC Input Typical Display Modes**

The following table is an illustration of some of the typical video display modes. Your TV may not support all resolutions.

Index	Resolution	Frequency
1	640x480	60Hz
2	640x480	75Hz
3	800x600	56Hz
4	800x600	60Hz
5	800x600	72Hz
6	800x600	75Hz
7	1024x768	60Hz
8	1024x768	70Hz
9	1024x768	75Hz
10	1152x896	75Hz
11	1280x896	60Hz
12	1366x768	60Hz
13	1280x896	60Hz

**Supported File Formats for USB Mode****Video File Formats**

Max. Resolution & Frame Rate / Bit Rate		
Extension	Video Codec	
.mpg, .mpeg, .dat, .vob .ts, .tp, .m2ts .avi	MPEG1/2, H.264, VC1 MPEG1/2, MPEG4, H.264 MPEG1/2, H.265, MPEG4, H.264	
.3gp, .3gpp		
.m4v		
.flv		
.asf, .wmv	Sorenson Sp, MPEG4, H.264	
.webm	MPEG4, WMV3, VC1	
	Vp8, Vp9	

**Picture File Formats**

Resolution (width x height)		
Extension	Specification	
.jpg, .jpeg	Baseline	8192 x 8192
.bmp	RGB / 14/8/16/24/32 bit	3000 x 3000
	RLI / E / 8 / bil	
	Grayscale, 24/32 bit per pixel	
	JPEG2000	
	Interlace format	
	Progressive	

**Audio File Formats**

Format	
Extension	
.mp3	
.ac3	
.aac	AAC
.wma	WMA
.amr	AMR-NB, AMR-WB
.wav	MPEG Lt, AAC, PCM

(X: Not Available, O: Available)

In some cases a signal on the TV may not be displayed properly. The problem may be an inconsistency with standards from the source equipment (DVD, Set-top box, etc.). If you do experience such a problem please contact your dealer and also the manufacturer of the source equipment.

## Subtitle File Formats

External Subtitles	Specification
.ssa	Sub Station Alpha
.ass	Advanced Sub Station Alpha
.sit	Subripper
.sub	Micro DVD / SubViewer
sub + .idx	VOBSub
.txt	Micro DVD / TMPPlayer / MPL2
.mp1	MPL2
.smi	Sami
.jss	JACOSUB
.ttml	TIML
.xml / .sub	DVDSUBTITLE
.lrc	.

## Internal Subtitles

Extension	Specification
.mkv	VOBSub
.mkv	ASS / SSA / TEXT
.dat, .mpg, .mpeg, .vob	DVD Subtitle
.m4	DIV Subtitle; TEXT

## Supported DVI Resolutions

When connecting devices to your TV's connectors by using DVI converter cable(DVI to HDMI cable - not supplied), you can refer to the following resolution information.

	56Hz	60Hz	66Hz	76Hz	70Hz	72Hz	75Hz
640x400	x			x			
640x800	x	x	x	x	x	x	x
800x600	x				x		
832x624					x		
1024x768		x	x	x	x	x	x
1152x864		x		x	x	x	x
1152x720				x	x	x	x
1280x768	x				x		
1360x768	x				x		
1280x800	x				x		
1280x1024	x				x		
1400x900	x				x		
1440x900	x				x		
1600x1200	x				x		
1880x1050	x				x		
1920x1080	x				x		

## Internet Speed Test

Highlight **Internet Speed Test** and press the **OK** button. TV will check the Internet connection bandwidth and display the result when complete.

### Advanced Settings

Highlight **Advanced Settings** and press the **OK** button. On the next screen you can change the IP and DNS settings of the TV. Highlight the desired one and press Left or Right button to change the setting from **Automatic to Manual**. Now you can enter the IP and / or DNS values manually. Select the related item in the drop down menu and enter the new values using the numeric buttons of the remote. Highlight **Save** and press the **OK** button to save settings when complete.

### Wireless Connectivity

#### To Connect to a Wireless Network

The TV cannot connect to the networks with a hidden SSID. To make your modem's SSID visible, you should change your SSID settings via the modem's software.



### 1. Broadband ISP connection


- A Wireless-N router (IEEE 802.11ab/g/n) with simultaneous 2.4- and 5 GHz bands is designed to increase bandwidth. These are optimized for smoother and faster HD video streaming, file transfers and wireless gaming.
- The frequency and channel differ depending on the area.
- The transmission speed differs depending on the distance and number of obstructions between the transmission products. The configuration of these products, the radio wave conditions, the line traffic and the products that you use, the transmission may also be cut off or may get disconnected depending on the radio wave conditions, DECT phones or any other WLAN 11b appliances. The standard values of the transmission speed are the theoretical maximum values for the wireless standards. They are not the actual speeds of data transmission.

## Connectivity

### Wired Connectivity


#### To Connect to a Wired Network

- You must have a modem/router connected to an active broadband connection.
- Connect your TV to your modem/router via an Ethernet cable. There is a LAN port at the rear (back) of your TV.



### 1. Broadband ISP connection

- LAN input on the rear side of the TV
- LAN input on the rear side of the TV
- LAN input on the rear side of the TV



### 1. Network wall socket

#### Configuring Wired Device Settings

##### Network Type

The **Network Type** can be selected as **Wired Device**, **Wireless Device** or **Disabled**. In accordance with the active connection to the TV set, Select this as **Wired Device** if you are connecting via an Ethernet cable.

- The location where the transmission is most effective differs depending on the usage environment.

The Wireless feature of the TV supports IEEE 802.11 a/b/g & n type models. It is highly recommended that you should use the IEEE 802.11n communication protocol in order to avoid any possible problems while watching videos.

You must change your modem's SSID when there are any other modems around with the same SSID. You can encounter connection problems otherwise. Use a wired connection if you experience problems with a wireless connection.

#### Configuring Wireless Device Settings

Open the Network menu and select **Network Type as Wireless Device** to start connection process.

Highlight **Scan Wireless Networks** option and press OK to start a search for available wireless networks. All found networks will be listed. Highly if you desired network from the list, and press OK to connect. A network with hidden SSID can not be detected by other devices. If you want to connect to a network with hidden SSID, scroll down to the list of selected wireless networks, highlight the **Add New Network** option and press OK. Enter the name of the network and select the security type using the related options to connect.

**Note:** If the modem supports N mode, you should set N mode settings.

If the selected network is password-protected, enter the correct key by using the initial keyboard and the OK button via the directional buttons and the OK button on the remote control.

Wait until the IP address is shown on the screen. This means that the connection is now established. To disconnect from a wireless network, highlight **Network Type** and press Left or Right buttons to set as **Disabled**.

If you have connected to a wireless network **Disconnect** option will appear in the **Network** menu and your wireless network profile will also be saved, thus your TV will connect to the same network automatically whenever you switch to wireless connection. To disconnect from a wireless network and delete the saved wireless network profile, highlight **Disconnect** and press OK.

If your router has WPS, you can directly connect to the modem/router without entering a password or adding the network first. Highlight **Press your wifi router** option and press OK. Goto your modem/router device and press the WPS button on it to make the connection. You will see a connection confirmation on your TV once the devices have paired. Select OK to proceed. If further configuration is required.

Highlight **Internet Speed Test** and press the OK button to check your internet connection speed. Highlight **OK**

does not apply, when the TV is switched into the standby mode.

The performance of some devices in the market, may vary due to the software architecture. In order to use Networked Standby Mode feature with a better performance, please make sure that your device has latest firmware version.

If you want your TV to consume less power in standby mode, you can disable this feature by setting the **Networked Standby Mode** option as **Off**.

#### Wireless Display

Open the **Network** menu and select **Network Type as Wireless Device**.

There are different standards which enable sharing of screens including graphical, video and audio content between your mobile device and TV.

Then press the **Source** button on the remote and switch to **Wireless Display** source.

A screen appears stating that the TV is ready for connection.

Open the sharing application on your mobile device. These applications are named differently for each brand, refer to the instruction manual of your mobile device for detailed information.

Scan for devices. After you select your TV and connect, the screen of your device will be displayed on your TV.

**Note:** This feature can be used only if the mobile device supports this feature. If the operating system version you use supports this feature, then it may be incompatible problems with the operating system versions which are released after the production of this TV. Scanning and connecting processes differ according to the programme you use.

#### Connecting Other Wireless Devices

**Networked Standby Mode** is standard that allows a device to be turned on or woken up by a network message. The message is sent to the device by a program executed on a remote device connected to the same local area network, such as a smartphone. Your TV is Wi-Fi and WLAN compatible. This feature might be disabled during the First Time Installation process. To enable this feature set the **Networked Standby Mode** option in the **Network** menu as **On**.

It is necessary that both the device, from which the network message will be sent to the TV, and the network connected to the same network. Networked Standby Mode feature is only supported for Android OS devices and can only be used via YouTube and Netflix applications.

In order to use this feature the TV and the remote device should be connected at least once while the TV is on. If the TV is powered off, the connection should be re-established, the next time it is switched on. Otherwise this feature will be unavailable. This

**Advanced Settings** and press the **OK** button to open the advanced setting menu. Use directional pad and numeric buttons to set. Highlight **Save** and press the **OK** button to save settings when complete.

#### Other Information

The status of the connection will be displayed as **Connected** or **Not Connected** and the current IP address, if a connections established.

#### Connecting to your mobile device via WLAN

If your mobile device has WLAN feature, you can connect it by your TV via a router, in order to access the content in your device. For this, your mobile device must have an appropriate sharing software. Connect your TV to your router following the steps mentioned in the sections above.

Afterwards, connect your mobile device to the router and then activate the sharing software on your mobile device then, select files that you want to share with your TV. Then press the **Source** button on the remote and switch to **Wireless Display** source.

A screen appears stating that the TV is ready for connection.

Open the sharing application on your mobile device. These applications are named differently for each brand, refer to the instruction manual of your mobile device for detailed information.

Scan for devices. After you select your TV and connect, the screen of your device will be displayed on your TV.

**Note:** This feature can be used only if the mobile device supports this feature. If the operating system version you use supports this feature, then it may be incompatible problems with the operating system versions which are released after the production of this TV. Scanning and connecting processes differ according to the programme you use.

#### Connecting Other Wireless Devices

**Networked Standby Mode** is standard that allows a device to be turned on or woken up by a network message. The message is sent to the device by a program executed on a remote device connected to the same local area network, such as a smartphone. Your TV is Wi-Fi and WLAN compatible. This feature might be disabled during the First Time Installation process. To enable this feature set the **Networked Standby Mode** option in the **Network** menu as **On**.

It is necessary that both the device, from which the network message will be sent to the TV, and the network connected to the same network. Networked Standby Mode feature is only supported for Android OS devices and can only be used via YouTube and Netflix applications.

In order to use this feature the TV and the remote device should be connected at least once while the TV is on. If the TV is powered off, the connection should be re-established, the next time it is switched on. Otherwise this feature will be unavailable. This

devices that use the same wireless technology and start to use them. Follow the on-screen instructions. Start the device discovery. A list of available wireless devices will be displayed. Select the device you want to connect from the list and press the **OK** button to connect. If "Device connected" message is displayed, the connection is successfully established. If the connection fails try it again.

**Note:** Your TV may not be compatible with all keyboard and mouse models in the market. For more information contact your local dealer or retail outlet where you bought your TV.

#### Image transfer and audio streaming

You can also use this type of connection to transfer images or stream audio from your mobile device to your TV.

Pair the mobile device and the TV as described before. Start a device search in your hand-held device. Select your TV from listed devices. Confirm the request for connection on your TV screen and do the same on your hand held device screen. If no pairing is done, image transfer or audio streaming to the TV will not be possible.

The images sent by mobile device will be displayed on the TV without confirmation request, if the image file is suitable. You can also save the image file to a connected USB memory drive as set boot logo. If this feature is supported and the file is suitable. Press the **Exit** button to terminate displaying the image. The audio will be routed through the speakers of the TV, after confirmation is given. To start audio streaming unpair the device from your TV if it is paired with your TV previously. After pairing is completed, a confirmation message will be displayed asking whether you want to start audio streaming from your mobile device. Select **Yes** and press the **OK** button on the remote of the TV. If the connection is succeeded, the audio will be routed through the speakers of the TV. A small window will appear on the upper side of the TV screen as long as the audio streaming connection is active. To terminate the audio streaming, you should run off the wireless connection of your mobile device.

**Select Yes** and press the **OK** button on the remote of the TV. If the connection is succeeded, the audio will be routed through the speakers of the TV. A confirmation message will be displayed on the screen as well as on the mobile device. To stop the audio streaming, you should run off the wireless connection of your mobile device.

#### Using with mobile devices

There are different standards which enable sharing of screens including graphical, video and audio content between your mobile device and TV.

Then press the **Source** button on the remote and connect to **Wireless Display** source.

A screen appears stating that the TV is ready for connection.

Open the sharing application on your mobile device. These applications are named differently for each brand, refer to the instruction manual of your mobile device for detailed information.

Scan for devices. After you select your TV and connect, the screen of your device will be displayed on your TV.

**Note:** This feature can be used only if the mobile device supports this feature. If the operating system version you use supports this feature, then it may be incompatible problems with the operating system versions which are released after the production of this TV. Scanning and connecting processes differ according to the programme you use.

**Select Yes** and press the **OK** button on the TV. Note: Refer to the user manual of the wireless device to learn how to set the device to pairing mode.

You can connect a audio devices, keyboards and mice wirelessly to your TV. Uplink or switch off any other connected audio device in order for wireless connection feature to work correctly. For audio devices you should use the **Audio Link** option, for keyboards and mice the **Input Device** option in the **Settings->Devices** menu. Select the menu option and press the **OK** button to open the **Input Device** menu. Select the **Input Device** option and press the **OK** button to open the **Input Device** menu. Using this menu you can discover and connect the

improve the performance of your wireless device place it at least 1 meter away from any other wireless devices.

## Connectivity Troubleshooting

### Wireless Network Not Available

- Ensure that any firewalls of your network allow the TV wireless connection.
- Try searching for wireless networks again, using the **Network** menu screen.

If the wireless network does not function properly, try using the wired network in your home. Refer to the **Wired Connectivity** section for more information on the process.

If the TV does not function using the wired connection, check the modem (router). If the router does not have a problem, check the internet connection of your modem.

### Connection is Slow

See the instruction book of your wireless modem to get information on the internal service area, connection speed, signal quality and other settings. You need to have a high speed connection for your modem.

### Disruption during playback or slow reactions

You could try the following in such a case:  
Keep at least three meters distance from microwave ovens, mobile telephones, bluetooth devices or any other WLAN compatible devices. Try changing the active channel on the WLAN router.

### Internet Connection Not Available / Audio Video Sharing Not Working

If the MAC address (a unique identifier number) of your PC or modem has been permanently registered, it is possible that your TV might not connect to the internet. In such a case, the MAC address is authenticated each time when you connect to the internet. This is a protection against unauthorized access. Since your TV has its own MAC address, your internet service provider cannot validate the MAC address of your TV. For this reason, your TV cannot connect to the internet. Contact your internet service provider and request information on how to connect a different device, such as your TV, to the internet.

It is also possible that the connection may not be available due to a firewall problem. If you think this causes your problem, contact your internet service provider. A firewall might be the reason of a connectivity and discovery problem while using the TV in Audio Video Sharing mode or while browsing via Audio Video Sharing feature.

### Invalid Domain

Ensure that you have already logged on to your PC with an authorized user name/password and also ensure that your domain is active, prior to sharing any files in your media server program on your PC. If the domain is invalid, this might cause problems while browsing files in Audio Video Sharing mode.

## Using Audio Video Sharing Network Service

Audio Video Sharing feature uses a standard that eases the viewing process of digital electronics and makes them more convenient to use on a Home network.

This standard allows you to view and play photos, music and videos stored in the media server connected to your home network.

### 1. Server Software Installation

See the **Wired/Wireless Connectivity** chapters for detailed configuration information.

### 3. Enable Audio Video Sharing

Enter the **Settings>Devices** menu and enable the **Audio Video Sharing** option.

### 4. Play Shared Files via Media Browser

Highlight the **Audio Video Sharing** option in the **Source** menu by using the directional buttons and press **OK**. Available media server devices in the network will be listed. Select one and press **OK** to continue. The media browser will then be displayed.

Refer to the **Media Browser** menu section for further information on file playback.

If a problem occurs with the network, switch your television off at the wall socket and back on again. Trick mode and the jump feature are not supported by the Audio Video Sharing feature.

PC/HDD/Media Player or any other devices that are compatible should be used with a wired connection for higher playback quality.

Use a LAN connection for quicker file sharing between other devices like computers.

*Note: There may be some PCs which may not be able to utilize the Audio Video Sharing feature due to administrator and security settings (such as a business PC).*

### Apps

You can access the applications installed on your TV from the **Home** menu. Press the **Menu** button on the remote. **Home** menu will be displayed. Highlight an app and press **OK** to launch or remove it. Highlight an app and press **OK** to see the available options.

In order to manage the apps installed on your TV, you can use the **More Apps** option in the **TV** menu. You can add, remove or update the **Home** menu, launch or remove the **More Apps** option in the **TV** menu. You can add new apps from the application market. To access the market highlight the **Market** option in the **TV** menu and press **OK**. Available apps will be displayed.

You can also access the application market from within the **More Apps** menu.

You can reset your customisations on the **Home** menu, including app-related ones, to default using the **Reset Apps** option in the **Settings** menu (availability depends on TV model and its features). Highlight this option and press **OK**. A confirmation message will be displayed. Highlight **Yes** and press **OK** to proceed. Note that you will not be able to perform its operation again within the next few minutes.

### Notes:

The possible application dependent problems may be caused by the content service provider.  
Third party internet services may change, be discontinued or restricted at any time.

### Internet Browser

To use the internet browser, enter the **Home** menu first. Then launch the internet browser application which has an orange coloured logo with earth symbol on it.

In the initial screen of the browser, the thumbnails of the predefined (if any) links to web sites available will be displayed. Select one of them and press **OK** to open the **Edit Speed Dial** and the **Add to Speed Dial** options. To navigate the web browser, use the directional buttons on the remote or a connected mouse. To see the browser user options bar, move the cursor to the top of the page. **History**, **Tabs** and **Bookmarks** options in the browser bar which contains previous/next buttons, the refresh button, the address/search bar, the **Speed Dial** and the **View** buttons are available.

To add a desired website to the **Speed Dial** list for quick access, move the cursor to the top of the page or press **View** button and press the **OK** button. Then highlight the **Add to Speed Dial** option in the submenu and press the **OK** button again. **Name** and **Address** will be filled automatically according to the site you are visiting. Highlight **OK** and press the **OK** button to add.

You can also use the **View** menu option to manage the browser. Highlight the **View** button and press the **OK** button to see available page specific and general options.

There are various ways to search or visit websites using the web browser.

Enter the address of a website (URL) into the **Search** address bar and highlight the **Enter** button on the virtual keyboard and press the **OK** button to visit the site.

Enter keywords into the search/address bar and highlight the **Enter** button on the virtual keyboard and press the **OK** button to start a search for the related websites.

Highlight a Speed Dial thumbnail and press the **OK** button to visit the related website.  
Plug-in with USB mice. Your TV is compatible with USB mice or wireless mouse adaptor into the **USB** input of your TV for easier and quicker navigation.

Some web pages include flash content. These are not supported by the browser.  
Your TV does not support any download processes from the internet via the browser.

All sites on the internet might not be supported. According to the circumstances video contents might not be able to be played.

### HBTV System

HBTV (Hybrid Broadcast Broadband TV) is a new industry standard that seamlessly combines TV services delivered via broadcast with services delivered via broadband and also enables access to internet only services for consumers using connected TV and set-top boxes. Services delivered through HBTV include traditional broadcast TV channels, catch-up services, video-on-demand, electronic programme guide, interactive advertising, personalisation, voting, games, social networking and other multimedia applications. HBTV applications are available on channels where they are signalled by the broadcaster. The broadcaster marks one application as "autoplay" and this one is started by the platform automatically. The autoplay applications are generally launched with a small red button icon to notify the user that there is an HBTV application on that channel. Press the red button to open the application page. After the page is displayed you can go back to the initial red button displayed by pressing the red button again. You can toggle between the red button icon mode and full UI mode of the application via pressing red button. It should be noted that the red button switching capability is provided by the application and some application may behave differently (other colour buttons such as green, yellow, blue, may be defined for some other functions, e.g. shructics).

To switch to another channel while an HBTV application is active (either in red button icon mode or full UI mode), the following scenarios can occur.

The application can continue running.

The application can be terminated and another auto-start red button application can be launched.

HBTV allows the applications to be retrieved both from broadcast or broadcast. The broadcaster may enable

bothways or one of them. If the platform does not have an operational broadband connection, the platform can still launch applications transmitted on broadcast.

The auto-start red button applications generally provide links to other applications. The user then can switch to other applications by using the links provided. The applications should provide a way to terminate themselves, usually **Exit** button is used for this. HbbTV applications use keys on the remote control to interact with the user. When an HbbTV application is launched, the control of some keys are owned by the application. For example, numeric channel selection may not work on a television application where the numbers reflect teletext pages.

HbbTV requires AV streaming capability for the platform. There are numerous applications providing VOD (video on demand) and catch-up TV services. The user can use play, pause, stop, forward, and rewind keys on the remote control to interact with the AV content.

**Note:** You can enable or disable this feature from the **Privacy Settings** in **Settings>System** menu.

### Smart Center

Smart Center is a mobile application running on iOS and Android platforms. With your mobile device, you can easily stream your favourite live shows and programmes from your smart TV. Also, you can launch your applications, use your mobile device as a remote control for your TV and share media files.

**Note:** Being able to use all functions of this application depends on the features of your TV.

### Getting Started

To be able to use internet-based features, your modem/router must be connected to the internet.

**IMPORTANT:** Make sure the TV and mobile device are connected to the same network.

For media sharing feature **Audio Video Sharing** option should be enabled (if available). Press the **Menu** button on the remote, select **Settings>Devices** menu and press **OK**. **HighLight** **Audio Video Sharing** and change as **Enabled**. Your TV is ready to connect to your mobile device now.

Install the **Smart Center** application onto your mobile device.

Start the **Smart Center** application. If all connections are configured properly, you will see your TV's name on your mobile device. If your TV's name doesn't appear on the list, wait a while and tap on the **Refresh** widget. Select your TV from the list.

### Mobile Device screen

On the main screen you can find tabs to access various features.

The application retrieves actual channel list from TV first when it starts.

**MY CHANNELS:** The programmes of first four channels from the channel list retrieved from the TV are shown. You can change the listed channels. Press on the channel thumbnail and hold. A list of channels will be displayed and you can choose your desired channel to be replaced.

TV: You can watch content through the TV tab. In this mode, you can navigate through the channel list retrieved from your TV and click on thumbnails to view the detail pages.

**RECORDINGS:** You can view your active recordings (if available) and reminders through this tab. To delete any item, simply press on the delete icon found on each row.

**EPG(Electronic programme guide):** You can view the broadcast schedules of selected channel lists through this tab. You can also navigate through channels by pressing on the selected channel on the EPG grid. Please note that updating /refreshing the EPG information may take a while depending on your network and web service quality.

**Note:** Internet connection is required for WEB based EPG information.

**SETTINGS:** Configure the application to your liking. You can change;

**Auto-select FollowMeTV:** FollowMeTV function (if available) will start automatically when this setting is enabled. Default is disabled.

**Auto-connection to TV:** When enabled, your mobile device will automatically connect to last connected TV and skips the TV search screen.

**Change TV:** Shows the currently connected TV. You can press on this setting to go to the "TV" search screen and change to a different TV.

**Edit custom channel list:** You can edit your custom channel list using this setting.

**Choose channel list source:** You can choose the channel list source to be used in the application. The options are "TV List" and "Custom List". Additionally you can activate "Remember my choice" option to set the selected channel list source as a constant choice. In this case if the selected source is available it will be used in the application.

**Version No.:** Displays the current version of the application.

### Detail Page

To open detail page tap on a programme. On the detail page you can get detailed information of the programmes you select. There are "Details", "Cast&Crew" and "Videos" tabs to find on this page.

**DETAILS:** This tab provides summary and information about the selected programme.

**CAST&CREW:** Shows all the people contributed to the current programme.

**VIDEOS:** Provides videos on YouTube related to the selected channel.

**Note:** For some functions an internet connection may be required.

**FollowMe TV Feature (if available)**

Tap on the **FOLLOW ME TV** widget located at the upper right of the screen of your mobile device to change the layout for **FollowMe TV** feature.

**Tap the play icon to start streaming of the content from the TV to your mobile device. Available if your device is in your routers operation range.**

**Mirror Mode**

This mode of **FollowMe TV** content is enabled by default and allows streaming the content from any other selected TV sources and Media Brower.

**Notes:**

**Note:** Only *digital(DVB-T/C/S) SD and HD channels are supported.*

**Multilingual audio support and subtitle on/off features are not functional.**

**The streaming performance may change depending on the quality of your connection.**

**Media Share Page**

To access the **Media Share** widget tap on the **Up-arrow** on the upper right side of the screen. If the **Media Share** widget is pressed, a screen is displayed where you can select the media file type to share with your TV.

If the **Media Share** widget is pressed, a screen is displayed where you can select the media file type to share with your TV.

**Note:** Not all image formats are supported. This function will not work if audio/video sharing feature is not supported.

**Smart Remote Feature**

You can use your mobile device as a remote control for your TV once it has been connected to the TV. To access smart remote's full features you can use the menu at the bottom middle of the screen.

**Voice Recognition**

You can tap on the **Microphone** ( ) widget and manage your application, giving voice commands such as "Volume Up/Down", "Programme Up/Down".

**Note:** This feature is only for android-based devices available.

### Keyboard Page

The keyboard page can be opened in two ways: by pressing the **Keyboard** ( ) widget on the application screen or automatically by receiving a command from the TV.

**Requirements**

1. Smart TV

2. Network connection

**Mobile Device based on Android or iOS platform (Android OS 5.1 or higher; iOS 12 or higher version)**

**Smart Center app (to be found on online application stores based on Android and iOS platforms)**

**Router modem**

**USB storage device in FAT32 format (required for USB Recording feature, if available)**

**Notes:**

**For Android devices, Normal(middle), Large(laptop) and Extra Large(desktop) screen sizes are supported. Devices with 3 or smaller screen sizes are not supported.**

**For iOS devices, all screen sizes are supported.**

**For OS devices, all screen sizes are supported.**

**User interface of the Smart Center application is subject to change according to version installed on your device.**

**Alexa Ready**

Alexa is Amazon's cloud-based voice service available in many voice controlled assistant devices. By means of the Alexa built-in and Works With Alexa features you can use your TV as an Alexa device and control the functions of your TV with Alexa.

**Alexa Built-in**

You can use your TV as an Alexa device. In order to do this, a Microphone Box ( ) will be required. After connecting your Microphone Box to your TV, the setup process should be completed. The setup can be carried out in the ways described below.

**(1) The Microphone Box can be purchased separately if not supplied with the unit. For more information contact your local retailer or dealer where you bought your TV.**

**\* Use the Alexa Built-in option in the **Settings>System>Setup>Voice Assistant** menu**

**\* Carry out the first time installation on your TV. The setup wizard will guide you through the setup process. Refer to the user manual of the Microphone Box for detailed information.**

**Alexa Home Screen**

Once the setup is complete, Alexa Home Screen feature will be integrated. This feature is an ambient screen which appears when no user activity is detected. A background image, time and date information and voice command suggestions will be displayed on the Alexa Home Screen.

**You can use the Alexa Home Screen option in the **Settings>System>Voice Assistant>Alexa Built-in** menu to configure the settings of this feature. You can set off one of the inactivity periods to enable or set to Off if disable.**

**Alexa Home Screen is displayed only when web browser or any other video on demand application except Netflix is running. It appears when no user activity is**

detected during the predefined inactivity period unless a media playback is in progress. Watching a movie, for example, is not considered as user inactivity.

You can press remote control buttons to make it disappear. As an exception you can use the **Volume +/-** buttons to control volume level even when Alexa Home Screen is running.

#### Works With Alexa

You can control the functions of your TV with Alexa. In order to do this, the setup process should be completed. The setup can be carried out in the ways described below.

- Use the **Works With Alexa** option in the **Settings->System>Voice Assistant** menu
- Carry out first time installation on your TV. The setup installation process is completed after the installation process is completed

#### Setup wizard

The wizard will guide you through the setup process.

- If you carry out first time installation on your TV, the Alexa setup wizard will be displayed after the installation process is completed. On the first screen highlight **Learn More** option and press **OK**. On the next screen you will be informed about the feature. Highlight **Start** and press **OK** to proceed.

If you skip the setup wizard after the first time installation you can use the **Works With Alexa** option in the **Settings->System>Voice Assistant** menu to carry out the setup later manually. On the first screen you will be informed about the feature. Highlight **Start** and press **OK** to proceed.

• An authentication code will be created and displayed on the screen. Use your computer or any other device with internet access to go to the internet address ([URL](http://)) shown on the screen. You will be directed to a page where you can sign in to your Amazon account first. If you are not already signed in, then you will be redirected to a page where you can enter the authentication code you see on the TV and link your TV to your Amazon account.

• If the linking process was successful you will be asked to determine a name for your TV, called **Friendly Name**. A **Friendly Name** is a name that reminds you of your TV such as 'Living Room TV', 'Dining Room TV', 'Kitchen TV', 'Dining Room TV', etc. Choose an easy-to-say name. You will say this name to tell Alexa which TV to control. When you are done, highlight **OK** and press **OK**.

• Examples about the use of the feature will be displayed on the next screen. Press **OK** to finish the setup.

If you carried out the setup after the first time installation you will return to the first screen of the setup wizard when you press **OK**. In that case press **Exit** or highlight **Setup Later** and press **OK** in order to exit the setup.

Once the setup is complete you will be able to control the functions of your TV with Alexa.

**Note:** Make sure that the devices are connected to the internet.

#### Example Commands

Here are some voice commands that you can use:

Command	Function
Alexa, turn on FN	Powers on the TV
Alexa, turn off FN	Powers off the TV
Alexa, start FN	Starts media playback
Alexa, pause FN	Pauses media playback
Alexa, resume FN	Resumes media playback
Alexa, stop FN	Stops media playback
Alexa, advance media in fast forward mode	Advances media in fast forward mode
Alexa, rewind on FN	Rewinds media
Alexa, set the volume of 50	Sets the volume to the specified level
Alexa, turn the volume up on FN	Increases volume by 10 units
Alexa, turn the volume down on FN	Decreases volume by 10 units
Alexa, mute FN	Mutes sound
Alexa, unmute FN	Unmutes sound
Alexa, change the input to "input_name" on FN	The TV switches to the input source with the specified <b>friendly name</b> (e.g., <b>HDMI 1</b> )
Alexa, change channel to "channel_number" on FN	The TV switches to the channel with the specified <b>channel number</b> (e.g., <b>channel 200</b> )
Alexa, channel up on FN	The TV switches to the next higher channel, if any available
Alexa, channel down on FN	The TV switches to the next lower channel, if any available

#### Google Assistant

Your TV works with OK Google for voice control of your connected devices and appliances.

#### Works With OK Google

By means of this feature you can control the functions of your TV with Google Assistant devices. In order to do this, the setup process should be completed.

#### Before the setup

Complete the following procedures before you start the setup on your TV.

- Install the Google Home application on your mobile phone and login to your account
- Add the assistant device to your account
- Select the **Vsmart TV** action from the list of actions within the application

#### Setup process

A screen will be displayed where you will enter the authentication code which will be created during the setup process on your TV in order to link your TV to your account. Continue with the setup on your TV to get the authentication code.

#### Setup process

The setup can be carried out by using the **Google Assistant** option in the **Settings->System->Voice Assistant** menu. The wizard will guide you through the setup process.

- On the first screen highlight **Start** and press **OK** to proceed

#### Setup process

You will be asked to determine a name for your TV on the next screen, called **Friendly Name** (FN). A **Friendly Name** is a name that reminds you of your TV such as 'Living Room TV', 'Kitchen TV', 'Dining Room TV', etc. Choose an easy-to-say name. When you are done, highlight **OK** and press **OK**.

#### Setup process

An authentication code will be created and displayed on the screen. Enter the code you see on the TV on the Google Home application

Once the setup is complete, you will be able to control the functions of your TV with Google Assistant.

**Note:** Make sure that the devices are connected to the internet.

You can link only one TV to your account.

#### Example Commands

Just say 'Ok Google' to control your TV using just your voice.

#### Google Commands

YOur TV works with OK Google for voice control of your connected devices and appliances.

#### Works With Google

The TV switches to the channel with the specified **friendly name** (e.g., **HDMI 1**)

#### Before the setup

The TV switches to the channel with the specified **channel number** (e.g., **channel 200**)

#### Setup process

The TV switches to the next higher channel, if any available

#### Setup process

The TV switches to the next lower channel, if any available

#### Example Commands

**Google** is a trademark of Google LLC.

#### Example Commands

**FN** is the abbreviation for '**Friendly Name**'.

#### Amazon DART

Once the setup is complete, the DART (Dash Replenishment) Through Alexa feature will be integrated. This feature enables new batteries to be ordered automatically when the remote control is low on batteries. You can use Alexa App to configure DART settings, e.g. the battery type you want to be ordered.

#### Example Commands

**DART** is the abbreviation for '**Friendly Name**'.

#### Example Commands

**Amazon** is a trademark of Amazon.com, Inc. or its affiliates.

#### Example Commands

**English** - 38 -

## **AC Adaptor Specifications**

Manufacturer Name	SHENZHEN HUNKEY ELECTRIC CO., LTD
Model Identifier	HK4120240384B
Input Voltage (V)	100-240
Input AC Frequency (Hz)	50-60
Output Voltage (V)	24.0
Output Current (A)	3.75
Average Active Efficiency	% 88.0
Efficiency at Low Load (%@)	% 85.0
No-load Power Consumption (W)	0.21

## **Battery Specifications**

Runtime	Approx 2.5 hours (1)
Cell Type	Li-Ion 21700 (4900mAh)

(1) Running time can be extended up to 4 hours depending on the **Power Mode** setting in the **Settings >Battery** menu

## **DVB Functionality Information**

This DVB receiver is only suitable for use in the country which it was designed to be used in.

Although this DVB receiver conforms to the latest DVB specifications at the time of manufacture, we cannot guarantee compatibility with future DVB transmissions due to changes that may be implemented in broadcast signals and technologies.

Some digital television functions may not be available in all countries.

We continually strive to improve our products; therefore, specifications may change without prior notice.

For advice on where to purchase accessories, please contact the store where you purchased your equipment.

- TR:** İşbu belgede; VESTEL Elektronik Sanayi ve Ticaret A.Ş., telsiz ekipmanı tipi TFT IDTV 'nin 2014/53/AB sayılı direktifte uygun olduğuunu beyan eder. AB uygunluk beyanının tam metni internet adresinde mevcuttur: doc.vosshub.com
- EN:** Hereby, VESTEL Elektronik Sanayi ve Ticaret A.Ş., declares that the radio equipment type TFT IDTV is in compliance with Directive 2014/53/EU. The full text of the EU declaration of conformity is available at the following internet address: doc.vosshub.com
- BG:** С настоящото VESTEL Elektronik Sanayi ve Ticaret A.Ş., декларира, че този тип радиооборудование TFT IDTV е в съответствие с Директива 2014/53/EU. Цялостният текст на ЕС декларацията за съответствие може да се намери на следния интернет адрес: doc.vosshub.com
- CZ:** Tímto VESTEL Elektronik Sanayi ve Ticaret A.Ş., prohlašuje, že typ rádiového zařízení TFT IDTV je v souladu se směrnicí 2014/53/EU. Úplné znění EU prohlášení o shodě je k dispozici na této internetové adrese: doc.vosshub.com
- DA:** Hermed erklærer VESTEL Elektronik Sanayi ve Ticaret A.Ş., at radioudstyrstypen TFT IDTV er i overensstemmelse med direktiv 2014/53/EU. EU-overensstemmelseserklæringens fulde tekst kan findes på følgende internetadresse: doc.vosshub.com
- DE:** Hiermit erklärt VESTEL Elektronik Sanayi ve Ticaret A.Ş., dass der Funkanlagentyp TFT IDTV der Richtlinie 2014/53/EU entspricht. Der vollständige Text der EU-Konformitätserklärung ist unter der folgenden Internetadresse verfügbar: doc.vosshub.com
- EL:** Με την παρούσα ο/η VESTEL Elektronik Sanayi ve Ticaret A.Ş., δηλώνει ότι ο ραδιοεπιλογές TFT IDTV πληροί την οδηγία 2014/53/ΕΕ. Το πλήρες κείμενο της δήλωσης συμμόρφωσης ΕΕ διατίθεται στην ακόλουθη ιστοσελίδα στο διαδίκτυο: doc.vosshub.com
- ES:** Por la presente, VESTEL Elektronik Sanayi ve Ticaret A.Ş., declara que el tipo de equipo radioeléctrico TFT IDTV es conforme con la Directiva 2014/53/UE. El texto completo de la declaración UE de conformidad está disponible en la dirección Internet siguiente: doc.vosshub.com
- ET:** Käesolevaga deklareerib VESTEL Elektronik Sanayi ve Ticaret A.Ş., et käesolev raadioseadme tüüp TFT IDTV vastab direktiivi 2014/53/EL nõuetele. ELI vastavusdeklaratsiooni täielik tekst on kättesaadav järgmisel internetaadressil: doc.vosshub.com
- FI:** VESTEL Elektronik Sanayi ve Ticaret A.Ş., vakuuttaa, että radiolaitetyyppi TFT IDTV on direktiivin 2014/53/EU mukainen. EU-vaatimustenmukaisuusvakuutuksen täysimittainen teksti on saatavilla seuraavassa internetsoitteessa: doc.vosshub.com
- FR:** Le soussigné, VESTEL Elektronik Sanayi ve Ticaret A.Ş., déclare que l'équipement radioélectrique du type TFT IDTV est conforme à la directive 2014/53/UE. Le texte complet de la déclaration UE de conformité est disponible à l'adresse internet suivante: doc.vosshub.com
- HR:** VESTEL Elektronik Sanayi ve Ticaret A.Ş., ovime izjavljuje da je radikska oprema tipa TFT IDTV u skladu s Direktivom 2014/53/EU. Cjeloviti tekst EU izjave o sukladnosti dostupan je na sljedećoj internetskoj adresi: doc.vosshub.com
- HU:** VESTEL Elektronik Sanayi ve Ticaret A.Ş., igazolja, hogy a TFT IDTV típusú rádióberendezés megfelel a 2014/53/EU irányelvnek. Az EU-megfelelőségi nyilatkozat teljes szövege elérhető a következő internethoz címen: doc.vosshub.com
- IT:** Il fabbricante, VESTEL Elektronik Sanayi ve Ticaret A.Ş., dichiara che il tipo di apparecchiatura radio TFT IDTV è conforme alla direttiva 2014/53/UE. Il testo completo della dichiarazione di conformità UE è disponibile al seguente indirizzo Internet: doc.vosshub.com
- LT:** Aš, VESTEL Elektronik Sanayi ve Ticaret A.Ş., patvirtinu, kad radio įrenginių tipas TFT IDTV atitinka Direktyvą 2014/53/ES. Visas ES atitikties deklaracijos tekstas prieinamas šiuo internetu adresu: doc.vosshub.com
- LV:** Ar šo VESTEL Elektronik Sanayi ve Ticaret A.Ş., deklarē, ka radioiekārtai TFT IDTV atbilst Direktīvai 2014/53/ES. Pilns ES atbilstības deklarācijas teksts ir pieejams šādā interneta vietnē: doc.vosshub.com
- MT:** B'dan, VESTEL Elektronik Sanayi ve Ticaret A.Ş., niddikjara li dan it-tip ta' tagħmir tar-radju TFT IDTV huwa konformi mad-Direttiva 2014/53/UE. It-test kollu tad-dikkarazzjoni ta' konformità tal-UE huwa disponibbli f'dan l-indirizz tal-Internet li ġej: doc.vosshub.com
- NL:** Hierbij verklaar ik, VESTEL Elektronik Sanayi ve Ticaret A.Ş., dat het type radioapparatuur TFT IDTV conform is met Richtlijn 2014/53/EU. De volledige tekst van de EU-conformiteitsverklaring kan worden geraadpleegd op het volgende internetadres: doc.vosshub.com
- PL:** VESTEL Elektronik Sanayi ve Ticaret A.Ş., niniejszym oświadczyc, że typ urządzenia radioowego TFT IDTV jest zgodny z dyrektywą 2014/53/UE. Pełny tekst deklaracji zgodności UE jest dostępny pod następującym adresem internetowym: doc.vosshub.com
- PT:** O(a) abaixo assinado(a) VESTEL Elektronik Sanayi ve Ticaret A.Ş., declara que o presente tipo de equipamento de rádio TFT IDTV está em conformidade com a Diretiva 2014/53/UE. O texto integral da declaração de conformidade está disponível no seguinte endereço de Internet: doc.vosshub.com
- RO:** Prin prezenta, VESTEL Elektronik Sanayi ve Ticaret A.Ş., declară că tipul de echipamente radio TFT IDTV este în conformitate cu Directiva 2014/53/UE. Textul integral al declarării UE de conformitate este disponibil la următoarea adresă internet: doc.vosshub.com
- SK:** VESTEL Elektronik Sanayi ve Ticaret A.Ş., týmto vyhlásuje, že rádiové zariadenie typu TFT IDTV je v súlade so smernicou 2014/53/EU. Úplné EU vyhlásenie o zhode je k dispozícii na tejto internetovej adrese: doc.vosshub.com
- SL:** VESTEL Elektronik Sanayi ve Ticaret A.Ş., potrjuje, da je tip radijske opreme TFT IDTV skladen z Direktivo 2014/53/EU. Celotno besedilo izjave EU o skladnosti je na voljo na naslednjem spletnem naslovu: doc.vosshub.com
- SV:** Härmär försäkrar VESTEL Elektronik Sanayi ve Ticaret A.Ş., att denna typ av radioutrustning TFT IDTV överensstämmer med direktiv 2014/53/EU. Den fullständiga texten till EU-försäkran om överensstämmelse finns på följande webbadress: doc.vosshub.com







**TELEFUNKEN**



50678389